

METTLER TOLEDO

Table of Contents

1	Introduction	7
1.1	Further documents and information	7
1.2	Explanation of conventions and symbols used	7
1.3	Acronyms and abbreviations	7
1.4	Product range	8
1.4.1	XSR precision balances	8
1.4.1.1	S weighing platform	8
1.4.1.2	L weighing platform	9
1.5	Compliance information	9
2	Safety Information	11
2.1	Definitions of signal words and warning symbols	11
2.2	Product-specific safety information	11
3	Design and Function	13
3.1	Function description	13
3.2	Overview S weighing platform	13
3.2.1	Balances with readability 1 mg	13
3.2.2	Balances with readability 10 mg and 100 mg	14
3.2.3	Interface board	14
3.3	Overview L weighing platform	15
3.3.1	Balances with readability of 100 mg and 1 g	15
3.3.2	Interface board	15
3.4	Overview terminal	16
3.5	Overview type label	16
3.6	User interface	17
3.6.1	Main sections at a glance	17
3.6.2	Main weighing screen	17
3.6.3	Panel "Balance menu"	18
3.6.4	Panel "Methods"	18
3.6.5	Panel "Results"	19
3.6.6	Icons and symbols	20
3.6.6.1	System status icons	20
3.6.6.2	Weighing status icons	20
3.6.6.3	Process status icons	21
4	Installation and Putting into Operaton	22
4.1	Selecting the location	22
4.2	Unpacking the balance	22
4.3	Scope of delivery	23
4.3.1	S weighing platform	23
4.3.2	L weighing platform	23
4.4	Installation	23
4.4.1	Balances with S weighing platform	23
4.4.1.1	Attaching the terminal to the weighing platform	23
4.4.1.2	Assembling balances 1 mg with MagicCube draft shield and SmartPan weighing pan	25
4.4.1.3	Assembling balances 1 mg with SmartPan weighing pan	26
4.4.1.4	Assembling balances 10 mg with SmartPan weighing pan	27
4.4.1.5	Assembling balances 100 mg	27
4.4.2	Balances with L weighing platform	27
4.4.2.1	Attaching the terminal to the weighing platform	27
4.4.2.2	Assembling balances 100 mg and 1 g	28
4.5	Putting into operation	28
4.5.1	Connecting the balance	28

4.5.2	Switching on the balance	29
4.5.3	Leveling the balance	29
4.5.4	Performing an internal adjustment	30
4.5.5	Entering / Exiting standby mode	30
4.5.6	Switching off the balance	30
4.6	Performing a simple weighing	30
4.6.1	Zeroing the balance.....	30
4.6.2	Taring the balance	30
4.6.3	Performing a weighing	31
4.6.4	Completing the weighing	31
4.7	Transporting, packing and storing.....	31
4.7.1	Transporting the balance over short distances	31
4.7.2	Transporting the balance over long distances	32
4.7.3	Packing and storing	32
4.8	Weighing below the balance.....	32
4.8.1	S weighing platform	32
4.8.2	L weighing platform	33

5	Operation	34
5.1	Touch screen	34
5.1.1	Selecting or activating an item	34
5.1.2	Scrolling	34
5.1.3	Entering characters and numbers.....	34
5.1.4	Changing the date and time	35
5.2	Methods.....	35
5.2.1	Methods overview	35
5.2.2	Method "General weighing"	35
5.2.2.1	Creating a method "General weighing"	36
5.2.2.2	Performing a "General weighing"	36
5.2.3	Method "Simple formulation"	37
5.2.3.1	Creating a method "Simple formulation"	38
5.2.3.2	Method "Simple formulation"	38
5.2.4	Method "Titration"	39
5.2.4.1	Creating a method "Titration"	39
5.2.4.2	Performing a "Titration".....	39
5.2.5	Method "Density determination"	40
5.2.5.1	Creating a method "Density determination"	40
5.2.5.2	Performing a "Density determination"	41
5.2.6	Method "Piece Counting"	41
5.2.6.1	Creating a method "Piece Counting"	42
5.2.6.2	Performing a "Piece Counting".....	42
5.2.7	Editing a method	43
5.2.8	Cloning a method	43
5.2.9	Deleting a method.....	43
5.2.10	Using methods with multiple weighing items (itemized)	43
5.2.10.1	Creating a new method with multiple weighing items (itemized).....	44
5.2.10.2	Creating an itemized method from a completed task	44
5.2.10.3	Performing an itemized method	44
5.3	Test weights	45
5.3.1	Defining an individual test weight	45
5.3.2	Defining a combined test weight	45
5.4	Tests.....	45
5.4.1	Overview routine tests.....	45
5.4.1.1	Eccentricity.....	46
5.4.1.2	Repeatability test.....	46
5.4.1.3	Sensitivity test.....	46
5.4.2	Creating a new test	46
5.4.3	Performing a test	47

5.4.3.1	Performing an "Eccentricity"	47
5.4.3.2	Performing a "Repeatability test"	48
5.4.3.3	Performing a "Sensitivity test"	49
5.4.4	Editing a test	51
5.4.5	Printing test results.....	51
5.4.6	Deleting a test	51
5.4.7	Consulting the test history	51
5.5	Adjustments.....	52
5.5.1	Internal adjustment	52
5.5.1.1	Editing an "Internal adjustment"	52
5.5.1.2	Performing an "Internal adjustment"	52
5.5.2	External adjustment.....	52
5.5.2.1	Editing an "External adjustment"	52
5.5.2.2	Performing an "External adjustment"	53
5.5.3	Consulting the adjustment history	53
5.6	Peripheral devices	53
5.6.1	Printer	53
5.6.1.1	Printing results manually on a strip printer via USB.....	54
5.6.1.2	Printing results automatically on a label printer via Bluetooth.....	55
5.6.2	Barcode reader	57
5.6.2.1	Scan a sample ID using a barcode reader	57
5.6.3	Foot switch and ErgoSens.....	58
5.6.3.1	Taring the balance with an ErgoSens.....	58
5.6.4	Editing the settings of a device	59
5.6.5	Deleting a device	59
5.7	Remote control via services	59
5.7.1	LabX service.....	59
5.7.1.1	Using LabX via a USB connection	60
5.7.1.2	Using LabX via an Ethernet connection	60
5.7.2	MT-SICS service.....	60
5.7.2.1	Using MT-SICS via a USB connection	61
5.7.2.2	Using MT-SICS via an Ethernet connection	61
5.7.3	Web service	62
5.8	Data management.....	63
5.8.1	Exporting results	63
5.8.2	Sending individual results to a computer	64
5.8.3	Exporting and importing settings.....	65
5.8.3.1	Transferring test weight settings between balances.....	65
5.9	Tolerance profiles	66
5.10	Password protection and balance reset.....	66
5.10.1	Creating an unblocking password.....	66
5.10.2	Blocking and unblocking the settings	67
5.10.2.1	Blocking the balance settings	67
5.10.2.2	Blocking method settings.....	67
5.10.2.3	Unblocking the settings.....	67
5.10.3	Blocking and unblocking the balance.....	67
5.10.3.1	Blocking the balance.....	68
5.10.3.2	Unblocking the balance	68
5.10.4	Resetting the balance	68

6	Software Description	69
6.1	Balance menu settings.....	69
6.1.1	Leveling aid	69
6.1.2	History.....	69
6.1.2.1	Adjustments	69
6.1.2.2	Tests	70
6.1.2.3	Service	70
6.1.3	Balance info.....	70

6.1.4	Settings	70
6.1.4.1	Balance	71
6.1.4.2	Interfaces	77
6.1.4.3	Devices / Printers	78
6.1.4.4	LabX / Services	79
6.1.4.5	Printing the settings	79
6.1.5	Maintenance	80
6.1.5.1	Service menu	80
6.2	Weighing methods settings	81
6.2.1	Settings: method "General weighing"	81
6.2.1.1	General	81
6.2.1.2	ID format	81
6.2.1.3	Weighing	82
6.2.1.4	Weighing item / Weighing items	84
6.2.1.5	Automation	85
6.2.1.6	Print / Export	86
6.2.2	Settings: method "Simple formulation"	90
6.2.2.1	General	90
6.2.2.2	Formulation	91
6.2.2.3	ID format	92
6.2.2.4	Weighing	93
6.2.2.5	Weighing item	93
6.2.2.6	Weighing items	94
6.2.2.7	Automation	95
6.2.2.8	Print / Export	96
6.2.3	Settings: method "Titration"	99
6.2.3.1	General	100
6.2.3.2	ID format	100
6.2.3.3	Weighing	101
6.2.3.4	Weighing item	102
6.2.3.5	Automation	102
6.2.3.6	Print / Export	103
6.2.4	Settings: method "Density determination"	107
6.2.4.1	General	107
6.2.4.2	Density	108
6.2.4.3	ID format	108
6.2.4.4	Weighing	109
6.2.4.5	Weighing item	110
6.2.4.6	Automation	111
6.2.4.7	Print / Export	111
6.2.5	Settings: method "Piece Counting"	113
6.2.5.1	General	113
6.2.5.2	ID format	114
6.2.5.3	Weighing	115
6.2.5.4	Weighing item	116
6.2.5.5	Automation	116
6.2.5.6	Print / Export	118
6.3	Test weights settings	121
6.3.1	Settings: individual test weight	121
6.3.2	Settings: combined test weight	122
6.4	Tests settings	122
6.4.1	Settings: Eccentricity	122
6.4.2	Settings: Repeatability test	126
6.4.3	Settings: Sensitivity test	129
6.5	Adjustments settings	132
7	Maintenance	135
7.1	Maintenance tasks	135

7.2	Cleaning	135
7.2.1	Cleaning agents.....	135
7.2.2	Cleaning the MagicCube draft shield	136
7.2.3	Cleaning the balance.....	136
7.2.4	Putting into operation after cleaning	137
7.3	Service.....	137
7.4	Software update	137
7.4.1	Updating the software.....	138
7.4.2	Restoring the software to the previous version	138
7.4.3	Putting into operation after software update.....	138
8	Troubleshooting	139
8.1	Error messages.....	139
8.2	Error symptoms	139
8.3	Putting into operation after fixing an error	141
9	Technical Data	142
9.1	General data.....	142
9.2	Explanatory notes for the METTLER TOLEDO AC/DC adapter.....	143
9.3	Model-specific data	144
9.3.1	S platform	144
9.3.1.1	Readability 1 mg, with MagicCube Draft Shield and SmartPan	144
9.3.1.2	Readability 1 mg, with SmartPan.....	145
9.3.1.3	Readability 10 mg, with SmartPan.....	146
9.3.1.4	Readability 100 mg	148
9.3.2	L platform	150
9.3.2.1	Readability 100 mg	150
9.3.2.2	Readability 1 g	152
9.4	Dimensions	153
9.4.1	S platform, readability 1 mg, with MagicCube Draft Shield and SmartPan.....	153
9.4.2	S platform, readability 1 mg, with SmartPan	154
9.4.3	S platform, readability 10 mg, with SmartPan	155
9.4.4	S platform, readability 100 mg	156
9.4.5	L platform, readability 100 mg / 1 g	157
10	Disposal	158
11	Accessories and Spare Parts	159
11.1	Accessories	159
11.2	Spare parts.....	165
11.2.1	Balances S weighing platform	165
11.2.1.1	Balance S platform, readability 1 mg, SmartPan, MagicCube draft shield	165
11.2.1.2	Balance S platform, readability 1 mg, SmartPan.....	166
11.2.1.3	Balance S platform, readability 10 mg, SmartPan.....	167
11.2.1.4	Balance S platform, readability 100 mg	168
11.2.2	Balances L weighing platform	169
11.2.2.1	Balance L platform, readability 100 mg / 1 g.....	169
11.2.3	Miscellaneous	170
11.2.4	MagicCube draft shield	171
11.2.5	Packaging	172
11.2.5.1	S platform with draft shield.....	172
11.2.5.2	S platform without draft shield	173
11.2.5.3	L platform, readability 10 mg.....	174
11.2.5.4	L platform, readability 100 mg and 1g.....	175
12	Appendix	176
12.1	Approved balances.....	176
12.1.1	Definitions.....	176

12.1.2	Descriptive markings	176
12.1.3	Restrictions on zeroing and taring	176
12.1.4	Factory method: General Weighing	176
12.1.5	Representation of weighing results	177
12.1.6	MT-SICS.....	178
12.1.7	Reference	178

Index

179

1 Introduction

Thank you for choosing a METTLER TOLEDO balance. The balance combines high performance with ease of use.

This document is based on the software version V 2.0.501.

EULA

The software in this product is licensed under the METTLER TOLEDO End User License Agreement (EULA) for Software.

When using this product you agree to the terms of the EULA.

▶ www.mt.com/EULA

1.1 Further documents and information

This document is available in other languages online.

▶ www.mt.com/XSR-precision-RM

Product page:

▶ www.mt.com/XSR-precision

Instructions for cleaning a balance, "8 Steps to a Clean Balance":

▶ www.mt.com/lab-cleaning-guide

Search for software:

▶ www.mt.com/labweighing-software-download

Search for documents:

▶ www.mt.com/library

For further questions, please contact your authorized METTLER TOLEDO dealer or service representative.

▶ www.mt.com/contact

1.2 Explanation of conventions and symbols used

Conventions and symbols

Key and/or button designations and display texts are shown in graphic or bold text, e.g., , **Edit**.

 **Note** For useful information about the product.



Refers to an external document.

Elements of instructions

In this manual, step-by-step instructions are presented as follows. The action steps are numbered and can contain prerequisites, intermediate results and results, as shown in the example. Sequences with less than two steps are not numbered.

■ Prerequisites that must be fulfilled before the individual steps can be executed.

1 Step 1

➔ Intermediate result

2 Step 2

➔ Result

1.3 Acronyms and abbreviations



Original term	Explanation
AC	Alternating Current
ASTM	American Society for Testing and Materials



DC	Direct Current
EMC	Electromagnetic Compatibility
FCC	Federal Communications Commission
GWP	Good Weighing Practice
HID	Human Interaction Device
ID	Identification
LED	Light-Emitting Diode
LPS	Limited Power Source
MAC	Media Access Control
MT-SICS	METTLER TOLEDO Standard Interface Command Set
NA	Not Applicable
OIML	Organisation Internationale de Métrologie Légale (International Organization of Legal Metrology)
RAM	Random Access Memory
RFID	Radio-frequency identification
RM	Reference Manual
SELV	Safety Extra Low Voltage
SOP	Standard Operating Procedure
SQC	Statistical Quality Control
UM	User Manual
USB	Universal Serial Bus
USP	United States Pharmacopeia

1.4 Product range



1.4.1 XSR precision balances

1.4.1.1 S weighing platform

Balance	Models designation
	Readability: 1 mg <ul style="list-style-type: none"> • XSR303S • XSR603S • XSR1203S
	Readability: 1 mg <ul style="list-style-type: none"> • XSR303SN • XSR603SN

Balance	Models designation
	Readability: 10 mg <ul style="list-style-type: none"> • XSR2002S • XSR4002S • XSR6002S • XSR6002SDR • XSR1202S • XSR10002S
	Readability: 100 mg <ul style="list-style-type: none"> • XSR4001S • XSR6001S • XSR8001S • XSR10001S

1.4.1.2 L weighing platform

Balance	Models designation
	Readability: 100 mg <ul style="list-style-type: none"> • XSR10001L • XSR16001L • XSR32001L • XSR32001LDR
	Readability: 1 g <ul style="list-style-type: none"> • XSR16000L • XSR32000L

1.5 Compliance information

National approval documents, e.g., the FCC Supplier Declaration of Conformity, are available online and/or included in the packaging.

► www.mt.com/ComplianceSearch

Contact METTLER TOLEDO for questions about the country-specific compliance of your instrument.

► www.mt.com/contact

United States of America

This equipment has been tested and found to comply with the limits for a **Class A** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2 Safety Information

Two documents named "User Manual" and "Reference Manual" are available for this instrument.

- The User Manual is printed and delivered with the instrument.
- The electronic Reference Manual contains a full description of the instrument and its use.
- Keep both documents for future reference.
- Include both documents if you transfer the instrument to other parties.

Only use the instrument according to the User Manual and the Reference Manual. If you do not use the instrument according to these documents or if the instrument is modified, the safety of the instrument may be impaired and Mettler-Toledo GmbH assumes no liability.

2.1 Definitions of signal words and warning symbols

Safety notes contain important information on safety issues. Ignoring the safety notes may lead to personal injury, damage to the instrument, malfunctions and false results. Safety notes are marked with the following signal words and warning symbols:

Signal words

DANGER	A hazardous situation with high risk, resulting in death or severe injury if not avoided.
WARNING	A hazardous situation with medium risk, possibly resulting in death or severe injury if not avoided.
CAUTION	A hazardous situation with low risk, resulting in minor or moderate injury if not avoided.
NOTICE	A hazardous situation with low risk, resulting in damage to the instrument, other material damage, malfunctions and erroneous results, or loss of data.

Warning symbols



General hazard



Notice

2.2 Product-specific safety information

Intended use

This instrument is designed to be used by trained staff. The instrument is intended for weighing purposes.

Any other type of use and operation beyond the limits of use stated by Mettler-Toledo GmbH without consent from Mettler-Toledo GmbH is considered as not intended.

Responsibilities of the instrument owner

The instrument owner is the person holding the legal title to the instrument and who uses the instrument or authorizes any person to use it, or the person who is deemed by law to be the operator of the instrument. The instrument owner is responsible for the safety of all users of the instrument and third parties.

Mettler-Toledo GmbH assumes that the instrument owner trains users to safely use the instrument in their workplace and deal with potential hazards. Mettler-Toledo GmbH assumes that the instrument owner provides the necessary protective gear.

Safety notes



WARNING

Death or serious injury due to electric shock

Contact with parts that carry a live current can lead to death or injury.

- 1 Only use the METTLER TOLEDO power cable and AC/DC adapter designed for your instrument.
- 2 Connect the power cable to a grounded power outlet.
- 3 Keep all electrical cables and connections away from liquids and moisture.
- 4 Check the cables and the power plug for damage and replace them if damaged.



NOTICE

Damage to the instrument or malfunction due to the use of unsuitable parts

- Only use parts from METTLER TOLEDO that are intended to be used with your instrument.

3 Design and Function

3.1 Function description


The XSR line comprises a range of balances that differ from each other due to their weighing range and resolution. The balances of the XSR line combine a large number of weighing and adjustment possibilities with a simple operation handling.

The following features are common to all models of the XSR precision line:

- 4.3-inch capacitive color TFT-touch screen.
- fully automatic adjustment using internal weights
- various methods that can be defined individually
- various routine tests that can be defined individually
- History about performed tests and adjustments.
- built-in level sensor and leveling aid for fast and easy leveling

3.2 Overview S weighing platform


3.2.1 Balances with readability 1 mg




1	MagicCube draft shield	6	MagicCube draft shield side door
2	DripTray	7	MagicCube draft shield side door handler
3	SmartPan weighing pan	8	Weighing platform with protective cover
4	Weighing pan	9	Leveling foot
5	MagicCube draft shield top door	10	Terminal with protective cover

3.2.2 Balances with readability 10 mg and 100 mg

10 mg




100 mg



1	Weighing pan support cap	6	Safety foot
2	DripTray	7	Weighing platform with protective cover
3	SmartPan weighing pan	8	Fastening plate with positioning screws
4	Weighing pan support	9	Leveling foot
5	Weighing pan with protective cover	10	Terminal with protective cover


3.2.3 Interface board



1	Ethernet port	5	USB-B port (to host)
2	USB-A ports (to device)	6	Socket for terminal cable
3	Fixations for optional terminal stand	7	Socket for AC/DC adapter
4	Service seal		


3.3 Overview L weighing platform

3.3.1 Balances with readability of 100 mg and 1 g




1	Weighing pan support cap	3	Leveling foot
2	Weighing pan	4	Terminal with protective cover

3.3.2 Interface board



1	Socket for AC/DC adapter	4	USB-B port (to host)
2	Socket for terminal cable	5	USB-A ports (to device)
3	Service seal	6	Ethernet port

3.4 Overview terminal




	Name	Description
	Methods	Opens the section Methods .
	Results	Opens the Results list .
	Balance menu	Opens the section Balance menu .
	Home	To return from any menu level to the main weighing screen.
	Zero	Zeroes the balance. The balance must always be zeroed before starting the weighing process. After zeroing, the balance sets a new zero point.
	Tare	Tares the balance. This function is used when the weighing process involves containers. After taring the balance, the screen shows <i>Net</i> which indicates that all displayed weights are net.
	Standby	By tapping , the balance is not completely switched off but goes into standby mode. To switch the balance completely off, it must be unplugged from the power supply. Note Do not disconnect the balance from the power supply unless the balance is not used for an extended period of time. After switching on the instrument, it must warm up before giving accurate results.

3.5 Overview type label


The information on the type label helps to identify the balance and terminal.

Type label of the terminal



1. Terminal type
2. Terminal serial number

Type label of the balance




1. Balance model
2. Year of manufacture
3. Readability
4. Maximum capacity
5. Manufacturer
6. Balance type
7. Balance serial number
8. Power consumption

3.6 User interface

3.6.1 Main sections at a glance

The main weighing screen (1) is the central navigation point where all the menus and settings can be found. The **Balance menu** (2), **Methods** (3) and **Results** (4) open when pressing the symbols on the terminal.



See also


- [Main weighing screen](#) ▶ Page 17
- [Panel "Balance menu"](#) ▶ Page 18
- [Panel "Methods"](#) ▶ Page 18
- [Panel "Results"](#) ▶ Page 19

3.6.2 Main weighing screen




	Name	Description
1	Weighing value field	Shows the current weighing value.
2	Level indicator	Indicates if the balance is leveled (green) or not (red).
3	Warning and error message area	Shows current warning and/or error messages.
4	Button Add result	Adds the result to the Results list . Depending on the selected method, the button can have different functions.
5	Action bar	Contains actions referring to the current task.
6	Method information area	Contains information about the sample, method or task IDs.
7	SmartTrac	Used as a weighing aid to define a target weight with upper and lower tolerances.
8	Weighing value area	Shows the results of the current weighing process.
9	Method name	Shows the name of the current method.

3.6.3 Panel "Balance menu"



	Name	Description
1	Leveling aid	Opens the leveling dialog.
2	Settings	Opens the complete settings dialog.
3	Balance info	Shows the balance information.
4	History	Opens the history dialog.
5	Maintenance	Opens the balance maintenance dialog.
6	Close	Closes the balance dialog.
7	Blocking	Opens the block balance dialog.

3.6.4 Panel "Methods"




	Name	Description
1	Methods list	Lists the methods already defined by the user. Methods can be created, edited, cloned, started, or deleted.
2	Tests	Lists the tests already defined by the user. <ul style="list-style-type: none"> • Sensitivity tests • Repeatability tests • Eccentricity tests Routine tests can be created, edited, started, or deleted. A list of the tests previously performed is available in the History .
3	Adjustments	Shows the currently selected internal or external adjustment. The adjustment can be edited or started. A list of the adjustments previously performed is available in the History .

See also

[History](#) ▶ Page 69

3.6.5 Panel "Results"








	Name	Description
1	Result state	Shows the state of the weighing process.
2	Sample ID	Shows the Sample ID of the weighing.
3	Gross weight	Shows the gross weight. D : indicates that the value was unstable. This might occur when the Weighing mode is set to Immediate . * : indicates that the value was calculated. This might occur, for example, when the Weighing mode is set to Dynamic or the Tare Mode is set to Preset tare .
4	Timestamp	Shows the individual timestamp of each weighing item.
5	Balance status	Shows stability, level state of the balance, minimum weight, tolerance state and test and adjustment state.
6	Complete	Opens the dialog Complete task . <ul style="list-style-type: none"> • Print task label manually • Print results manually • Export results manually

	Name	Description
7	More	Opens the dialog More . <ul style="list-style-type: none"> • Start adjustment • Change display unit • Configure tare • Configure zero • Save as method (itemized) (only available for methods with the option Weighing items)
8	Exclude result	Excludes the current result from the Results list . A comment can be added to the excluded result, e.g., to describe the reason of the exclusion. Depending on the format of the results printout, the excluded result can be printed or not.
9	Close	Closes the Results list and goes back to the main weighing screen.

3.6.6 Icons and symbols



3.6.6.1 System status icons






System messages can appear due to a user action, a user input or a system process. Some messages leave it up to the user to choose upon acting, they will disappear after acknowledging. Other messages remain persistent, so the user can defer them but eventually has to handle them. These messages can be seen in the main status bar on the upper right-hand side of the display.

Icon	Name	Description
	Leveled	More details about the leveling status are displayed when tapping the level status.
	Out of level	The balance must be leveled. Information about leveling the balance can be found in the section Leveling the balance.
	Information	Information messages appear due to user actions or system processes and offer opportunities that are related to the current action or process.
	Warning	Warning messages appear due to user actions or system processes that could lead to a problem that can be prevented.
	Error	Error messages appear due to user actions or system processes that have failed. It is mostly still possible to handle such a problem.

3.6.6.2 Weighing status icons





Weighing status icons appear due to the weight value matching certain quality criteria. The information on the status can be looked by tapping on any of the visible weighing status icons.

Icon	Name	Description
	Stability indicator	When the stability indicator appears, the balance is not stable. Make sure that the balance is placed at an adequate location. Information about the adequate location can be found in the section Selecting the location.
Net	Net indicator	Appears when the tare key has been pressed and the tare weight has been subtracted.
	Calculated value	The current weight value is calculated. This symbol only appears in the weighing value area when a container has been used with the function Preset tare .

	Minimum weight violation	The current weight value is smaller than the defined minimum weight. Make sure that the weight is larger than the minimum weight.
	Balance invalid	The current balance configuration is invalid or quality criteria have not been fulfilled according to the GWP approved definition.
	Weight not ready	The current weight measurement is not ready according to the GWP approved definition. This can be caused by an overload, an underload, or a minimum weight violation.
	Weight ready	The current weight measurement is ready according to the GWP approved definition. It can be added to the Results list .
	External ionizer discharging	The external ionizer is currently discharging.

3.6.6.3 Process status icons

The status of the processes running on the balance is indicated by a small icon on the bottom right corner of the icon of the associated process. This applies to **Tests** and **Adjustments**.

Icon	Name	Description
	Running	The process is currently running.
	Scheduled	The process is scheduled.
	Information	Information is available about the process, e.g., a reminder.
	Overdue	The process is overdue.

4 Installation and Putting into Operaton

4.1 Selecting the location


A balance is a sensitive precision instrument. The location where it is placed will have a profound effect on the accuracy of the weighing results.

Requirements of the location


Place indoors on stable table




Avoid direct sunlight




Ensure sufficient spacing



Avoid vibrations




Level the instrument



Avoid strong drafts



Provide adequate lighting



Avoid temperature fluctuations



Sufficient spacing for balances: > 15 cm all around the instrument

Take into account the environmental conditions. See "Technical Data".

4.2 Unpacking the balance

Open the balance packaging and check for transportation damage or missing parts. Please inform a METTLER TOLEDO service representative in the event of missing or defective parts.

METTLER TOLEDO recommends retaining the original box with its packaging elements. Use the packaging elements to store and to transport the balance.

4.3 Scope of delivery

4.3.1 S weighing platform

Components	1 mg with MagicCube draft shield	1 mg without MagicCube draft shield	10 mg	100 mg
Weighing platform with protective cover	✓	✓	✓	✓
Terminal with protective cover	✓	✓	✓	✓
Terminal holder	✓	✓	✓	✓
Terminal connection cable (pre-assembled)	✓	✓	✓	✓
MagicCube draft shield with additional draft shield door and DripTray	✓	–	–	–
Weighing pan 127 × 127 mm	✓	–	–	–
Weighing pan 172 × 205 mm	–	–	✓	–
Weighing pan 190 × 223 mm	–	–	–	✓
SmartPan weighing pan	✓	✓	✓	–
Weighing pan support	–	–	–	✓
DripTray	✓	✓	✓	–
Weighing hook for below-the-balance weighing	✓	✓	✓	✓
AC/DC adapter	✓	✓	✓	✓
Power cable (country-specific)	✓	✓	✓	✓
User Manual	✓	✓	✓	✓
Production certificate	✓	✓	✓	✓
CE declaration of conformity	✓	✓	✓	✓

4.3.2 L weighing platform

Components	100 mg	1 g
Weighing platform	✓	✓
Terminal with protective cover	✓	✓
Terminal holder (pre-assembled)	✓	✓
Terminal connection cable	✓	✓
Weighing pan	✓	✓
AC/DC adapter	✓	✓
Power cable (country-specific)	✓	✓
User Manual	✓	✓
Production certificate	✓	✓
CE declaration of conformity	✓	✓

4.4 Installation

4.4.1 Balances with S weighing platform

4.4.1.1 Attaching the terminal to the weighing platform

The terminal is usually placed in front of the weighing platform on the terminal holder. Alternatively, the terminal can be placed next to the weighing platform, or attached to an additional terminal stand.




NOTICE

Damage to the balance


The weighing platform and the terminal are not safely fixed by the terminal holder and may fall off when carrying.

- Remove the terminal from the weighing platform and place it on the weighing pan when carrying the balance.


- 1 Place the weighing platform on a flat surface.
- 2 Position the terminal holder (1) in front of the weighing platform. The plug of the pre-mounted terminal connection cable (2) must lie between the terminal holder (1) and the weighing platform.



- 3 Push the terminal holder (3) towards the weighing platform. The far end of the terminal holder (3) must be pushed into the lock element (4) at the bottom of the weighing platform.
- 4 Use the terminal connection cable to connect the terminal with the weighing platform.



- 5 Place the terminal on top of the terminal holder.
 - 6 Push the terminal towards the weighing platform until the terminal locks into the terminal holder.
- ➔ The terminal is mounted and connected to the weighing platform.



4.4.1.2 Assembling balances 1 mg with MagicCube draft shield and SmartPan weighing pan




NOTICE

Damage to weighing platform and the MagicCube draft shield when carrying


The U-shaped MagicCube draft shield glass is not fixed to the MagicCube draft shield housing.

- 1 Always close the cover before carrying the MagicCube draft shield.
- 2 Always hold the MagicCube draft shield on the housing underneath the glass. Always hold the MagicCube draft shield with both hands and on both sides and keep it in a horizontal position.

- 1 Place the MagicCube draft shield on top of the weighing platform.




- 2 Open the MagicCube draft shield top door.
- 3 Place the DripTray (1) into the MagicCube draft shield.
- 4 Place the SmartPan weighing pan (2) into the MagicCube draft shield on top of the DripTray (1).
- 5 The weighing pan (3) is optional and can be placed into the MagicCube draft shield on top of the SmartPan weighing pan (2).




Options for installing the MagicCube draft shield

- 1 Open the MagicCube draft shield top door.
- 2 Take the additional MagicCube draft shield door (1) out of the rear panel.
- 3 Insert the additional MagicCube draft shield door into the housing from the left or the right side.

- 4 Insert the additional MagicCube draft shield door into the fixation holes at the bottom of the housing and then at the top of the housing.




The MagicCube draft shield for XSR models consists of a fixed draft shield housing with top door (1), side door (2) and a flexible U-shaped draft shield glass (3). The U-shaped draft shield glass (3) can be placed individually on top of the draft shield housing. The side door can be found in the draft shield housing.




4.4.1.3 Assembling balances 1 mg with SmartPan weighing pan

- 1 Place the DripTray (1) on top of the weighing platform.
- 2 Place the SmartPan weighing pan (2) on top of the DripTray (1).
- 3 The weighing pan can be placed on top of the SmartPan weighing pan if needed.




4.4.1.4 Assembling balances 10 mg with SmartPan weighing pan

- 1 Place the weighing pan support caps (1) on top of the weighing platform.
- 2 Place the DripTray (2) on top of the weighing platform.
- 3 Place the SmartPan weighing pan (3) on top of the 4 weighing pan support caps (1).
- 4 Place the weighing pan with the protective cover (4) on top of the SmartPan weighing pan (3).



4.4.1.5 Assembling balances 100 mg

- 1 Place the 4 pan support caps (1) on top of the weighing platform.
- 2 Place the weighing pan support (2) on top of the 4 weighing pan support caps (1).
- 3 Place the weighing pan with the protective cover (3) on top of the weighing pan support (2).




4.4.2 Balances with L weighing platform


4.4.2.1 Attaching the terminal to the weighing platform

The terminal can be attached to the long side or to the short side of the L weighing platform.

- 1 Turn the weighing platform upside down.
- 2 Dismantle the screws (1) on the long side or the screws (2) on the short side of the weighing platform.
- 3 Connect the terminal to the weighing platform with the terminal connection cable.
- 4 Attach the terminal holder to the long side or to the short side of the weighing platform. Fix the terminal holder with the screws from the weighing platform.



- 5 Insert the terminal connection cable (3) into the cable channel.




Note

When inserting the terminal connection cable into the cable channel, the terminal connection cable must be inserted simultaneously from both directions. The terminal connection cable must not have any play between the plug and the cable channel (see picture).

- 6 Turn the weighing platform.

4.4.2.2 Assembling balances 100 mg and 1 g

- 1 Place the weighing pan support caps (1) on top of the weighing platform.
- 2 Place the weighing pan (2) on top of the weighing pan support caps (1).



4.5 Putting into operation

4.5.1 Connecting the balance




WARNING

Death or serious injury due to electric shock

Contact with parts that carry a live current can lead to death or injury.

- 1 Only use the METTLER TOLEDO power cable and AC/DC adapter designed for your instrument.
- 2 Connect the power cable to a grounded power outlet.
- 3 Keep all electrical cables and connections away from liquids and moisture.
- 4 Check the cables and the power plug for damage and replace them if damaged.

- 1 Install the cables in such a way that they cannot be damaged or interfere with operation.
 - 2 Insert the plug of the AC/DC adapter (2) into the power inlet of the instrument (1).
 - 3 Secure the plug by firmly tightening the knurled nut.
 - 4 Insert the plug of the power cable into a grounded power outlet that is easily accessible.
- ➔ The balance automatically switches on.



Note

Do not connect the instrument to a power outlet controlled by a switch. After switching on the instrument, it must warm up before giving accurate results.

See also

[General data](#) ▶ Page 142

4.5.2 Switching on the balance

When connected to the power supply, the balance automatically switches on.

EULA (End User License Agreement)

When the balance is switched on the first time, the EULA (End User License Agreement) appears on the screen.

- 1 Read the conditions.
- 2 Tap **I accept the terms in the license agreement.** and confirm with **✓ OK.**
 - ➔ The main weighing screen appears.

Acclimatization and warm up

Before the balance gives reliable results, it must:

- acclimatize to the room temperature
- warm up by being connected to the power supply

The acclimatization time and warm-up time for balances are available in "General data".

Note

When the balance is exiting standby, it is ready immediately.

See also

[General data](#) ▶ Page 142

[Entering / Exiting standby mode](#) ▶ Page 30

4.5.3 Leveling the balance

Exact horizontal and stable positioning are essential for repeatable and accurate weighing results.

If the message **Balance is out of level** appears:

- 1 Tap **► Level the balance.**
 - ➔ The **Leveling aid** opens.
- 2 Follow the instructions from the wizard.

The leveling aid can also be accessed through the **Balance menu**:

≡ **Navigation:** ⚙️ **Balance menu** > 🕒 **Leveling aid**

4.5.4 Performing an internal adjustment

≡ **Navigation:** ⌘ **Methods** > ⚙️ **Adjustments**

- The adjustment **Strategy** is set to **Internal adjustment**.
- 1 Open the **Methods** section, tap ⚙️ **Adjustments**, select the adjustment, and tap ▶ **Start**
- or -
from the main weighing screen, tap ⋮ **More** and tap **Start adjustment**.
 - ➔ **Internal adjustment** is being executed.
 - ➔ When the adjustment has been completed, an overview of the adjustment results appears.
- 2 Tap 🖨️ **Print** if you want to print the results.
- 3 Tap ✓ **Finish adjustment**.
 - ➔ The balance is ready.

4.5.5 Entering / Exiting standby mode

- 1 To enter standby mode, hold 🔌.
 - ➔ The display is dark. The balance is still switched on.
- 2 To exit standby mode, press 🔌.
 - ➔ The display is turned on.

4.5.6 Switching off the balance

To completely switch off the balance, it must be disconnected from the power supply. By holding 🔌, the balance goes only into standby mode.

i **Note**

When the balance was completely switched off for some time, it must warm up before it can be used.

See also

🔗 Switching on the balance ▶ Page 29

4.6 Performing a simple weighing

4.6.1 Zeroing the balance

- 1 Open the draft shield, if applicable.
- 2 Clear the weighing pan.
- 3 Close the draft shield, if applicable.
- 4 Press →**0**← to zero the balance.
 - ➔ The balance is zeroed.

4.6.2 Taring the balance

If a sample vessel is used, the balance must be tared.

- 1 Open the draft shield, if applicable.
- 2 Clear the weighing pan.
- 3 Close the draft shield, if applicable.
- 4 Press →**0**← to zero the balance.
- 5 Open the draft shield, if applicable.
- 6 Place the sample vessel on the weighing pan.
- 7 Close the draft shield, if applicable.

- 8 Press →T← to tare the balance.
- The balance is tared. The icon **Net** appears.

4.6.3 Performing a weighing

- 1 Open the draft shield, if applicable.
- 2 Place the weighing object into the sample vessel.
- 3 Tap **+ Add result** if you want to report the weighing result.
- The result is added to the **Results list**.

4.6.4 Completing the weighing

- 1 To save the **Results list**, tap **Complete**.
 - The window **Complete task** opens.
- 2 Select an option to save or print the **Results list**.
 - The respective dialog opens.
- 3 Follow the instructions from the wizard.
- 4 Tap **✓ Complete**.
 - The **Results list** is saved/printed and then cleared.

4.7 Transporting, packing and storing



NOTICE


Damage to the draft shield, terminal or additional terminal stand

Do not hold the balance only by the glass draft shield, by the terminal or by the terminal stand when carrying the balance.

- Remove the terminal of the S weighing platform from the terminal holder and place the terminal on top of the weighing pan. Always hold the weighing platform with both hands when carrying the balance.

4.7.1 Transporting the balance over short distances

- 1 Disconnect the balance from the AC/DC adapter.
- 2 Unplug all interface cables if necessary.
- 3 Remove the terminal from the terminal holder and place the terminal on top of the weighing platform (only for S weighing platform).
- 4 Hold the weighing platform with both hands and carry the balance in horizontal position to the target location. Consider the requirements of the location.



See also

- [Selecting the location ▶ Page 22](#)
- [Switching on the balance ▶ Page 29](#)
- [Leveling the balance ▶ Page 29](#)
- [Performing an internal adjustment ▶ Page 30](#)

4.7.2 Transporting the balance over long distances

METTLER TOLEDO recommends using the original packaging for transportation or shipment of the balance or balance components over long distances. The elements of the original packaging are developed specifically for the balance and its components and ensure maximum protection during transportation.

4.7.3 Packing and storing

Packing the balance

Store all parts of packaging in a safe place. The elements of the original packaging are developed specifically for the balance and its components, and ensures maximum protection during transportation and storage.

Storing the balance

Only store the balance under the following conditions:

- Indoor and in the original packaging
- According to the environmental conditions, see "Technical Data"

i Note

When storing for longer than 6 months, the rechargeable battery may become empty (only date and time get lost).

See also

- [Technical Data ▶ Page 142](#)

4.8 Weighing below the balance


All models with S weighing platform are equipped with a weighing hook for below-the-balance weighing. Models with L weighing platform are not equipped with a weighing hook. The weighing hook for L weighing platforms can be ordered as an accessory.

See also

- [Dimensions ▶ Page 153](#)


4.8.1 S weighing platform

- A weighing table or workbench is available, through which the weighing hook can be accessed.
 - 1 Disconnect the balance from the AC/DC adapter.
 - 2 Remove all elements from the weighing platform, e.g., draft shield, terminal and weighing pan.
 - 3 Turn the weighing platform to its side.
 - 4 Remove the screws (1) and remove the weighing hook cover (2).
 - 5 Turn the weighing platform back on its feet and reinstall all components.
- ➔ The weighing hook is accessible and can be used for below-the-balance weighing.



4.8.2 L weighing platform

- A weighing table or workbench is available, through which the weighing hook can be accessed.
 - 1 Disconnect the balance from the AC/DC adapter.
 - 2 Remove all elements from the weighing platform, e.g., draft shield, terminal and weighing pan.
 - 3 Turn the weighing platform upside down.
 - 4 Remove the screws (1) and remove the weighing hook cover (2).
 - 5 Install the weighing hook.
 - 6 Turn the weighing platform back on its feet and reinstall all components.
- ➔ The weighing hook is accessible and can be used for below-the-balance weighing.




5 Operation

5.1 Touch screen


5.1.1 Selecting or activating an item

- Tap the item or function to be selected or activated.



5.1.2 Scrolling

- Move the list up/down.




5.1.3 Entering characters and numbers

When tapping on fields that require letters, numbers, or special characters, a keyboard appears on the display.



	Name	Description
1	Input field	Shows the data that has been entered.
2	Backspace	Deletes the character left of the current cursor position. The cursor can be positioned by using the touch screen.
3	Confirm	Confirms the entered data.
4	Discard	Closes the keyboard dialog.
5	Numbers and special characters	Switches into the special character mode.
6	Shift	Switches between lower or upper case letters.

5.1.4 Changing the date and time



	Name	Explanation
1	Plus button	Increment
2	Display field	Shows the defined time or date.
3	Minus button	Decrement

Note

The format of date and time can be defined in the settings via the options **Date format** and **Time format**.

See also

[Date / Time / Language / Format](#) ▶ Page 75

5.2 Methods

A weighing method is an application for carrying out specific weighing tasks. The balance offers the method "General Weighing" with default parameters. You have the possibility to create a maximum of 50 methods and edit the methods. You can use these methods for your weighing task or edit them according to your requirements. Methods can also be deleted or cloned.

To support you while configuring new methods, a configuration wizard leads you through the whole process.

5.2.1 Methods overview

The section **Methods list** provides an overview of all methods already created on the balance. In this section, new methods can be defined and existing methods can be edited, cloned or deleted. It is also the starting point for using any method in a weighing procedure.

Navigation: ▼ **Methods** > **Methods list**

The following methods are available:

- **General weighing** (see [Method "General weighing" ▶ Page 35])
- **Simple formulation** (see [Method "Simple formulation" ▶ Page 37])
- **Titration** (see [Method "Titration" ▶ Page 39])
- **Density determination** (see [Method "Density determination" ▶ Page 40])
- **Piece Counting** (see [Method "Piece Counting" ▶ Page 41])


5.2.2 Method "General weighing"

The method **General weighing** offers the basic weighing functions (zeroing, taring, weighing). The method is used for simple weighing tasks or to perform a series of check weighing or dosing.

The settings of the weighing item, e.g., target weight and tolerances, can be specified for one or multiple weighing items. Two different methods exist:

- **General weighing:**
 - Select this method if you want to work with a single set of parameters.
- **General weighing (itemized):**

- Select this method if you want to define the parameters for multiple weighing items. A method with multiple weighing items is particularly useful when the weighing task consists of a series of weighings, each with its own individual parameters, such as target weight, tolerances, etc. For further information, see [Using methods with multiple weighing items (itemized) ▶ Page 44].



You have the possibility to start with method factory setting parameter or to create a new method with changed method parameter.

For details about method settings:

See also

- 🔗 Settings: method "General weighing" ▶ Page 81
- 🔗 Using methods with multiple weighing items (itemized) ▶ Page 44

5.2.2.1 Creating a method "General weighing"

≡ **Navigation:** ☰ **Methods** > ☰ **Methods list**

- 1 Tap **+** **New** in the action bar.
 - ➔ The method wizard opens, starting at **1. Method type**.
- 2 Tap **Method type** and select the method type **General weighing** or **General weighing (itemized)**.
- 3 Tap **→ Next**.
 - ➔ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap **→ Next**.
 - ➔ The method wizard opens the section **3. Configuration**.
- 5 Select a **Tolerance profile** and tap **→ Next**.
 - ➔ The method wizard opens the section **4. Save**.
 - ➔ If setting up a method with multiple weighing items, the wizard opens the section **4. Weighing items**.
- 6 Select a weighing item from the list and define the **Sample ID**, **Unit**, **Target weight**, **-Tolerance**, and **+Tolerance**.
- 7 To add a weighing item, tap **+ Item** or **▣ Clone**.
- 8 Tap **→ Next**.
 - ➔ The method wizard opens the section **5. Save**.
- 9 Tap **✓ Finish** to save the new method.
 - ➔ The method has been created and appears in the list.

5.2.2.2 Performing a "General weighing"

This section describes a **General weighing** example step by step. Depending on the defined settings and weighing objects, the procedure can be different from this example.

- 1 Open the **Methods** section.

- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap ► **Start method**.
 - ➔ The main weighing screen appears with the selected method.
- 4 Press →0← to zero the balance.
- 5 Open the draft shield (if applicable) and place the weighing object in the center of the weighing pan.
- 6 Close the draft shield (if applicable) and wait until the weight stabilizes.
 - ➔ The weighing starts with **Capturing weight...**
- 7 Tap + **Add result**.
 - ➔ The weighing result is saved to the **Results list**.
- 8 When the weighing process is finished, tap **Complete** in the action bar.
 - ➔ The window **Complete task** opens. The task-specific information can be printed on a label printer. The **Results list** can be printed manually or automatically (depending on the method settings).
 - ➔ The task **General weighing** was successfully completed.

Note

It is possible to exclude a weighing result from the **Results list**. Open the **Results list**, select a result to exclude, and tap **Exclude result**.


The window **Complete task** always appears after completing the task, even if the results are saved automatically.

5.2.3 Method "Simple formulation"

With the method **Simple formulation** the concentration of a substance can automatically be calculated.

The settings of the weighing item, e.g., target weight and tolerances, can be specified for one or multiple weighing items. Two different methods exist:

- **Simple formulation:**
 - Select this method if you want to weigh a single component in a volumetric flask and have the concentration calculated automatically.
- **Simple formulation (itemized):**
 - Select this method if you want to follow a predefined solution recipe of one or several components. A method with multiple weighing items is particularly useful when the weighing task consists of a series of weighings, each with its own individual parameters, such as target weight, tolerances, etc. For further information, see [Using methods with multiple weighing items (itemized) ► Page 44].



For details about method settings:

See also

- Settings: method "Simple formulation" ► Page 90
- Using methods with multiple weighing items (itemized) ► Page 44

5.2.3.1 Creating a method "Simple formulation"

☰ **Navigation:** ☰ **Methods** > ☰ **Methods list**

- 1 Tap **+** **New** in the action bar.
 - ➔ The method wizard opens, starting at **1. Method type**.
- 2 Tap **Method type** and select the method type **Simple formulation** or **Simple formulation (itemized)**.
- 3 Tap **→ Next**.
 - ➔ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap **→ Next**.
 - ➔ The method wizard opens the section **3. Configuration**.
- 5 Select the options for **Calculate concentration per component**, **Calculate amount of component** and set a **Tolerance profile**.
- 6 Tap **→ Next**.
 - ➔ The method wizard opens the section **4. Save**.
 - ➔ When selected **Simple formulation (itemized)**, the wizard opens the optional creating section **4. Weighing items**.
- 7 Select a weighing item from the list and define the **Sample ID**, **Unit**, **Target weight**, **-Tolerance**, and **+Tolerance**.
 - ➔ The method wizard opens the section **5. Save**.
- 8 Tap **✓ Finish** to save the new method.
 - ➔ The method has been created and appears in the list.


5.2.3.2 Method "Simple formulation"

This example describes how to perform a **Simple formulation** with two components. It explains the basic functions of the method. Advanced functions such as the calculation of the concentration of a component can be defined in the method settings.

- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap **▶ Start method**.
 - ➔ The main weighing screen appears with the selected method.
- 4 Define the target weight and the tolerance limits for the first component.
- 5 Select **Component ID** to define the first component.
- 6 Select **Task ID** to define the whole task.
- 7 Press **→0←** to zero the balance.
- 8 Open the draft shield (if applicable) and place the weighing object in the center of the weighing pan.
- 9 Press **→T←** to tare the balance.
- 10 Open the draft shield (if applicable) and place the first component in the sample vessel.
 - ➔ The measurement starts.
- 11 Tap **+** **Add result**.
 - ➔ The weighing result is saved to the **Results list**.
- 12 Define the target weight and the tolerance limits for the second component.
- 13 Select **Component ID** to define the second component.
- 14 Open the draft shield (if applicable) and place the second component in the sample vessel.
- 15 Tap **+** **Add result**.
 - ➔ The weighing result is saved to the **Results list**.
- 16 Tap **☰ Complete** and select if you want to print or export the **Results list**.
 - ➔ The weight task is completed and the balance returns to the main weighing screen.

5.2.4 Method "Titration"

The method **Titration** enables the interaction between the balance and the titrator via MT-SICS.



For details about method settings:

See also

[Settings: method "Titration" ▶ Page 99](#)

5.2.4.1 Creating a method "Titration"

≡ **Navigation:** ≡ **Methods** > ≡ **Methods list**

- 1 Tap **+** **New** in the action bar.
 - ➔ The method wizard opens, starting at **1. Method type**.
- 2 Tap **Method type** and select the method type **Titration**.
- 3 Tap **→ Next**.
 - ➔ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap **→ Next**.
 - ➔ The method wizard opens the section **3. Configuration**.
- 5 Select a **RFID option**, a **Tolerance profile** and tap **→ Next**.
 - ➔ The method wizard opens the section **4. Save**.
- 6 Tap **✓ Finish** to save the new method.
 - ➔ The method has been created and appears in the list.

5.2.4.2 Performing a "Titration"

This example describes how to prepare a sample for titration and to transfer the information to the METTLER TOLEDO titrator via a USB connection. For more information about how to perform the titration, consult the manual of the titrator.

- A METTLER TOLEDO titrator is connected to the balance via USB.
 - A titration method exists in the **Methods list**.
- 1 Open the **Methods** section.
 - 2 Select the desired titration method from the **Methods list**.
 - 3 Tap **▶ Start method**.
 - ➔ The main weighing screen appears with the selected method.
 - 4 Press **→0←** to zero the balance.
 - 5 Place the sample vessel on the weighing pan.
 - 6 Wait until the weight stabilizes.
 - 7 Press **→T←** to tare the balance.

- 8 Place the sample in the sample vessel.
- 9 Wait until the weight stabilizes.
- 10 Tap **✓ OK** to accept the measurement.
 - ➔ The weighing result is saved to the **Results list** and automatically sent to the titrator.
- 11 Continue your workflow on the titrator.


5.2.5 Method "Density determination"

The method **Density determination** is used for determining the density of solids and liquids. Density determination is carried out based on **Archimedes' principle** according to which a body immersed in a fluid undergoes an apparent loss in weight that is equal to the weight of the fluid it displaces. On the other hand, the **Density determination** method also supports the pycnometer method, which does not rely on **Archimedes' principle**. The method **Density determination** includes three method types:

Solid: Determines the density of a solid with the help of a density kit.

Liquid (sinkers): Determines the density of a liquid with the help of a density kit and a sinker.

Liquid (pycnometer): Determines the density of a liquid in a glass vessel, for example, using a pycnometer.



For details about method settings:

See also

[Settings: method "Density determination" ▶ Page 107](#)

5.2.5.1 Creating a method "Density determination"

≡ **Navigation:** **☰ Methods > ☰ Methods list**

- 1 Tap **+ New** in the action bar.
 - ➔ The method wizard opens, starting at **1. Method type**.
- 2 Tap **Method type** and select the method type **Density determination**.
- 3 Tap **→ Next**.
 - ➔ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap **→ Next**.
 - ➔ The method wizard opens the section **3. Configuration**.
- 5 Select the **Determination type** and define the corresponding settings, e.g., **Density unit** and **Weighing settings**.
- 6 Tap **→ Next**.
 - ➔ The method wizard opens the section **4. Weighing item**.
- 7 Define **Initial values for weighing** and tap **→ Next**.
 - ➔ The method wizard opens the section **5. Save**.

- 8 Tap **✓ Finish** to save the new method.
- ➔ The method has been created and appears in the list.

Note

The **Determination type** can only be selected as part of a new created method. If another **Determination type** (solid, liquid) is required, a new method must be created.

5.2.5.2 Performing a "Density determination"

This example describes how to determine the density of a solid using a density kit.

- A density kit is available for the balance.
- 1 Open the **Methods** section.
 - 2 Select a method from the **Methods list** or define a new method.
 - 3 Tap **▶ Start method**.
 - ➔ The main weighing screen appears with the selected method.
 - 4 Tap **▶ Start**.
 - 5 Specify the **Temperature** and the **Aux. liquid**.
 - 6 Tap **✓ OK**.
 - 7 Follow the instructions from the wizard.


Note

For approved balances, if the zeroing fails, use the function **Perform initial zero**, see [Service menu ▶ Page 80].

- ➔ The **Results list** opens and shows a summary of the weighing results.
- 8 Tap **☰ Complete** to open the printing options.
 - ➔ The dialog **Complete task** appears.
 - 9 Tap **✓ Complete**.
 - ➔ The task **Density determination** was successfully completed.

5.2.6 Method "Piece Counting"

The method **Piece Counting** allows you to determine the number of pieces put on the weighing pan. It is advantageous if all pieces are of approximately equal weight, since the unit quantity is determined on the basis of the average weight of a single piece.



For details about method settings:

See also

🔗 Settings: method "Piece Counting" ▶ Page 113

5.2.6.1 Creating a method "Piece Counting"

☰ **Navigation:** ☰ **Methods** > ☰ **Methods list**

- 1 Tap **+** **New** in the action bar.
 - ➔ The method wizard opens, starting at **1. Method type**.
- 2 Tap **Method type** and select the method type **Piece Counting**.
- 3 Tap **→ Next**.
 - ➔ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap **→ Next**.
 - ➔ The method wizard opens the section **3. Configuration**.
- 5 Select a **Tolerance profile** and tap **→ Next**.
 - ➔ The method wizard opens the section **4. Weighing item**.
- 6 Define a reference for pieces **Reference PCS**, a **Reference average weight**, **Target weight** and tap **→ Next**.
 - ➔ The method wizard opens the section **5. Save**.
- 7 Tap **✓ Finish** to save the new method.
 - ➔ The method has been created and appears in the list.



5.2.6.2 Performing a "Piece Counting"

Note

It is possible to exclude a weighing result from the **Results list**. Open the **Results list**, select a result to exclude, and tap **Exclude result**.


The window **Complete task** always appears after completing the task, even if the results are saved automatically.

This section describes how the method **Piece Counting** is being used in a task example. In this example we are weighing pieces in a sample vessel.

- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap **▶ Start method**.
 - ➔ The main weighing screen with the selected method opens. The balance displays the defined target value, the tolerance and the current average weight of one piece.
- 4 Press **→0←** to zero the balance.
 - or
 - If a container is used, place the container (1) on the weighing pan (2) and press **→T←** to tare the balance.
 - ➔ The tare-measurement starts with **Taring...**
- 5 If not yet done, enter the average weight for a known number of pieces in the method settings. This serves as reference for the piece counting. Tap  to capture the weight of the items on the weighing pan and use it as reference weight.
- 6 Place the pieces in the sample vessel.
- 7 Close the draft shield (if applicable) and wait until the weight stabilizes.
- 8 Tap **+** **Add result**.
 - ➔ The weighing result is saved to the **Results list**.
- 9 When the weighing process is finished, tap  **Complete** in the action bar.
 - ➔ The window **Complete task** opens. The task-specific information can be printed on a label printer. The **Results list** can be printed manually or automatically (depending on the method settings).
 - ➔ The task **Piece Counting** was successfully completed.

5.2.7 Editing a method

To clone a method proceed as follows:

- 1 Open the **Methods** section.
- 2 Select the method that you want to edit.
 - ➔ The line color of the selected method becomes blue.
- 3 Tap  **Edit**.



For details about method settings:

See also

 Weighing methods settings ▶ Page 81

5.2.8 Cloning a method

To simplify the process to create a method, an existing method can be cloned one or several times. The cloned method will have the same parameter values as the original one. If multiple weighing items exist in the original method, those will be cloned as well.




- 1 Open the **Methods** section.
- 2 Tap the method that you want to clone.
 - ➔ The line color of the selected method becomes blue.
- 3 Tap  **More** and tap  **Clone**.
 - ➔ A copy of the selected method appears in the list. The cloned method has the same settings as the original method.

Note

A method can be cloned several times. The name of the cloned method is always based on its original name, to which is appended a number.

5.2.9 Deleting a method

Both factory defined methods and user defined methods can be deleted if they are not needed. For this purpose proceed as follows:

- 1 Open the **Methods** section.
- 2 Tap the method that you want to delete.
 - ➔ The line color of the selected method becomes blue.
- 3 Tap  **More**.
- 4 Tap  **Delete**.
 - ➔ The message **Delete method and cancel tasks?** appears on the screen.
- 5 Tap  **OK** to delete the selected method.
 - ➔ The system returns to the method list. The method has been deleted and does not appear on the list anymore.

Note

There is always a method activated in the background. This method can not be directly deleted. To delete the method, another method must be started instead. Now the method is not activated anymore and can be deleted.

5.2.10 Using methods with multiple weighing items (itemized)

Working with itemized methods can simplify the workflow, especially when several weighings with different predefined target weights have to be carried out one after the other. Information such as a target weight and tolerances can be defined for each weighing item within a single task. This may save time and increase quality of weighing processes consisting of multiple steps.

Before multiple weighing items can be used in the weighing process, they must be defined. The two ways of creating a weighing method that includes several weighing items are:

- Directly define the multiple weighing items during the method creating process.
- Use the **Results list** of a running method to define a new method with multiple weighing items.

The following methods use multiple weighing items:

- **General weighing (itemized)**
- **Simple formulation (itemized)**

5.2.10.1 Creating a new method with multiple weighing items (itemized)

This example describes how to define multiple weighing items for the method **General weighing (itemized)**.

- 1 Open the **Methods** section.
 - 2 Tap **+ New** in the action bar.
 - 3 Tap **Method type** and select **General weighing (itemized)**.
 - 4 Step through the method wizard until step **4. Weighing items**.
 - ➔ The dialog **4. Weighing items** appears.
 - 5 Select a weighing item from the list and define the **Sample ID**, **Unit**, **Target weight**, **-Tolerance**, and **+Tolerance**.
 - 6 Tap **→ Next**.
 - 7 Tap **✓ Finish**.
- ➔ The method has been created and appears in the list.

5.2.10.2 Creating an itemized method from a completed task

It is possible to create a method with multiple items while performing a method that includes a single item, providing that the method type allows it. This example describes how to create a method **General weighing (itemized)** based on a method **General weighing**.

- 1 Start a method **General weighing**.
 - 2 Perform three weighings and add the results to the **Results list** by tapping **+ Add result**.
 - ➔ The results are saved to the **Results list**.
 - 3 Tap **⋮ More**.
 - 4 Tap **📄 Save as method (itemized)**.
 - 5 Define a **Method name**.
 - 6 Tap **✓ OK**.
- ➔ A method **General weighing (itemized)** including three items is created and added to the **Methods list** with the name defined by the user.

5.2.10.3 Performing an itemized method

After creating a method with multiple items, it can be started.

- 1 Open the **Methods** section.
- 2 Select an itemized method from the **Methods list**.
- 3 Tap **▶ Start method**.
 - ➔ The main weighing screen opens. The target weight and the tolerance limits defined in the method appear.

5.3 Test weights

5.3.1 Defining an individual test weight

The user should enter data related to each test weight based on the corresponding certificate. This enables each external test weight to be clearly assigned to a specific certificate. Up to 12 external test weights can be configured. These test weights can be used to carry out external tests and adjustments.

☰ **Navigation:** ☰ Methods > ⚙ Tests > ⚙ Test weights

i **Note**

An external test weight for an external adjustment has to weigh at least 10% of the balance capacity. External test weights under 10% of the balance capacity are not displayed on the balance.

- The dialog **Test weights** is open.
- 1 Tap **+ Test weight**.
- 2 Define the test weight settings and confirm with **✓ Finish**.
- ➔ The test weight is defined and will be available later in the test procedure.

5.3.2 Defining a combined test weight

The user can combine test weights to achieve a test weight capacity that is not available as a single standard weight. For example, a weight of 10 g and a weight of 20 g can be combined and used as a test weight of 30 g. Each combined test weight can include two or three test weights. The class of a specific combined weight can only be as good as the worst class of the individual test weights it contains. As for any other test weight, combined test weight can be used to carry out external tests and adjustments.

☰ **Navigation:** ☰ Methods > ⚙ Tests > ⚙ Test weights

- The dialog **Test weights** is open.
- At least two individual test weights are defined.
- 1 Tap **⚙ Combined weight**.
- 2 Enter a **Test weight name**.
- 3 Select the **Minimum weight class** for the combined weight.
- 4 Tap **Weights**.
 - ➔ The individual weights of at least **Minimum weight class** are shown.
- 5 Select the weights to include in the combined weight.
- 6 Tap **✓ OK**.
 - ➔ The **Nominal weight** is calculated as the sum of the selected individual weights.
- 7 Tap **✓ Save**.
 - ➔ The combined test weight is defined and will be available later in the test procedure.

5.4 Tests

Routine tests can be performed to ensure accurate weighing results according to GWP® or other QM systems. Therefore the tests should be performed in fixed, regular intervals depending on your QM system and the results should be documented in a traceable way.

☰ **Navigation:** ☰ Methods > ⚙ Tests


5.4.1 Overview routine tests

METTLER TOLEDO can help you to define the routine tests to be performed based on your process requirements. Please contact your local METTLER TOLEDO representative for additional information.

5.4.1.1 Eccentricity

The purpose of the eccentricity test is to check if every eccentric load deviation (corner load deviation) is within the user SOP tolerances. The corner load is the deviation of the measurement value through off-center (eccentric) loading. The corner load increases with the weight of the load and its distance from the center of the weighing pan support (1). If the display remains consistent, even when the same load is placed on different parts of the weighing pan, the balance does not have corner load deviation.

The result corresponds to the highest of the four determined eccentric load deviations (2 to 5).



5.4.1.2 Repeatability test

The repeatability test calculates the standard deviation of a series of measurements with a single test weight in order to determine the repeatability of the balance.

Repeatability is a measure of the ability of a balance to supply the same result in repetitive weighings with one and the same load under the same measurement conditions. During the test, a load is placed and measured at the same location on the weighing pan several times. Afterwards, the difference between the measured weight values is calculated. The spread of the measured results leads to the repeatability.

Repeatability is highly affected by the ambient conditions (drafts, temperature fluctuations and vibrations) and also by the skill of the person performing the weighing. Therefore, the series of measurements must be carried out by the same operator, in the same location, under constant ambient conditions and without interruption.

The following test types are available:

- **Repeatab. - 1 TP:** To test the repeatability of the balance at one test point, without tare weight.
- **Repeatab. - Tare - 1 TP:** To test the repeatability of the balance at one test point, with a tare weight.

5.4.1.3 Sensitivity test

The sensitivity of the balance defines the deviation between the balance reading and the actual load. The sensitivity test allows you to measure the sensitivity using one or two test points.

The following test types are available:

- **Sensitivity - 1 TP:** To test the sensitivity of the balance at one test point, without tare weight.
- **Sensitivity - 2 TP:** To test the sensitivity of the balance at two test points, without tare weight.
- **Sensitivity - Tare - 1 TP:** To test the sensitivity of the balance at one test point, with a tare weight.
- **Sensitivity - Tare - 2 TP:** To test the sensitivity of the balance at two test points, with a tare weight.

5.4.2 Creating a new test

Before a test can be performed, the test settings have to be defined. A test wizard is leading you step-by-step through the process.

- 1 Open the **Methods** section.
- 2 Tap **Tests**.
- 3 Tap **New**.
 - ➔ The wizard **Create new test** starts.
- 4 Select the test type.
- 5 Work through the process by using the button **Next** to go to the next step or the button **Back** to go back to the previous step.

For details about test settings:

See also

[Tests settings](#) ▶ Page 122

5.4.3 Performing a test



NOTICE

Incorrect weighing results due to wrong handling of the test weights.

- Only handle test weights with gloves, tweezers, weight forks, or weight handles.

You can perform an eccentricity test, a repeatability test or a sensitivity test. Which test you have to perform and when depends on the respective weighing processes. Mettler-Toledo GmbH can help you to define the routine tests to be performed based on your process requirements. Please contact your local METTLER TOLEDO representative for additional information.

Moments when tests could be performed:

- After cleaning
- After a software update
- Daily before putting into operation
- Depending on own SOP

Requirements:

- At least one test weight is defined.
- At least one sensitivity, one repeatability or one eccentricity test is created.

All of the following pictured test weights or vessels are examples. Actual test weights or vessels may look different.

See also

- [Defining an individual test weight](#) ▶ Page 45
- [Defining a combined test weight](#) ▶ Page 45
- [Tests settings](#) ▶ Page 122

5.4.3.1 Performing an "Eccentricity"

- 1 Open the **Methods** section.
- 2 Tap **Tests**.
 - ➔ The test(s) previously defined appear on the list.
- 3 Select the eccentricity test you wish to perform and tap **Start**.
 - ➔ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clean. Have at hand: the test weight, gloves, and the appropriate tools to handle the test weight.
- 5 When all requirements are fulfilled tap **✓ OK**.
- 6 Make sure that the weighing pan is empty and tap **✓OK**.
- 7 Choose an available test weight
 - or -
 - add a new test weight and tap **✓OK**.
- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ➔ The measurement starts with **Capturing weight...**
 - ➔ The result of the first measurement is added to the **Results list** as **Position 1**.
- 11 Lift the test weight and move to position 2 (front left corner of the weighing pan).
 - ➔ The measurement starts with **Capturing weight...**
 - ➔ The result of the second measurement is added to the **Results list** as **Position 2**.

- 12 Lift the test weight and move to position 3 (back left corner of the weighing pan).
 - ➔ The measurement starts with **Capturing weight....**
 - ➔ The result of the third measurement is added to the **Results list** as **Position 3**.
- 13 Lift the test weight and move to position 4 (back right corner of the weighing pan).
 - ➔ The measurement starts with **Capturing weight....**
 - ➔ The result of the fourth measurement is added to the **Results list** as **Position 4**.
- 14 Lift the test weight and move to position 5 (front right corner of the weighing pan).
 - ➔ The measurement starts with **Capturing weight....**
 - ➔ The result of the fifth measurement is added to the **Results list** as **Position 5**.
 - ➔ The eccentricity test is finished.
- 15 Remove the test weight carefully and tap **✓ OK**.
 - ➔ The door closes automatically (depending on the door settings) and the balance starts an automatic zeroing.
- 16 When the test procedure is finished, tap **Finish**.
 - ➔ The result dialog opens.
- 17 To print the results tap **Print**, to finish the test tap **✓ Finish**.

Test result

If the test failed, see "Troubleshooting", search the error, remedy it and test again. If the test fails again, contact a METTLER TOLEDO representative.

See also

[Troubleshooting](#) ▶ Page 139

5.4.3.2 Performing a "Repeatability test"

In this section, all repeatability tests are described. Which test you use depends on the respective test target.

Repeatability - 1 test point

- 1 Open the **Methods** section.
- 2 Tap **Tests**.
 - ➔ The test(s) previously defined appear on the list.
- 3 Select the repeatability test you wish to perform and tap **Start**.
 - ➔ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clean. Have at hand: the test weight, gloves, and the appropriate tools to handle the test weight.
- 5 When all requirements are fulfilled tap **✓ OK**.
- 6 Make sure that the weighing pan is empty and tap **✓OK**.
 - ➔ The balance starts an automatic zeroing.
- 7 Choose an available test weight
- or -
add a new test weight and tap **✓OK**.
- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ➔ The measurement starts with **Capturing weight....**
 - ➔ The result of the measurement is added to the **Results list**.
- 11 Remove the test weight carefully and tap **✓ OK**.
 - ➔ The balance starts an automatic zeroing.

- ➔ Depending on the specified **Number of repetitions** you have to repeat the last four steps a certain number of times.

12 When the test procedure is finished, tap  **Finish**.

- ➔ The result dialog opens.


13 To print the results tap  **Print**, to finish the test tap  **Finish**.

Repeatability - Tare - 1 test point

1 Open the **Methods** section.

2 Tap  **Tests**.

- ➔ The test(s) previously defined appear on the list.

3 Select the repeatability test you wish to perform and tap  **Start**.

- ➔ The test sequence starts.

4 Ensure that the weighing pan is empty and clean. Have at hand: the test weight, gloves, and the appropriate tools to handle the test weight.

5 When all requirements are fulfilled tap  **OK**.

6 Make sure that the weighing pan is empty and tap  **OK**.

- ➔ The balance starts an automatic zeroing.

7 Choose an available test weight/test container

- or -

add a new test weight/test container.

8 Place the test weight/test container in the center of the weighing pan and tap  **OK**.

- ➔ The measurement starts with **Taring....**

- ➔ The tare result is added to the **Results list**.

9 Carefully place the test weight onto the weighing pan or into the tare container.

- ➔ The measurement starts with **Capturing weight....**

- ➔ The result of the measurement is added to the **Results list**.

10 Remove the test weight, leave the container on the weighing pan.

- ➔ The measurement starts with **Taring....**

11 Carefully place the test weight onto the weighing pan or into the tare container.

- ➔ The measurement starts with **Capturing weight....**

- ➔ The result of the measurement is added to the **Results list**.

- ➔ Depending on the specified **Number of repetitions** you have to repeat the last two steps a certain number of times.

12 When the test procedure is finished, tap  **Finish**.

- ➔ The result dialog opens.

13 To print the results tap  **Print**, to finish the test tap  **Finish**.

Test result

If the test failed, see "Troubleshooting", search the error, remedy it and test again. If the test fails again, contact a METTLER TOLEDO representative.









See also

 Troubleshooting ▶ Page 139









5.4.3.3 Performing a "Sensitivity test"

In this section, two of four possible sensitivity tests are described. Which test you use depends on the respective test target. The procedure for the tests with two test points is similar, but additional test weights and test containers are necessary.

Sensitivity - 1 test point

- 1 Open the **Methods** section.
- 2 Tap  **Tests**.
 - ➔ The test(s) previously defined appear on the list.
- 3 Select the sensitivity test you wish to perform and tap  **Start**.
 - ➔ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clean. Have at hand: the test weight, gloves, and the appropriate tools to handle the test weight.
- 5 When all requirements are fulfilled tap  **OK**.
- 6 Make sure that the weighing pan is empty and tap  **OK**.
 - ➔ The balance starts an automatic zeroing.
- 7 Choose an available test weight
- or -
add a new test weight and tap  **OK**.
- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ➔ The measurement starts with **Capturing weight....**
 - ➔ The result of the measurement is added to the **Results list**.
- 11 When the test procedure is finished, tap  **Finish**.
 - ➔ The result dialog opens.
- 12 To print the results tap  **Print**, to finish the test tap  **Finish**.


Sensitivity - Tare - 1 test point

- 1 Open the **Methods** section.
- 2 Tap  **Tests**.
 - ➔ The test(s) previously defined appear on the list.
- 3 Select the sensitivity test you wish to perform and tap  **Start**.
 - ➔ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clean. Have at hand: the test weight, gloves, and the appropriate tools to handle the test weight.
- 5 When all requirements are fulfilled tap  **OK**.
- 6 Make sure that the weighing pan is empty and tap  **OK**.
 - ➔ The balance starts an automatic zeroing.
- 7 Choose an available test weight
- or -
add a new test weight and tap  **OK**.
 - ➔ The measurement starts with **Capturing weight....**
 - ➔ The tare result is added to the **Results list**.
- 8 Carefully place the test weight onto the weighing pan or into the tare container.
 - ➔ The measurement starts with **Capturing weight....**
 - ➔ The result of the measurement is added to the **Results list**.
- 9 When the test procedure is finished, tap  **Finish**.
 - ➔ The result dialog opens.
- 10 To print the results tap  **Print**, to finish the test tap  **Finish**.

Test result


If the test failed, see "Troubleshooting", search the error, remedy it and test again. If the test fails again, contact a METTLER TOLEDO representative.

See also

 Troubleshooting ▶ Page 139

5.4.4 Editing a test

≡ Navigation: Methods > Tests




- 1 Select the test to be edited from the list and tap  **Edit**.
 - ➔ The test settings open.
- 2 Edit the test settings.

See also


 Tests settings ▶ Page 122






5.4.5 Printing test results

You can print a test manually, whether the parameter **Automatic print** in the test settings is activated or deactivated. For this purpose proceed as follows:

- 1 Open the **Methods** section.
- 2 Tap  **Tests**.
 - ➔ The test list opens.
- 3 Select the test to print and tap  **More** and tap  **Print all**
 - ➔ The test is printed.

5.4.6 Deleting a test

Running tests are labeled with the symbol  and cannot be deleted. To delete a test, it must be finished or another test must be activated. To delete a test, proceed as follows:

- 1 Open the **Methods** section.
- 2 Tap  **Tests**.
 - ➔ The test list opens.
- 3 Select the test to delete.
- 4 Tap  **More** and tap  **Delete**.
 - ➔ The section **Delete routine test** opens. The message **Do you really want to delete the selected routine test?** appears.
- 5 Tap  **Yes** to delete the test. Tap  **No** to cancel the deleting process.
 - ➔ After deleting the test, the system returns to the test list. The test has been deleted and does not appear on the list anymore.

5.4.7 Consulting the test history

≡ Navigation: Balance menu > History > Tests

- Select a test.
- ➔ The test history opens. Specific data are displayed for each test, such as the date and time, type of test, temperature, level state, test weight ID, and weight deviation.

See also

 History ▶ Page 69

5.5 Adjustments

This section describes how internal and external adjustments can be defined and performed. Which type of adjustment is performed depends on the defined adjustment **Strategy**.

≡ **Navigation:** ☰ **Methods** > ⚙ **Adjustments**

5.5.1 Internal adjustment

5.5.1.1 Editing an "Internal adjustment"

- 1 Open the **Methods** section.
 - 2 Tap ⚙ **Adjustments**.
 - 3 Tap ✎ **Edit**.
 - 4 Set the **Strategy** to **Internal adjustment**.
 - 5 Define the adjustment parameters.
 - 6 Tap ✓ **Save**.
- ➔ Your internal adjustment has been edited.

For details about adjustment settings:

See also

🔗 Adjustments settings ▶ Page 132

5.5.1.2 Performing an "Internal adjustment"

- The adjustment **Strategy** is set to **Internal adjustment**.
- 1 Open the **Methods** section, tap ⚙ **Adjustments**, select the adjustment, and tap ▶ **Start**
- or -
from the main weighing screen, tap ⋮ **More** and tap **Start adjustment**.
 - ➔ **Internal adjustment** is being executed.
 - ➔ When the adjustment has been completed, an overview of the adjustment results appears.
 - 2 Tap 🖨 **Print** if you want to print the results.
 - 3 Tap ✓ **Finish adjustment**.
- ➔ The balance is ready.

5.5.2 External adjustment

5.5.2.1 Editing an "External adjustment"

- 1 Open the **Methods** section.
 - 2 Tap ⚙ **Adjustments**.
 - 3 Tap ✎ **Edit**.
 - 4 Set the **Strategy** to **External adjustment**.
 - 5 Tap ⚙ **Test weights - Edit test weight**.
 - ➔ The dialog **Test weights - Edit test weight** opens.
 - 6 Select a test weight from the list and tap ✓ **OK**
- or -
tap + **Test weight** to define a new test weight.
 - 7 Define the test weight settings and confirm with ✓ **OK**.
 - 8 Tap ✓ **Save**.
- ➔ Your external adjustment has been edited.









For details about adjustment settings:

See also

[Adjustments settings](#) ▶ Page 132

5.5.2.2 Performing an "External adjustment"

After the external weights have been defined, the function **External adjustment** can be performed.

- 1 Open the **Methods** section.
- 2 Tap  **Adjustments**.
- 3 Select the external adjustment you wish to perform and tap  **Start**.
 - ➔ The adjustment process starts.
- 4 Ensure that the weighing pan is empty and clean. Have at hand: the test weight, gloves, and the appropriate tools to handle the test weight.
- 5 When all requirements are fulfilled tap  **OK**.
- 6 Make sure that the weighing pan is empty and tap  **OK**.
- 7 Choose an available test weight
 - or -
 - add a new test weight and tap  **OK**.
- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ➔ The adjustment starts.
- 11 Remove the test weight from the weighing pan and tap  **OK**.
 - ➔ The adjustment is finishing and the adjustment results appear.
- 12 To print the results tap  **Print**, to finish the test tap  **Finish**.

See also

[Defining an individual test weight](#) ▶ Page 45

[Defining a combined test weight](#) ▶ Page 45

5.5.3 Consulting the adjustment history

 **Navigation:**  **Balance menu** >  **History** >  **Adjustments**

- Select an adjustment.
- ➔ The adjustment history opens. Specific data are displayed for each adjustment such as the date and time, type of adjustment, temperature, level state, adjustment trigger, and correction.

See also

[History](#) ▶ Page 69

5.6 Peripheral devices

5.6.1 Printer

Printers can help document your processes and results. Two types of printers can be connected to the balance:

- strip printer: to print on strip paper, for example, for the documentation of weighing result
- label printer: to print on label stickers, for example, for the identification of samples

Each weighing method offers the possibility to trigger the printing process manually on a label or on strip paper when completing a task. The settings of the method can also be edited such that the results are automatically printed when a result is added to the result list or when the task is complete, for example. When using a label printer, the template of the printed label is defined individually for each method.

The following sections show typical use cases of installing and using a printer with the balance. They cover two combinations of settings amongst: manual and automatic printing, strip and label printing, task results and weighing item results printing, as well as USB and Bluetooth connections. Other combinations of settings can be achieved similarly.



NOTICE

Damage to the device due to inappropriate use

- Consult the User Manual of the device before using it.

5.6.1.1 Printing results manually on a strip printer via USB

This example describes how to install a strip printer using a USB cable. For this example, the method does not include automatic printing, but the results are printed manually when the task is completed.

Installing and configuring the printer

- The printer is connected to the power outlet and switched on.
 - The USB cable is connected to the printer.
 - The main weighing screen is shown on the balance terminal.
- 1 Connect the USB cable to one of the USB-A ports of the balance.
 - ➔ The balance detects the USB device automatically. The dialog **Add device** appears, informing the user that the system has found a specific device.
 - 2 Set a name for the USB device, then tap → **Next**.
 - 3 Tap ✓ **Finish**.
 - ➔ The USB device is connected and saved to the system.
 - ➔ The settings of the device are displayed.
 - 4 Tap **Printer settings**.
 - 5 Tap **Printer category** and select **Strip printer**.
 - 6 Tap ✓ **Save**.

Note

Some printers can print both on labels or on strip paper. In those cases, the printer type must be specified in the settings of the printer. If the printer can only print on labels or can only print on strip paper, the printer type is set automatically.

Note

A label printer and a strip printer can be connected simultaneously to the balance. However, only one printer of a specific type can be active at any given time. When connecting a new printer of the same type, the printer of the same type that was previously active is deactivated automatically. After connecting a new printer, verify the status of all other printers.

Note

If the USB cable is disconnected and reconnected, the connection will be detected automatically. The printer does not need to be installed again.

Printing a test page

After installing and configuring a printer, a test page can be printed.

≡ **Navigation:** ⚙ **Balance menu** > ⚙ **Settings** > 🖨 **Devices / Printers**

- A printer is connected to the balance.
- 1 Navigate to the section 🖨 **Devices / Printers**.
 - 2 Select the printer in the list of devices.

- 3 Tap **⋮ More** and tap **Print test page**.

Printing the results

≡ **Navigation:** **Methods** > **Methods list**

- A strip printer is connected to the balance.
- 1 Select a method from the **Methods list**.
 - 2 Tap **Start method**.
 - 3 Perform the necessary actions to weigh your sample(s).
 - 4 Tap **Complete** to open the export options.
 - ➔ The dialog **Complete task** appears.
 - 5 Tap **Print results manually** to print the results on the strip printer.

See also

[Devices / Printers](#) ▶ Page 78

5.6.1.2 Printing results automatically on a label printer via Bluetooth

This example describes how to install a label printer using a Bluetooth adapter. For this example, the method is set such that a label is printed automatically every time the user taps **Add result**.



For more information about how to install your Bluetooth adapter, consult the Installation Instructions provided with it.

Installing and configuring the printer

≡ **Navigation:** **Balance menu** > **Settings** > **Interfaces** > **Bluetooth**

≡ **Navigation:** **Balance menu** > **Settings** > **Devices / Printers**

- The printer is connected to the power outlet and switched on.
 - A Bluetooth RS adapter (to connect to the printer) and a Bluetooth USB adapter (to connect to the balance) are available.
 - The switch on the Bluetooth RS adapter is in the position DCE.
 - You have identified the MAC address (unique device address) on the Bluetooth RS adapter.
 - The main weighing screen is shown on the balance terminal.
- 1 Connect the Bluetooth USB adapter to one of the USB-A ports of the balance.
 - 2 Connect the Bluetooth RS adaptor to the printer.
 - ➔ The lights on the Bluetooth RS adaptor start blinking.
 - 3 Navigate to the section **Bluetooth**.
 - 4 Set **Activation** to **Active**.
 - 5 Tap **Save**.
 - 6 Navigate to the section **Devices / Printers**.
 - 7 Tap **Add device**.
 - ➔ The dialog **Add device** opens.
 - 8 Select **Bluetooth connection** and tap **→ Next**.
 - ➔ The message **Searching for devices...** appears.
 - ➔ The MAC addresses of all the available Bluetooth devices appear.
 - 9 Select the MAC address of the Bluetooth RS adapter from the list and tap **→ Next**.
 - 10 Check that the **PIN Code** is correct: `Mettler-Toledo`.
 - 11 Tap **→ Next** to confirm the Bluetooth connection.

- ➔ The balance is pairing the Bluetooth USB adapter from the balance with the Bluetooth RS adapter from the printer.
 - ➔ The system informs the user that it has found the device.
- 12 Set a name for the USB device, then tap ➔ **Next**.
- 13 Tap ✓ **Finish**.
- ➔ The USB device is connected and saved to the system.
 - ➔ The settings of the device are displayed.
- 14 Tap **Printer settings**.
- 15 Tap **Printer category** and select **Label printer**.
- 16 Tap ✓ **Save**.

 **Note**

When setting up the Bluetooth connection, the balance pairs with the Bluetooth RS adaptor, not with the printer that is attached to it. When the user connects the same Bluetooth RS adaptor to another printer, the user must remove the configured printer from the list of devices and add the new printer.

 **Note**

Some printers can print both on labels or on strip paper. In those cases, the printer type must be specified in the settings of the printer. If the printer can only print on labels or can only print on strip paper, the printer type is set automatically.

 **Note**

A label printer and a strip printer can be connected simultaneously to the balance. However, only one printer of a specific type can be active at any given time. When connecting a new printer of the same type, the printer of the same type that was previously active is deactivated automatically. After connecting a new printer, verify the status of all other printers.



 **Note**

If the USB adapter is removed from the balance and plugged in again, the Bluetooth connection will be detected automatically. This may take up to 30 seconds.

Printing a test page



After installing and configuring a printer, a test page can be printed.

≡ **Navigation:**  **Balance menu** >  **Settings** >  **Devices / Printers**

- A printer is connected to the balance.
- 1 Navigate to the section  **Devices / Printers**.
 - 2 Select the printer in the list of devices.
 - 3 Tap **⋮ More** and tap  **Print test page**.

Editing the method settings

≡ **Navigation:**  **Methods** >  **Methods list**

- 1 Select a method from the **Methods list**.
- 2 Tap  **Edit**.
- 3 Tap  **Print / Export**.
- 4 Tap **Label printout for weighing item**.
- 5 Set **Automatic label printout for weighing item** to **Active**.
- 6 Select the desired template from the list: **Used template**.
- 7 Tap **Field settings**.
- 8 Customize the content of each field.
- 9 Tap ✓ **OK**.
- 10 Tap ✓ **Save**.

Printing the results

☰ Navigation: ☰ Methods > ☰ Methods list

- A label printer is connected to the balance.
 - A method exists with the desired template for the printed label.
- 1 Select the method from the **Methods list**.
 - 2 Tap ► **Start method**.
 - 3 Perform the necessary actions to weigh your sample.
 - 4 Tap + **Add result**.
 - ➔ The label for this weighing item is automatically printed on the label printer.

See also

- 🔗 Bluetooth ► Page 78
- 🔗 Devices / Printers ► Page 78

5.6.2 Barcode reader

The barcode reader can be used to enter text or numbers in any input field on the terminal. The format of the field must be compatible with the scanned barcode. Depending on the settings of the weighing method, the characters of the barcode can be added to the active field or to a specific field of the method. The latter is depicted by the following example.



NOTICE

Damage to the device due to inappropriate use

- Consult the User Manual of the device before using it.

5.6.2.1 Scan a sample ID using a barcode reader




This example shows how the barcode reader can be used to specify the ID of a sample in a method of type **General weighing**. A similar procedure can be applied to other method types and/or other input fields.

Installing and configuring the barcode reader

- A barcode reader is available.
 - The main weighing screen is shown on the balance terminal.
- 1 Connect the USB cable to one of the USB-A ports of the balance.
 - ➔ The balance detects the USB device automatically. The dialog **Add device** appears and a barcode is displayed.
 - 2 Use the barcode reader to scan the barcode on the display.
 - 3 Tap → **Next**.
 - 4 Set a name for the USB device, then tap → **Next**.
 - 5 Tap ✓ **Finish**.
 - ➔ The USB device is connected and saved to the system.
 - ➔ The settings of the device are displayed.
 - 6 Tap ✓ **Save**.
 - ➔ The barcode reader is ready to use.



Editing the method settings

Navigation: ☰ Methods > ☰ Methods list

- A method **General weighing** exists.
 - The method contains one **Result ID** for which **Result description** is set to **Sample ID**.
- 1 Select the method from the **Methods list**.
 - 2 Tap  **Edit**.
 - 3 Tap  **Automation**.
 - 4 Tap **Barcode data target** and select the **Result ID** corresponding to **Sample ID**, for example, **Result ID 1**.
 - 5 Tap  **Save**.

Running the method

Navigation: ☰ Methods > ☰ Methods list

- The barcode reader is connected to the balance.
 - You have a sample identified with a barcode.
- 1 Select the method from the **Methods list**.
 - 2 Tap  **Start method**.
 - 3 Use the barcode reader to scan the barcode that identifies your sample.
 - ➔ The text associated to the barcode appears in the field of **Sample ID**.
 - 4 Perform the necessary actions to weigh your sample.
 - 5 Tap  **Add result**.

See also

 [Devices / Printers](#) ▶ Page 78

5.6.3 Foot switch and ErgoSens

The foot switch and the ErgoSens are optional accessories that allow you to perform operations on your balance without having to use the terminal. The following section shows an example of an operation that can be performed with a foot switch or an ErgoSens.



NOTICE



Damage to the device due to inappropriate use

- Consult the User Manual of the device before using it.

5.6.3.1 Taring the balance with an ErgoSens

This example explains how to install a USB ErgoSens and configure it to tare the balance.

Installing and configuring the ErgoSens

- An ErgoSens is available.
 - The main weighing screen is shown on the balance terminal.
- 1 Connect the USB cable to one of the USB-A ports of the balance.
 - ➔ The balance detects the USB device automatically. The dialog **Add device** appears, informing the user that the system has found a specific device.
 - 2 Set a name for the USB device, then tap  **Next**.
 - 3 Tap  **Finish**.
 - ➔ The USB device is connected and saved to the system.
 - ➔ The settings of the device are displayed.


- 4 Tap **Function** and select **Tare**.
- 5 Tap **✓ Save**.
 - ➔ The ErgoSens is ready to use to tare the balance.

See also

 [Devices / Printers](#) ▶ Page 78



5.6.4 Editing the settings of a device

☰ **Navigation:**  **Balance menu** >  **Settings** >  **Devices / Printers**

- 1 Navigate to the section  **Devices / Printers**.
 - ➔ A list of devices appears, showing the connection status and the connection type of each device.
- 2 Select the device from the list of devices and printers.
 - ➔ The details of the device are shown.
- 3 To change the name of the device, tap **Name**, enter the name and tap **✓**.
- 4 Some devices have additional editable settings. Tap on those settings to edit them.
- 5 Save the settings.

5.6.5 Deleting a device

☰ **Navigation:**  **Balance menu** >  **Settings** >  **Devices / Printers**

- 1 Navigate to the section  **Devices / Printers**.
 - ➔ A list of devices appears, showing the connection status and the connection type of each device.
- 2 Select the device from the list of devices and printers.
- 3 Tap **⋮ More** and tap  **Delete device**.
 - ➔ A message appears, asking you to confirm that you want to delete the device.
- 4 To delete, tap **✓ OK**. To cancel the delete dialog, tap **✗ Cancel**.
 - ➔ The device is deleted.

5.7 Remote control via services

5.7.1 LabX service

To enable communication between LabX and instruments, the appropriate settings on the instruments must correspond with the settings in LabX. LabX synchronizes the date and time on the instruments with the LabX Server each time a connection is made and each time a task is started. When an instrument is connected, the user interface language on the connected instrument is changed to the language currently installed on the LabX installation.



To install LabX on your computer and for more information about LabX, consult the LabX Reference Manual (RM).

 **Note**

Once the connection between LabX and the balance is established, the balance terminal is controlled by LabX. It is always possible to switch to manual mode directly on the terminal.

See also

 [LabX / Services](#) ▶ Page 79

5.7.1.1 Using LabX via a USB connection

To establish this connection, the USB driver must be installed on your computer. The driver is available online:

► www.mt.com/labweighing-software-download

Connecting the balance to the computer

- A USB-A to USB-B cable is available.
- 1 Connect the USB cable to the USB-B port of the balance.
- 2 Connect the USB cable to a USB-A port on the computer.

Configuring the service on the balance

≡ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > ⚙️ **LabX / Services**

- 1 Navigate to the section ⚙️ **LabX / Services**.
- 2 Set **LabX service** to **USB**.
- 3 Tap ✓ **Save**.

5.7.1.2 Using LabX via an Ethernet connection

Connecting the balance to the network

≡ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > 📶 **Interfaces**

- An Ethernet cable is available.
- 1 Connect the Ethernet cable to the Ethernet port of the balance.
- 2 Connect the other end of the Ethernet cable to your local network.
- 3 Navigate to the section 📶 **Interfaces**.
- 4 Tap **Ethernet**.
- 5 Keep the settings of the Ethernet connection at hand. This information might be required to set up the connection at a later stage.
- 6 Tap ✓ **Save**.

Configuring the service on the balance

≡ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > ⚙️ **LabX / Services**

- The balance is connected to the network via Ethernet.
- 1 Navigate to the section ⚙️ **LabX / Services**.
- 2 Set **LabX service** to **Network**.
- 3 Note the port number. This information might be required to set up the connection at a later stage.
- 4 Tap ✓ **Save**.

5.7.2 MT-SICS service

All XPR and XSR balances can be integrated to a network and can be configured to communicate with a computer using MT-SICS (METTLER TOLEDO Standard Interface Command Set). The available commands depend on the functionality of the balance.

For further information, please contact your METTLER TOLEDO representative.

The full documentation related to MT-SICS for XPR and XSR balances is available online.

► www.mt.com/labweighing-software-download

See also

🔗 [LabX / Services](#) ► Page 79

5.7.2.1 Using MT-SICS via a USB connection

This example describes how to establish a direct USB connection between your balance and a computer. The computer can then be used to control the balance and receive data using the commands of MT-SICS.

To establish this connection, the USB driver must be installed on your computer. The driver is available online:

► www.mt.com/labweighing-software-download

Connecting the balance to the computer

- A USB-A to USB-B cable is available.
- 1 Connect the USB cable to the USB-B port of the balance.
- 2 Connect the USB cable to a USB-A port on the computer.

Configuring the service on the balance

☰ **Navigation:** ⚙ **Balance menu** > ⚙ **Settings** > 🏠 **LabX / Services**

- 1 Navigate to the section 🏠 **LabX / Services**.
- 2 Set **MT-SICS** to **USB**.
- 3 Tap ✓ **Save**.

Configuring the computer

- The USB driver is installed on the computer.
- A terminal program is installed and running on the computer.
- 1 Provide the necessary connection settings to the terminal program.
- 2 Test the connection by sending a command to the balance, for example, `s` to retrieve the stable weight from the balance.
 - ➔ If a string is received by the terminal program with the weight, date, and time, the connection has been successfully established.
 - ➔ If no response is received by the terminal program, check the connection settings.

5.7.2.2 Using MT-SICS via an Ethernet connection

This example describes how to establish a connection between a balance and a computer through a local network. The computer can then be used to controlled the balance and receive data using the commands of MT-SICS.

Connecting the balance to the network

☰ **Navigation:** ⚙ **Balance menu** > ⚙ **Settings** > 🏠 **Interfaces**

- An Ethernet cable is available.
- 1 Connect the Ethernet cable to the Ethernet port of the balance.
- 2 Connect the other end of the Ethernet cable to your local network.
- 3 Navigate to the section 🏠 **Interfaces**.
- 4 Tap **Ethernet**.
- 5 Keep the settings of the Ethernet connection at hand. This information might be required to set up the connection at a later stage.
- 6 Tap ✓ **Save**.

Configuring the service on the balance

☰ **Navigation:** ⚙ **Balance menu** > ⚙ **Settings** > 🏠 **LabX / Services**

- The balance is connected to the network via Ethernet.
- 1 Navigate to the section 🏠 **LabX / Services**.
- 2 Set **MT-SICS** to **Network**.
 - ➔ The port number appears in the list of settings.
- 3 Note the port number. This information might be required to set up the connection at a later stage.

- 4 Tap **✓ Save**.

Configuring the computer

- A terminal program is installed and running on the computer.
- 1 Provide the necessary connection settings to the terminal program.
 - ➔ The computer is connected to the same network and the same subnet as the balance.
 - 2 Test the connection by sending a command to the balance, for example, `s` to retrieve the stable weight from the balance.
 - ➔ If a string is received by the terminal program with the weight, date, and time, the connection has been successfully established.
 - ➔ If no response is received by the terminal program, check the connection settings.

Note

For more information, contact your network administrator.

5.7.3 Web service

The web service allows users to send commands to control and transfer data from the balance using a web browser.

Connecting the balance to the network

☰ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > 🌐 **Interfaces**

- An Ethernet cable is available.
- 1 Connect the Ethernet cable to the Ethernet port of the balance.
 - 2 Connect the other end of the Ethernet cable to your local network.
 - 3 Navigate to the section 🌐 **Interfaces**.
 - 4 Tap **Ethernet**.
 - 5 Keep the settings of the Ethernet connection at hand. This information might be required to set up the connection at a later stage.
 - 6 Tap **✓ Save**.

Configuring the service on the balance

☰ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > 🌐 **LabX / Services**

- The balance is connected to the network via Ethernet.
 - The computer and the balance are connected to the same network.
 - A web browser is available on the balance.
- 1 Navigate to the section 🌐 **LabX / Services**.
 - 2 Activate and configure the service.
 - 3 Tap **✓ Save**.



The documentation of web service and related examples are available online.

▶ www.mt.com/labweighing-software-download

Note

For more information, contact your network administrator.

Exporting the WSDL definition file

The WSDL (Web Services Description Language) file describes the functionalities of the web service. The WSDL file can be exported as follows.

☰ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > ⚖️ **Balance** > ⚙️ **General**

- 1 Navigate to ⚙️ **General**.
- 2 Tap ⋮ **More**.
- 3 Tap **Export web service WSDL file**
 - ➔ A list of available target locations is shown, including the file server and any USB storage device connected to the balance.
- 4 Select the target device on which you want to store the data.
- 5 Tap → **Next**.
 - ➔ If the export was successful, the display shows ✔️ with the name of the file and the target folder.

See also

🔗 LabX / Services ▶ Page 79

5.8 Data management

5.8.1 Exporting results

This example describes how to export results to a USB storage device at the end of a task.

Exporting weighing results

☰ **Navigation:** ⚖️ **Methods** > ⚖️ **Methods list**

- A USB storage device is connected to the balance.
- 1 Select a method from the **Methods list**.
 - 2 Tap ▶ **Start method**.
 - 3 Perform the necessary actions to weigh your sample(s).
 - 4 Tap 📄 **Complete** to open the export options.
 - ➔ The dialog **Complete task** appears.
 - 5 Tap **Export results manually** to export the results.
 - ➔ A list of available USB storage devices is shown.
 - 6 Select the target USB storage device to store the data.
 - 7 Tap → **Next**.
 - ➔ The results are exported to the USB storage device.
 - 8 Tap ✔️ **Complete**.
 - ➔ After completing the task, the results are deleted from the **Results list**.

Exporting the XSD file

Weighing results are exported in XML files. The description of the elements of the XML file is provided in an XSD (XML Schema Definition) file. The XSD file can be exported as follows.

📘 **Note**

If the XSD file is used for validation, the version contained in the XML file must match the version of the XSD schema.

☰ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > ⚖️ **Balance** > ⚙️ **General**

- 1 Navigate to ⚙️ **General**.
- 2 Tap ⋮ **More**.
- 3 Tap **Export results XSD files**.
 - ➔ A list of available target locations is shown, including the file server and any USB storage device connected to the balance.
- 4 Select the target device on which you want to store the data.
- 5 Tap → **Next**.

➔ If the export was successful, the display shows  with the name of the target folder.

5.8.2 Sending individual results to a computer

The balance offers the possibility to send weighing results to a computer via a USB connection. This feature can be used, for example, to send results to an Excel sheet, to a text file, or to MT-SICS. When used in mode **HID** (Human Interaction Device), the result is sent to the computer where the cursor is located, exactly as if it were a keyboard input (also referred to as "drop to cursor").

This example describes how to send weighing results from a method of type **General weighing** directly into an Excel file on a computer using the functionality **HID**.


Connecting the balance to the computer

- A USB-A to USB-B cable is available.

 - 1 Connect the USB cable to the USB-B port of the balance.
 - 2 Connect the USB cable to a USB-A port on the computer.

Configuring the balance

≡ **Navigation:**  **Balance menu** >  **Settings** >  **Balance** >  **Weighing / Quality**

- 1 Navigate to the section  **Weighing / Quality**.
- 2 Tap **Automatic weight value output**.
- 3 Tap **Output mode** and select **Results**.
- 4 Tap **Target** and select **HID**.
- 5 Review the rest of the settings in the section **Automatic weight value output** to customize the output, for example, to add the date and time to each weighing result.





Note

The right settings are highly dependent on your application. For example, when using an Excel sheet as the target, values separated with the character **TAB** will be placed in separate cells.

Editing the method settings

≡ **Navigation:**  **Methods** >  **Methods list**



- A method **General weighing** exists.

 - 1 Select the method from the **Methods list**.
 - 2 Tap  **Edit**.
 - 3 Tap  **Print / Export**.
 - 4 Tap **Strip printout and data export**.
 - 5 Set **Weight value** to **Active**.
 - 6 Tap  **OK**.
 - 7 Tap  **Save**.

➔ The method is set up to send the results to the computer when tapping **Add result**.

Running the method

- The USB driver is installed on the computer.

 - 1 Select the method from the **Methods list**.
 - 2 Tap  **Start method**.
 - 3 Perform the necessary actions to weigh your sample.
 - 4 Open an Excel sheet and place the cursor in a first target cell, for example, "A1".
 - 5 Tap  **Add result**.
 - ➔ The weighing result is saved to the **Results list**.
 - ➔ The weighing result is stored in cell "A1" of your Excel sheet.
 - ➔ If the character **TAB** is used as delimiter, the other weighing parameters are stored in cells "B1", "C1", etc.

- ➔ If the character **Enter** is used to mark the end of the line, the cursor now appears in cell "A2".

5.8.3 Exporting and importing settings

The settings of the balance can be exported and imported. Transferring data from one balance to another is helpful, for example, to use the same method on several balances. It is also good practice to store the balance settings as backup before updating the software.

The following data can be imported and exported:

- **Balance settings**
 - When importing these settings, the GWP status of the balance might change (**GWP Approved mode**).
 - The balance might prompt to reboot.
- **Methods**
 - When importing methods, you can select if all methods or only selected methods are imported.
 - If importing a method with the same name as an existing method, you can select if you want the method to be overwritten or not.
- **Tests and weights**
 - When importing these settings, all the existing tests and test weights on the balance are erased and replaced by the imported data.

The data can be transferred via a USB storage device. For XPR balances, the data can also be transferred via a file server.



NOTICE

Data import can cause data loss

Importing data can delete user application data without warning.

5.8.3.1 Transferring test weight settings between balances

This example shows how to export test weight settings from one balance and import them on another balance. This procedure is particularly helpful if you are using the same calibrated weights to perform tests on several balances. The data is transferred using a USB storage device.

Exporting data and settings

☰ **Navigation:** ⚙ **Balance menu** > 🛠 **Maintenance** > 📄 **Import / Export**

- A USB storage device is connected to the balance.
- 1 Navigate to the section 📄 **Import / Export**.
 - ➔ The dialog **Import / Export** opens.
- 2 Select 📄 **Export data and settings** and tap → **Next**.
 - ➔ The dialog **Export data and settings** opens.
- 3 Deactivate all data types except **Tests and weights**.
- 4 Tap ✓ **Export**.
 - ➔ A list of available USB storage devices is shown.
- 5 Select the target USB storage device to store the data.
- 6 Tap → **Next**.
 - ➔ The system exports the data to the USB storage device.
 - ➔ If the export was successful, the display shows 🟢 with the name of the file and the target folder.
- 7 Tap ✕ **Close** to finish the process.

Importing data and settings

≡ **Navigation:** ⚙️ **Balance menu** > 🗄️ **Maintenance** > 📄 **Import / Export**

■ A USB storage device containing the data to import is connected to the balance.

1 Navigate to the section 📄 **Import / Export**.

➔ The dialog **Import / Export** opens.

2 Select 📄 **Import data and settings** and tap → **Next**.

➔ A list of available USB storage devices is shown.

3 Select the USB storage device containing the data to import.

4 Tap → **Next**.

5 Select which file you want to import.

6 Tap → **Next**.

7 To import only the test weights, select the data type **Test weights**.

8 Tap ✓ **Import**.

➔ The system imports the data from the USB storage device.

➔ If the import was successful, the message **Import of data and settings has been executed**. appears.

9 Tap ✕ **Close** to finish the process.

5.9 Tolerance profiles

≡ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > 🗄️ **Balance** > ⚙️ **Weighing / Quality** > **Tolerance profiles**

Creating a Tolerance profile

1 Tap + **New** to create a new profile.

2 Define the profile settings.

3 When all the settings have been defined, tap ✓ **OK**.

➔ The system returns to the profile list and the new profile appears on the list.

By tapping an existing profile, its settings can be changed, the profile can be deleted or it can be set as default value. Several profiles can be created. A default profile must be selected.

If changes are made to the default tolerance profile, the status of the routine tests will be set to **Never executed**.

5.10 Password protection and balance reset

The balance settings or the whole balance can be blocked to prevent unauthorized modifications or usage. An unblocking password first needs to be created.



NOTICE

Unusable balance due to forgotten password

A blocked balance cannot be unblocked without the unblocking password.

– Note the password and keep it in a safe place.





5.10.1 Creating an unblocking password

≡ **Navigation:** ⚙️ **Balance menu** > ⚙️ **Settings** > 🗄️ **Balance** > ⚙️ **General**

1 To create an unblocking password, tap ⋮ **More** in the action bar and select 🔑 **Unblocking password**

➔ The dialog **Set unblocking password** opens.

2 Set a new password, confirm it, and tap ✓ **OK**.



- 3 In the dialog  **General**, tap  **Save** and  **OK**.
- ➔ The unblocking password is created.
- ➔ The additional option  **Blocking** is available in the action bar of the **Balance menu**. It can be used to block the balance or block/unblock the balance settings.

5.10.2 Blocking and unblocking the settings






Blocking the settings prevents unauthorized modifications of the settings of the balance. If **Lock method** is activated for a specific method, blocking the balance settings also prevents unauthorized changes of the method settings. Further usage of the balance is possible, but the settings cannot be edited without the unblocking password (except **Language**).

☰ **Navigation:**  **Balance menu** >  **Blocking**



5.10.2.1 Blocking the balance settings

- The unblocking password is available.
- 1 To block the balance settings, tap  **Block settings**.
 - ➔ The dialog **Block balance** opens.
 - 2 Tap  **OK** to block the settings.
 - ➔ The balance settings are blocked. The balance can be used normally, but the balance and method settings cannot be edited.

5.10.2.2 Blocking method settings

- The balance settings are not blocked.
 - The unblocking password is available.
- 1 Select a method from the **Methods list** or define a new method.
 - 2 Tap  **Edit**.
 - 3 Tap  **General** and set **Lock method** to **Active**.
 - 4 Tap  **Save**.
 - 5 To block the balance settings, tap  **Block settings**.
 - ➔ The dialog **Block balance** opens.
 - 6 Tap  **OK** to block the settings.
 - ➔ The balance settings are blocked. The balance can be used normally, but the balance and method settings cannot be edited.
 - ➔ If **Lock method** is set to **Active** after the balance settings are blocked, the method can be edited until the next time the balance is blocked.

5.10.2.3 Unblocking the settings

- The balance settings are blocked.
 - The unblocking password is available.
- 1 To unblock the balance settings, tap  **Unblock settings**.
 - 2 Type the unblocking password and tap  **OK**.
 - ➔ The balance settings are unblocked.

5.10.3 Blocking and unblocking the balance

Blocking the balance will prevent any further usage of the balance.

5.10.3.1 Blocking the balance

≡ Navigation: ⚙ Balance menu > 🔒 Blocking

- 1 To block the balance, tap 🔒 **Block balance**.
➔ The dialog **Block balance** opens.
- 2 Tap → **Next**.
- 3 Enter your unblocking password and tap ✓ **Block balance**.
➔ The balance is blocked and the blocking screen appears.

5.10.3.2 Unblocking the balance

- The balance is blocked and the blocking screen is open.
- 1 Tap 🔓 **Unblock balance**.
 - 2 Type in the unblocking password, if applicable.
 - 3 Tap ✓ **Unblock balance** to confirm.
By tapping ✕ **Cancel** instead, the main weighing screen appears, but the balance is still blocked and only a limited number of settings can be edited.
- ➔ The balance is unblocked and the main weighing screen appears.

5.10.4 Resetting the balance

≡ Navigation: ⚙ Balance menu > 🛠 Maintenance > ↺ Reset



NOTICE


Reset causes data loss

Resetting the balance will delete user application data and set the user configuration back to factory state.






- 1 To delete the data for test history and adjustment history, activate the option **Also delete test and adjustment history**.
- 2 Tap → **Next**.
➔ The window **Reset balance** opens and warns that some data will be lost by resetting the balance.
- 3 Tap ↺ **Reset balance**.
➔ The balance software restarts in factory state.

6 Software Description

6.1 Balance menu settings

The **Balance menu** contains general settings and information. To open the section **Balance menu**, tap the symbol  on the right-hand side of the display.

The section **Balance menu** is divided into the following subsections.

-  **Leveling aid** (see [Leveling aid ▶ Page 69])
-  **History** (see [History ▶ Page 69])
-  **Balance info** (see [Balance info ▶ Page 70])
-  **Settings** (see [Settings ▶ Page 70])
-  **Maintenance** (see [Maintenance ▶ Page 80])

6.1.1 Leveling aid

Exact horizontal positioning and stable installation is essential for repeatable and accurate weighing results. With the **Leveling aid** the balance can be leveled.

≡ **Navigation:**  **Balance menu** >  **Leveling aid**

Note

After leveling the balance an internal adjustment must be performed.

See also




 [Leveling the balance ▶ Page 29](#)

6.1.2 History

The balance permanently records the tests and adjustments that are performed in the section **History**

≡ **Navigation:**  **Balance menu** >  **History**




The section **History** is divided into the following subsections:

-  **Adjustments**
-  **Tests**
-  **Service**

6.1.2.1 Adjustments

≡ **Navigation:**  **Balance menu** >  **History** >  **Adjustments**




A maximum of 500 entries can be stored in the adjustments history.

Button	Name	Description
	Filter	Tap to filter the list: <ul style="list-style-type: none">• By date range• By user name
	Print	Tap to print the displayed entries.
	Close	Tap to return to the section History .

6.1.2.2 Tests

≡ Navigation: ⚙ Balance menu > 📄 History > 📄 Tests




A maximum of 500 entries can be stored in the test history.

Button	Name	Description
	Filter	Tap to filter the list: <ul style="list-style-type: none">• By date range• By user name
	Print	Tap to print the displayed entries.
	Close	Tap to return to the section History .

6.1.2.3 Service

≡ Navigation: ⚙ Balance menu > 📄 History > 📄 Service

A maximum of 500 entries can be stored in the service history.



Button	Name	Description
	Filter	Tap to filter the list: <ul style="list-style-type: none">• By date range• By technician
	Print	Tap to print the displayed entries.
	Close	Tap to return to the section History .

6.1.3 Balance info

≡ Navigation: ⚙ Balance menu > 📄 Balance info

The section **Balance info** shows information about the specific balance about:

- **Identification**
- **Hardware**
- **Software**
- **Maintenance**

Button	Name	Description
	License agreement	Tap to open the licence agreement.
	Close	Tap to return to the Balance menu .

6.1.4 Settings

This section describes the settings of the balance that can be changed to suit specific requirements. The balance settings apply to the entire weighing system.

≡ Navigation: ⚙ Balance menu > ⚙ Settings

The section **Settings** is divided into the following subsections:

- ⚖ Balance
- 🖨 Interfaces
- 🖨 Devices / Printers
- ⚙ LabX / Services

6.1.4.1 Balance

≡ Navigation: ⚙ Balance menu > ⚙ Settings > ⚖ Balance

The section **Balance** is divided into the following subsections:

- ⚖ Weighing / Quality
- 🌐 Date / Time / Language / Format
- 🖨 Screen / StatusLight / Sound
- ⚙ General

Weighing / Quality

≡ Navigation: ⚙ Balance menu > ⚙ Settings > ⚖ Balance > ⚖ Weighing / Quality

Parameter	Description	Values
Leveling warning	Defines the action when the balance is out of level When Forced leveling is selected and the balance is out of level, no weighing value can be added to the Results list (green button disabled). For approved balances, this setting is set to Forced leveling and cannot be edited.	Inactive Optional leveling* Forced leveling
Tolerance profiles	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods. This section contains several settings that are described in the table Tolerance profiles below.	
Automatic weight value output	Defines if and in which manner (MT-SICS and/or HID) the weighing values should be exported. This section contains several settings that are described in the table Automatic weight value output below.	

GWP Approved mode	<p>Good Weighing Practice (GWP®) is a program started by METTLER TOLEDO to help customers operate their weighing equipment in a safe and efficient way. It covers every relevant step in the life cycle of the instrument and provides clear guidance on how to specify, calibrate and operate weighing instruments.</p> <p>The GWP Approved mode observes if the following conditions are given:</p> <ul style="list-style-type: none"> • Use of an appropriate tolerance profile. • The internal adjustment was successful. • Required tests were successful. • Setting up of enforced leveling. • No MinWeigh violation. <p>If all conditions are given, the balance adds the GWP Approved sign behind every weighing result.</p> <p>The GWP Approved mode can only be enabled by a METTLER TOLEDO service technician.</p>	Active Inactive*
Balance recalib. reminder	Defines whether the user is reminded about the upcoming expiry date of the calibration.	Active* Inactive
Days in advance	<p>Defines the number of days before the due date the recalibration reminder is shown.</p> <p>This setting is only available if Balance recalib. reminder is set to Active.</p>	Numeric (30 days* 0...400 days)
Action when calib. expired	<p>Defines the action when the calibration has expired.</p> <p>Block: The balance will be blocked. In this case, the balance cannot be used anymore until a user unblocks the balance.</p>	None* Block
Days before blocking	Defines the number of days before the reminder informs about the upcoming expiry date.	Numeric (30 days* 0...400 days)
Weight recalib. reminder	Defines whether the user is reminded about the upcoming expiry date of the test weight calibration.	Active Inactive*
Days in advance	<p>Defines the number of days before the due date the recalibration reminder is shown.</p> <p>This setting is only available if Weight recalib. reminder is set to Active.</p>	Numeric (30 days* 0...400 days)
Service reminder	Defines whether the user is reminded about the upcoming due date of the service.	Active Inactive*
Days in advance	<p>Defines the number of days before the due date the service reminder is shown.</p> <p>This setting is only available if Service reminder is set to Active.</p>	Numeric (30 days* 0...400 days)

* Factory setting

Tolerance profiles

Settings relating to weighing performance and data from balance calibration can be stored in a tolerance profile.

For more information about creating tolerance profiles, see [Tolerance profiles ▶ Page 66]

Parameter	Description	Values
Name	Defines the name of the profile.	Text (0...22 characters)
Indicator	Defines the color of the indicator icon for the tolerance profile. The icon will appear above the weighing value unit. When a color is selected, a description of maximum 3 characters can be added.	None* Neutral White Yellow Red Blue Green Black
Indicator text	Defines the text of the indicator icon.	Text (0...3 characters)

Calibration certificate	Selects a calibration certificate from a drop-down list of certificates available on the balance. New certificates can only be created by a service technician based on a performed balance calibration.	Calibration certificate None*
Environment	Defines the environmental conditions of the balance. Very stable: For an environment that is free from any drafts and vibrations. Stable: For an environment that is practically free from drafts and vibrations. Standard: For an average working environment subject to moderate variations in the ambient conditions. Unstable: For an environment where the conditions are from time to time changing. Very unstable: For an environment where the conditions are continuously changing.	Very stable Stable Standard* Unstable Very unstable
Weighing mode	Defines the filter settings of the balance. Universal: For all standard weighing applications. Sensor mode: Depending on the setting of the ambient conditions, this setting delivers a filtered weighing signal of varying strength. The filter has a linear characteristic in relation to time (not adaptive) and is suitable for continuous measured value processing.	Universal* Sensor mode
Value release	Defines the speed at which the balance regards the measured value as stable and available for capture. Very fast: recommended if you require fast results and repeatability is not very important. Very reliable: provides very good repeatability of the measured results but prolongs the stabilization time. Some intermediate settings can also be chosen from.	Very fast Fast Fast and reliable* Reliable Very reliable
Display readability	Determines the readability d of the balance display. 1d: Shows the maximum resolution 2d: 2 times smaller resolution 5d: 5 times smaller resolution 10d: 10 times smaller resolution 100d: 100 times smaller resolution 1000d: 1000 times smaller resolution For approved balances, the values available for this setting depend on the balance model.	1d* 2d 5d 10d 100d 1000d
Zero drift compensation	The function Zero drift compensation performs ongoing corrections of deviations from zero which may occur, for example, as a result of small amounts of dirt on the weighing pan. For approved balances, the values available for this setting depend on the balance model.	Active* Inactive
Allowed units	Defines the units that are allowed in this tolerance profile.	The available values are model-specific.

* Factory setting

Automatic weight value output

The balance can be connected to a computer with a USB cable. Weighing results can then be directly transferred to a target application, e.g., Microsoft Excel.

Parameter	Description	Values
Output mode	<p>Defines which weighing values are transferred via the communication interface, e.g., USB, Ethernet.</p> <p>Results: The weighing values are transferred only when they are added to the Results list.</p> <p>Continuous: The weighing values are transferred continuously via the interface defined under LabX / Services > MT-SICS.</p> <p>Additional fields are available, depending on the chosen option.</p>	Results* Continuous
Target	<p>Defines the way the weighing values are transferred.</p> <p>HID (Human Interaction Device): Transfers simple character streams (e.g. weight values) to a desktop computer without installing additional drivers (comparable to a keyboard). The format of a transferred weighing value can be configured.</p> <p>MT-SICS: The data is transferred in MT-SICS format (METTLER TOLEDO Standard Interface Command Set). MT-SICS operates bidirectional, i.e. usually balance sends the confirmations to the host and receives commands. A separate reference manual is available for MT-SICS.</p> <p>HID / MT-SICS: The data is transferred in HID and MT-SICS format in parallel.</p> <p>MT-SICS configurable: The data is transferred in a user-defined MT-SICS format.</p> <p>This setting is only available if Output mode is set to Results.</p>	HID* HID / MT-SICS MT-SICS MT-SICS configurable
Result ID 1 Result ID 2	<p>Defines if the fields Result ID 1 and Result ID 2 are included in the output, respectively.</p> <p>Supported characters are:</p> <ul style="list-style-type: none"> • numbers: 0 – 9 • letters: a – z and A – Z • special characters: space, dot, comma, semicolon, plus, minus <p>Non-supported characters will be replaced by a space.</p> <p>This setting is only available if Output mode is set to Results.</p>	Active Inactive*
Date	<p>Defines if the field Date is included in the output.</p> <p>The format of the date is YYYY-MM-DD.</p> <p>This setting is only available if Output mode is set to Results.</p>	Active Inactive*
Time	<p>Defines if the field Time is included in the output.</p> <p>The format of the time is hh-mm-ss.</p> <p>This setting is only available if Output mode is set to Results.</p>	Active Inactive*
Net indicator	<p>In the standard output format, net weights are not specially marked. To place an N in front of net weights, this function can be activated. The net symbol is left-justified in the field.</p> <p>This setting is only available if Output mode is set to Results.</p>	Active Inactive*
Net indicator field length	<p>Defines the field length of the Net indicator.</p> <p>This setting is only available if Output mode is set to Results and Net indicator is set to Active.</p>	Numeric (2* 1...2)

Weight field length	Defines the number of digits that will be transferred into the application on the computer, e.g., into an Excel field. This setting is only available if Output mode is set to Results .	Numeric (1* 0...20)
Sign	Defines if the weighing result is displayed with an algebraic sign. For all values: Each weighing result is preceded by a plus or minus sign. For negative values: Only negative values are preceded by a minus sign. Positive values are transferred without algebraic sign. This setting is only available if Output mode is set to Results .	For all values For negative values*
Sign position	Defines if the algebraic sign is positioned at the first place of the weight field or directly in front of the weight digits. This setting is only available if Output mode is set to Results .	Left of weight field Left of weight digits*
Decimal delimiter	Defines the character used to separate the whole and fractional part of a numeric value. This setting is only available if Output mode is set to Results .	, .*
Unit	Defines if a weighing unit is being shown in the weighing field. This setting is only available if Output mode is set to Results .	Active* Inactive
Unit field length	Defines the field length of the weighing unit. This setting is only available if Output mode is set to Results and Unit is set to Active .	Numeric (1* 1...6)
Field delimiter	Defines a character or sequence of characters to separate data fields. This setting is only available if Output mode is set to Results .	None Space* TAB , ;
End of line character	Defines a character or sequence of characters signifying the end of a line. This setting is only available if Output mode is set to Results .	CRLF CR LF TAB None Enter*
Updates/sec.	Defines the rate at which data is transferred. This setting is only available if Output mode is set to Continuous .	2 5 6* 10
Format	Defines the format of the transferred data. This setting is only available if Output mode is set to Continuous .	MT-SICS* PM AT/MT

* Factory setting

Date / Time / Language / Format

Navigation: Balance menu > Settings > Balance > Date / Time / Language / Format

Parameter	Description	Values
Date	Defines the current date.	Date
Time	Defines the current time. Use the plus/minus buttons to define the time.	Time
Language	Defines the language of the interface navigation.	English Deutsch Français 日本語 中文 Español Italiano Русский Português Polski Magyar Čeština
Time zone	Selects a time zone. When the time zone is set, the balance changes automatically between summer and winter time.	see list on the screen

Date format	Selects the date format.	D.MMM.YYYY* MMM D YYYY DD.MM.YYYY MM/DD/YYYY YYYY- MM-DD YYYY/MM/DD YYYY年M月D日
Time format	Selects the time format.	24:MM* 12:MM 24.MM 12.MM
Keyboard layout	Defines the language of the keyboard layout.	English German French Spanish Japanese Simplified Chinese Russian Czech Polish Hungarian

* Factory setting

Screen / StatusLight / Sound


Navigation: Balance menu > Settings > Balance > Screen / StatusLight / Sound

Parameter	Description	Values
Screen brightness	Defines the brightness of the display.	20 % 40 % 60 % 80 %* 100 %
Sound volume	Defines the volume of the terminal sound.	Inactive 20 % 40 % 60 %* 80 % 100 %
Sound on key press	Defines if there is a sound when a key is pressed.	Active* Inactive
Sound on info	Defines if there is a sound when an information appears on the screen.	Active* Inactive
Sound on warning	Defines is there is a sound when a warning appears on the screen.	Active* Inactive
Sound on error	Defines is there is a sound in case of an error.	Active* Inactive
StatusLight	<p>Activates/deactivates the StatusLight.</p> <p>Active (without green light): All current status of the balance are monitored, the red/yellow lights will turn on if needed, but the green light will stay turned off.</p> <ul style="list-style-type: none"> • StatusLight is red: Error. The balance must not be used until the error is corrected. • StatusLight is yellow: Warning. For example, the test manager has pushed a test to the balance or you are operating the balance between the date of the calibration reminder and the scheduled date of the next calibration. The balance can still be used. • StatusLight is green or off: Ok. No problems detected and the balance is ready to weigh. 	Active* Active (without green light) Inactive
StatusLight brightness	<p>Defines the brightness of the activated StatusLight.</p> <p>This setting is only available if StatusLight is set to Active or Active (without green light).</p>	20 % 40 % 60 %* 80 % 100 %

* Factory setting

General

Navigation:  Balance menu >  Settings >  Balance >  General

Parameter	Description	Values
Balance ID	Defines the ID of the balance. This name could be used to communicate with the balance over a network. No space or special characters are allowed.	Text (0...22 characters)
Standby	Defines if the balance automatically enters standby mode after not being used for a predefined Wait time . The standby mode can always be started manually by pressing  .	Active* Inactive
Wait time	Defines after how long the balance automatically switches to standby mode when not used. This setting is only available if Standby is set to Active .	Numeric (10 minutes* 0...60 minutes)
Software update on system start-up	With this option activated, software update can be performed from a USB storage device on startup.	Active* Inactive

6.1.4.2 Interfaces

Navigation:  Balance menu >  Settings >  Interfaces

The section **Interfaces** has the following subsection:

-  Ethernet
-  Bluetooth

Ethernet

The **Ethernet** interface allows to connect the balance to a network in order to:

- communicate remotely with the balance using the MT-SICS communication protocol or LabX

Navigation:  Balance menu >  Settings >  Interfaces >  Ethernet

Parameter	Description	Values
Host name	Defines the balance host name.	Text (1...22 characters)
MAC address	Information on the MAC address (Media Access Control) that is used to uniquely identify the balance in the network.	
Network configuration	DHCP: The settings of the Ethernet connection will be automatically set. Manual: The settings of the Ethernet connection must be set manually by the user.	DHCP* Manual
IP address	If the IP is not to be automatically obtained, you can enter it here.	000.000.000.000... 255.255.255.255
Subnet mask	Defines the subnet mask that is used by the TCP/IP protocol to determine whether a host is on the local subnet or on a remote network.	000.000.000.000... 255.255.255.255
DNS server (primary)	Defines the address of the primary DNS (domain name system) server.	000.000.000.000... 255.255.255.255
DNS server (secondary)	Defines the address of the secondary DNS server.	000.000.000.000... 255.255.255.255
Default gateway	Defines the address of the default gateway that links the host's subnet to other networks.	000.000.000.000... 255.255.255.255

* Factory setting

Bluetooth

Navigation: Balance menu > Settings > Interfaces > Bluetooth

Bluetooth identification

Parameter	Description	Values
Activation	With the option Bluetooth you have the possibility to communicate with a printer via Bluetooth.	Inactive* Active

* Factory setting

6.1.4.3 Devices / Printers

Navigation: Balance menu > Settings > Devices / Printers

This section is divided into the following subsections:

- Printer
- Barcode reader
- ErgoSens
- Foot switch

Printer

Navigation: Balance menu > Settings > Devices / Printers > Printer

Printer settings

Parameter	Description	Values
Printer category	Defines the type of the printer. Strip printer: to print weighing results on strip paper Label printer: to print weighing results on labels	Strip printer Label printer*
Device	Allows to activate or deactivate the device.	Activated* Deactivated
Line end	Defines the line end character for printing. The values set here have to match the printer settings. This setting is only available for strip printers.	<CR> <LF>* <CR> <LF>
Character set	Defines the communication specific character code. The values set here have to match the printer settings. This setting is only available for strip printers.	ANSI/WIN IBM/DOS UTF8*

* Factory setting

Barcode reader

Navigation: Balance menu > Settings > Devices / Printers > Barcode reader

Once connected to a USB port of the balance, the device is automatically recognized. The settings can be consulted here.

ErgoSens

Navigation: Balance menu > Settings > Devices / Printers > ErgoSens

Parameter	Description	Values
Function	Defines which function is to be executed when triggering the device.	None* Zero Tare Add result

* Factory setting

Foot switch

Navigation: Balance menu > Settings > Devices / Printers > Foot switch

Parameter	Description	Values
Function	Defines which function is to be executed when triggering the device.	None* Zero Tare Add result

* Factory setting

See also

- Printer ▶ Page 53
- Barcode reader ▶ Page 57
- Foot switch and ErgoSens ▶ Page 58

6.1.4.4 LabX / Services

Several services are available to communicate with the balance: **LabX service**, **MT-SICS service**, or **Web service**. Note that only one service can be enabled at any given time.

To enable communication between LabX and instruments, the appropriate settings on the instruments must correspond with the settings in LabX. LabX synchronizes the date and time on the instruments with the LabX Server each time a connection is made and each time a task is started. When an instrument is connected, the user interface language on the connected instrument is changed to the language currently installed on the LabX installation.

Navigation: Balance menu > Settings > LabX / Services

Parameter	Description	Values
LabX service	Inactive: No connection to LabX will be established. Network: A network connection to LabX will be established on startup. The Port must be specified. USB: A USB connection to LabX will be established on startup.	Inactive* Network USB
MT-SICS service	Inactive: No MT-SICS port will be opened. Network: An MT-SICS network port will be opened on startup. The Port must be specified. USB: An MT-SICS USB port will be opened on startup.	Inactive* Network USB
Web service	If set to Active , a network port will be opened on startup. Use the menu Web service configuration to configure the service. The complete Web service documentation is available online: www.mt.com/labweighing-software-download .	Inactive* Active

* Factory setting

See also

- LabX service ▶ Page 59
- MT-SICS service ▶ Page 60
- Web service ▶ Page 62

6.1.4.5 Printing the settings

Navigation: Balance menu > Settings > More

When all the balance settings are configured, you can print the complete list to archive the information.

- To print the balance settings, tap **Print the settings**.
 - ➔ The complete balance settings are printed.

6.1.5 Maintenance

Navigation: Balance menu > Maintenance

The section **Maintenance** is divided into the following subsections:

- Import / Export
- Software update
- Reset
- Service menu

See also

- Data management ▶ Page 63
- Software update ▶ Page 137
- Resetting the balance ▶ Page 68

6.1.5.1 Service menu

Navigation: Balance menu > Maintenance > Service menu

Icon	Name	Description
 	Device errors	<p>Tap to display the code of an error. This error code can be useful in your communication with METTLER TOLEDO when troubleshooting your device. The icon depends on the severity of the error: critical error, warning, or information.</p> <p>The icons of device errors only appear when an error with an error code is ongoing on the device.</p>
	Show adjustment state	<p>Tap to open information about:</p> <ul style="list-style-type: none"> • Prescaler • Temperature compensation • Production linearization • Standard calibration • Production calibration • User linearization • User calibration
	Save support file	Tap to save support file (all relevant information to an error) on a USB storage device to send it to a METTLER TOLEDO representative.
	Import log configuration	<p>A log configuration file can be provided by METTLER TOLEDO to allow a more comprehensive collection of balance parameters to be stored in the support file. This is only used for troubleshooting purposes.</p> <p>Tap to import the log configuration from a USB storage device so that the enhanced list of parameters can be exported and sent to a METTLER TOLEDO representative.</p>
	Perform initial zero	<p>Tap to perform an initial zero of the balance. This can be useful when using accessories whose weight exceeds the zeroing range of the balance, for example a density kit.</p> <p>This function is only available for approved balances.</p>

6.2 Weighing methods settings

6.2.1 Settings: method "General weighing"

In this section, the settings of the methods **General weighing** and **General weighing (itemized)** are described. Settings can be edited for a newly created method or an already existing method.

Navigation: Methods > Methods list > my general weighing > Edit

The settings of the method **General weighing** are grouped as follows:

- **General**
- **ID format**
- **Weighing**
- **Weighing item**, only available for the method **General weighing**
- **Weighing items**, only available for the method **General weighing (itemized)**
- **Automation**
- **Print / Export**

See also

[Creating a method "General weighing" ▶ Page 36](#)

[Editing a method ▶ Page 43](#)

6.2.1.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method.	Text (1...22 characters)
Comment	The method can be described with a comment.	Text (0...128 characters)
Lock method	Locks the method to prevent further editing.	Active Inactive*

* Factory setting

6.2.1.2 ID format

Task IDs

Parameter	Description	Values
Number of task IDs	Defines the number of task IDs. If the Number of task IDs is larger than 0, the settings Task ID , Task description and Prefix/Default value are available for every single task ID.	0 1* 2

Task ID 1	Defines the naming type of the task ID. Manual with default: The value of the task ID can be entered manually at method execution time. Automatic timestamp: The system provides a value created from a prefix with the current date and time appended.	Manual with default* Automatic timestamp
Task description	Allows to define a label for each task ID field.	Text (0...32 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method. This setting is only available when the corresponding Task ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the task ID. This setting is only available if the corresponding Task ID is set to Automatic timestamp .	Text (0...32 characters)

* Factory setting

Result IDs

Parameter	Description	Values
Number of result IDs	Defines the number of result IDs. If the Number of result IDs is larger than 0, the settings Result ID , Result description and Prefix/Default value are available for every single result ID.	0 1* 2
Result ID 1	Defines the naming type of the result ID. Manual with default: The value of the result ID can be entered manually at method execution time. Automatic counter: The system provides a value created from a Prefix to which is appended a unique number (counter).	Manual with default* Automatic counter
Result description	Allows to define a label for each result ID.	Text (0...32 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method. This setting is only available when the corresponding Result ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the result ID. This setting is only available if the corresponding Result ID is set to Automatic counter .	Text (0...32 characters)

* Factory setting

6.2.1.3 Weighing

Custom unit

When the parameter **Define custom unit** is activated, additional parameters can be defined.

Parameter	Description	Values
Define custom unit	With this option activated, a specific weighing unit can be defined. This allows calculations, e.g., surfaces or volumes, to be carried out directly during the determination of the weighing result. If a custom unit is defined, this unit is added to the list of available units throughout the method.	Active Inactive*
Name	Defines the name of the custom unit.	Text (0...6 characters)

Formula	Defines how subsequently defined value for Factor is calculated. There are 2 formulae available: Multiplicative : Multiplies the net weight by the factor. Divisive : The factor is divided by the net weight. The formula can be used, for example, to simultaneously take into account a known error factor while weighing.	Multiplicative* Divisive
Factor	Defines the factor with which the effective weighing result (net weight) is calculated via the previously selected Formula .	Numeric
Display readability	Defines the formatting for the weighing result. Example: A setting of "0.05" defines two places after the decimal point with rounding to 5. A determined result of 123.4777 is consequently displayed as 123.50. This function can only be used to reduce the resolution of the weighing result. No value must therefore be entered that exceeds the maximum balance resolution. Values that are too small are automatically rounded off.	Numeric

* Factory setting

Weighing settings

Parameter	Description	Values
Tolerance profile	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Tolerance profiles are created by the user for specific balances and applications.
Weight capture mode	Defines the behavior when the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. Stable : The system waits for a stable weight. Immediate : The system does not wait for a stable weight. The system waits for the defined Weight capture delay , then the weight value from the weight stream is captured. Dynamic : After a fix delay of 3 s, the balance calculates the weight as the average of a number of weighing values over a defined duration (Weight capture duration). When set to Dynamic , a reduced number of Automation features is available.	Stable* Immediate Dynamic
Weight capture delay	Defines the time in seconds the balance waits for capturing the weight after the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. This setting is only available when the Weight capture mode is set to Immediate or Dynamic . For Dynamic , the value is set to 3 seconds and cannot be edited.	Numeric (5 seconds* 0...60 seconds)
Weight capture duration	Defines the time during which the weight is captured and averaged. This setting is only available when the Weight capture mode is set to Dynamic .	Numeric (10 s* 3...120 s)

* Factory setting

Statistics

Parameter	Description	Values
Activate statistics	<p>If Activate statistics is set to Active, the following statistics will be calculated:</p> <p>Count: Number of items used for the statistics</p> <p>Sum: sum of all value (decimal places and unit according to the method settings)</p> <p>Minimum: smallest value (decimal places and unit according to the method settings)</p> <p>Maximum: largest value (decimal places and unit according to the method setting)</p> <p>Range: difference between the largest and smallest values (decimal places and unit according to the method settings)</p> <p>Average: The values are summed up and divided by the number of values, rounded to 1 digit more than the configured decimal places in the associated tolerance profile (unit according to the method settings).</p> <p>Standard deviation: standard deviation rounded to 1 digit more than the configured decimal places in the associated tolerance profile (unit according to the method settings)</p> <p>Relative standard deviation: relative standard deviation (rounded to 2 decimal places, in %)</p> <p>The statistical values are calculated and displayed as soon as a result is added or updated.</p>	Active Inactive*

* Factory setting

Electrostatic

Parameter	Description	Values
Ionizer	Defines whether the ionizer is activated/deactivated.	Active Inactive*

* Factory setting

See also

[Creating a method "General weighing"](#) ▶ Page 36

6.2.1.4 Weighing item / Weighing items

A target weight with tolerance limits can be defined for the method. The method **General weighing** includes a single item in **Weighing item**, whereas several items can be defined for the method **General weighing (itemized)** in **Weighing items**.

Parameter	Description	Values
Sample ID	<p>Defines the name of the sample.</p> <p>This setting is only available for methods containing several weighing items (itemized).</p>	Text (0...32 characters)
Unit	Defines the unit of the weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
-Tolerance	<p>Defines the lower tolerance limit.</p> <p>This setting is only available if a Target weight is defined.</p>	Numeric

+Tolerance	Defines the upper tolerance limit. This setting is only available if a Target weight is defined.	Numeric
------------	--	---------

See also

 Creating a method "General weighing" ▶ Page 36


 Using methods with multiple weighing items (itemized) ▶ Page 43


6.2.1.5 Automation

Parameter	Description	Values
Barcode data target	<p>If a barcode reader is connected to the balance, this option defines how the data is to be processed.</p> <p>Keyboard Input: The data is written in the currently open input window. If no input window is open, the data is ignored.</p> <p>Target weight value: The barcode data is interpreted as a value for the target weight.</p> <p>Task ID 1: The received barcode data is treated as identification text for this task ID.</p> <p>Result ID 1: The received barcode data is treated as identification text for this result ID.</p> <p>The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.</p> <p>Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.</p>	Keyboard Input* Target weight value Task ID 1 Result ID 1 ...

* Factory setting

Weighing automation

Parameter	Description	Values
Automatic zero	<p>Active: the balance is automatically zeroed when the weight falls below a predefined threshold.</p> <p>This setting is not available for approved balances.</p>	Active Inactive*
Automatic zero threshold	<p>Defines the threshold of the Automatic zero.</p> <p>This setting is only available if Automatic zero is set to Active.</p>	Numeric
Tare Mode	<p>Defines the tare mode.</p> <p>None: No automatic tare.</p> <p>Automatic tare: The balance stores automatically the first stable weight as the tare weight.</p> <p>Preset tare: Allows you to enter manually a numerical entry of a fixed tare weight.</p>	None* Automatic tare Preset tare
Automatic tare threshold	<p>Defines the threshold of the option Tare Mode.</p> <p>This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.</p> <p>Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button  subsequently pressed. The applied weight is directly taken over as a limit.</p> <p>This setting is only available if Tare Mode is set to Automatic tare.</p>	Numeric

Preset tare value	<p>Defines a weight value for the pretare function.</p> <p>Instead of entering the value, the respective tare container can be placed on the weighing pan and the button  subsequently pressed. The weight is directly taken over as pretare value.</p> <p>This setting is only available if Tare Mode is set to Preset tare.</p>	Numeric
Automatic result	<p>Automatically generates a weighing result after a threshold is reached.</p> <p>None: No automatic result will be generated.</p> <p>With sample tare: After a weight value that reached the threshold is being removed from the weighing pan, the balance is being tared.</p> <p>Without sample tare: After a weight value that reached the threshold is being removed from the weighing pan, the balance is not being tared.</p>	None With sample tare* Without sample tare
Automatic result threshold	<p>Defines the threshold of the Automatic result.</p> <p>The result is automatically added to the Results list only if the weight of the sample is larger than the defined threshold.</p> <p>This setting is only available if Automatic result is set to Active.</p>	Numeric
Weight trigger	<p>Defines the behaviour of the Automatic result threshold.</p> <p>Exceeding: The weighing result is generated when the weight exceeds the defined threshold.</p> <p>Falling below: The weighing result is generated when the weight falls below the defined threshold.</p> <p>This setting is only available if Automatic result is set to Without sample tare.</p>	Exceeding* Falling below
Automatic tare after result	<p>If set to Active, the balance is automatically tared when a result is added to the Results list.</p>	Active Inactive*
Automatic task completion	<p>Active: the balance automatically completes a running task after the result of the last weighing item has been added to the Results list.</p> <p>This setting is only available if the method is using multiple weighing items.</p>	Active Inactive*

* Factory setting

See also

 [Creating a method "General weighing" ▶ Page 36](#)

6.2.1.6 Print / Export

Parameter	Description	Values
Strip printout and data export	<p>Defines the content of the printout and/or export, as well as which printing/exporting actions are performed automatically when the task is complete.</p> <p>This section contains several settings that are described in the table Strip printout and data export below.</p>	
Label printout for task	<p>Defines the template of the task label to be printed, i.e., which data is included on the label and in which format.</p> <p>This section contains several settings that are described in the table Label printout for task below.</p>	

Label printout for weighing item	Defines the template of the weighing item label to be printed, i.e., which data is included on the label and in which format. This section contains several settings that are described in the table Label printout for weighing item below.	
Label cutting	Defines if the labels should be cut after printing. Per label: Each label is cut once printed. Per task: The labels are cut when the task is complete. This setting is only relevant if the connected label printer can cut labels.	Off* Per label Per task

* Factory setting

6.2.1.6.1 Strip printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the Results list on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active Inactive*
Results export	Activates/Deactivates the automatic data export to a USB storage device when the Complete button is tapped.	Active Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add result .	Active Inactive*

* Factory setting

Strip printout template

This menu item can be used to define which information is printed by the strip printer.

Each individual parameter can be set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- To disable all check boxes at once, tap **Deselect all**.
➔ All parameters are set to **Inactive**.
- To enable all check boxes at once, tap **Select all**.
➔ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Quality information	Defines which quality information is printed.	Tolerance profile Adjustment date/time Routine test name Routine test last execution date Routine test result GWP Approved state Level state MinWeigh state

Task information	Defines which information about the task is printed.	Method name Method comment Task IDs Custom unit settings Automatic result settings Count Sum Average Minimum Maximum Range Standard deviation Relative standard deviation
Weighing item information	Defines which information about the weighing items is printed/exported.	Show excluded weighing items Result state Result IDs GWP Approved state Level state MinWeigh state Tolerance state Target and tolerances
Result detail information	Defines which information related to the result of the measurement is printed.	Weight Tare weight Gross weight Info weight Date/time Stability

6.2.1.6.2 Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric
Used template	Chooses the label template.	Available labels are shown below.

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting

6.2.1.6.3 Label printout for weighing item

Parameter	Description	Values
Automatic label printout for weighing item	When set to Active , the weighing item label is automatically printed when tapping Add result .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric
Used template	Chooses the label template.	Available labels are shown below.

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings







The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.


Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting

6.2.1.6.4 Available labels

The following label layouts can be selected:

 <p>1 2 3 4 5</p> <p>5 large fields</p>	 <p>1 2 3 4 5</p> <p>5 small fields</p>
 <p>1 2 3 4 5</p> <p>6 7 8 9 10</p> <p>10 small fields</p>	 <p>1 2 3</p> <p>1D barcode with 3 large fields</p>
 <p>1 2 3</p> <p>1D barcode with 3 small fields</p>	 <p>1 2 3</p> <p>4 5 6</p> <p>1D barcode with 6 small fields</p>



6.2.2 Settings: method "Simple formulation"

Navigation: Methods > Methods list > my simple formulation > Edit

The settings of the method **Simple formulation** are grouped as follows:

- **General**
- **Formulation**
- **ID format**
- **Weighing**
- **Weighing item**, only available for the method **Simple formulation**
- **Weighing items**, only available for the method **Simple formulation (itemized)**
- **Automation**
- **Print / Export**

See also

- [Creating a method "Simple formulation" ▶ Page 38](#)
- [Editing a method ▶ Page 43](#)

6.2.2.1 General


The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method.	Text (1...22 characters)
Comment	The method can be described with a comment.	Text (0...128 characters)

Lock method	Locks the method to prevent further editing.	Active Inactive*
-------------	--	--------------------

* Factory setting

6.2.2.2 Formulation

Parameter	Description	Values
Calculate target	<p>Defines the basis for the calculation of the target weight.</p> <p>Flask volume: Calculates the target weight according to the reference flask volume and the actual flask volume.</p> <p>Target concentration: Calculates the target weight according to the desired target concentration.</p> <p>This setting is only available for methods of the type Simple formulation (itemized).</p>	None* Flask volume Target concentration
Calculate concentration per component	<p>Calculates the concentration of the final solution.</p> <p>If Concentration unit represents a molar concentration (mol/l or mmol/l), the calculation is based on:</p> <ul style="list-style-type: none"> • Purity • Reference flask volume • Molar mass • weight of the component <p>If Concentration unit represents a mass concentration (mg/ml, mg/l, µg/ml, g/ml, or g/l), the calculation is based on:</p> <ul style="list-style-type: none"> • Purity • Reference flask volume • weight of the component <p>If Concentration unit represents a mass ratio (%), the calculation is based on:</p> <ul style="list-style-type: none"> • Purity • Reference weight • weight of the component 	Active Inactive*
Calculate amount of component	Calculates the amount of component (in mol) based on the Molar mass and weight of component.	Active Inactive*
Concentration unit	<p>Defines the concentration unit.</p> <p>This setting is only available if Calculate concentration per component is set to Active.</p>	mol/l* mmol/l mg/ml mg/l µg/ml g/ml g/l %
Reference flask volume	<p>Defines the volume of the reference flask.</p> <p>This setting is only available if Concentration unit is not set to %.</p>	Numeric (1 ml* 1...999999 ml)
Reference weight (100%)	<p>Defines the reference weight for the calculation of concentration of the component.</p> <p>Instead of entering the reference weight manually, place the reference weight on the weighing pan and tap the button . The applied weight is directly taken over as a reference weight.</p> <p>This setting is only available if Concentration unit is set to %.</p>	Depending on the capacity of the balance.

* Factory setting

Production and expiry date

Parameter	Description	Values
Production date	Defines the production date. Current date: The production date is set automatically to the date when starting the weighing task. Manual input: The production date can be entered manually when starting the weighing task.	None Current date* Manual input
Expiry date	Defines the expiry date of the substance. Period: The expiry date is set automatically when starting the weighing task (expiry date = date when starting the weighing task + number of days defined in the field Period). Manual input: The expiry date can be entered manually when starting the weighing task.	None* Period Manual input
Period	Defines the period of the expiry date. This setting is only available if Expiry date is set to Period .	Numeric (1 day* 1...9999 days)

* Factory setting

See also

[🔗](#) Creating a method "Simple formulation" ▶ Page 38

6.2.2.3 ID format

Task IDs

Parameter	Description	Values
Number of task IDs	Defines the number of task IDs. If the Number of task IDs is larger than 0, the settings Task ID , Task description and Prefix/Default value are available for every single task ID.	0 1* 2
Task ID 1	Defines the naming type of the task ID. Manual with default: The value of the task ID can be entered manually at method execution time. Automatic timestamp: The system provides a value created from a prefix with the current date and time appended.	Manual with default* Automatic timestamp
Task description	Allows to define a label for each task ID field.	Text (0...32 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method. This setting is only available when the corresponding Task ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the task ID. This setting is only available is the corresponding Task ID is set to Automatic timestamp .	Text (0...32 characters)

* Factory setting

Result IDs

Parameter	Description	Values
Number of result IDs	Defines the number of result IDs. If the Number of result IDs is larger than 0, the settings Result ID , Result description and Prefix/Default value are available for every single result ID.	0 1* 2

Result ID 1	Defines the naming type of the result ID. Manual with default: The value of the result ID can be entered manually at method execution time. Automatic counter: The system provides a value created from a Prefix to which is appended a unique number (counter).	Manual with default* Automatic counter
Result description	Allows to define a label for each result ID.	Text (0...32 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method. This setting is only available when the corresponding Result ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the result ID. This setting is only available if the corresponding Result ID is set to Automatic counter .	Text (0...32 characters)

* Factory setting

6.2.2.4 Weighing

Weighing settings

Parameter	Description	Values
Tolerance profile	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Tolerance profiles are created by the user for specific balances and applications.

Electrostatic

Parameter	Description	Values
Ionizer	Defines whether the ionizer is activated/deactivated.	Active Inactive*

* Factory setting

See also

 [Creating a method "Simple formulation" ▶ Page 38](#)

6.2.2.5 Weighing item

A target weight with tolerance limits can be defined for the method. The method **Simple formulation** includes a single item in **Weighing item**, whereas several items can be defined for the method **Simple formulation (itemized)** in **Weighing items**.

Initial values for weighing

Parameter	Description	Values
Molar mass	Defines the molar mass of the component. The molar mass of an ion is calculated by adding the atomic weight of the individual atoms the ion is composed of. This setting is available if Calculate amount of component is set to Active or if the Concentration unit is expressed in molar concentration.	Numeric (1...10000 g/mol)
Purity	To define the purity of the component. This setting is only available if Calculate concentration per component or Calculate amount of component is set to Active .	Numeric (100%* 0.001...100%)
Unit	Defines the unit of the weighing result.	The available units depend on the balance model.

Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
-Tolerance	Defines the lower tolerance limit. This setting is only available if a Target weight is defined.	Numeric
+Tolerance	Defines the upper tolerance limit. This setting is only available if a Target weight is defined.	Numeric

* Factory setting

See also

 [Creating a method "Simple formulation" ▶ Page 38](#)

6.2.2.6 Weighing items

This section is only available for the method **Simple formulation (itemized)**.

Parameter	Description	Values
Component ID	Defines the name of the component.	Text (0...32 characters)
Molar mass	Defines the molar mass of the component. The molar mass of an ion is calculated by adding the atomic weight of the individual atoms the ion is composed of. This setting is available if Calculate amount of component is set to Active or if the Concentration unit is expressed in molar concentration.	Numeric (1...10000 g/mol)
Purity	To define the purity of the component. This setting is only available if Calculate concentration per component or Calculate amount of component is set to Active .	Numeric (100%* 0.001...100%)
Unit	Defines the unit of the weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight of the component. If Calculate target is set to Target concentration , the Target weight is calculated and cannot be edited manually.	Numeric
Target concentration	Defines the target concentration of the component. This setting is only available if Calculate target is set to Target concentration .	Numeric (0% 0.001...100%)
-Tolerance	Defines the lower tolerance limit. This setting is only available if a Target weight or Target concentration is defined.	Numeric
+Tolerance	Defines the upper tolerance limit. This setting is only available if a Target weight or Target concentration is defined.	Numeric

* Factory setting

See also

 [Creating a method "Simple formulation" ▶ Page 38](#)



 [Using methods with multiple weighing items \(itemized\) ▶ Page 43](#)

6.2.2.7 Automation

Parameter	Description	Values
Barcode data target	<p>If a barcode reader is connected to the balance, this option defines how the data is to be processed.</p> <p>Keyboard Input: The data is written in the currently open input window. If no input window is open, the data is ignored.</p> <p>Target weight value: The barcode data is interpreted as a value for the target weight.</p> <p>Task ID 1: The received barcode data is treated as identification text for this task ID.</p> <p>Result ID 1: The received barcode data is treated as identification text for this result ID.</p> <p>The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.</p> <p>Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.</p>	Keyboard Input* Target weight value Task ID 1 Result ID 1 ...

* Factory setting

Weighing automation

Parameter	Description	Values
Automatic zero	<p>Active: the balance is automatically zeroed when the weight falls below a predefined threshold.</p> <p>This setting is not available for approved balances.</p>	Active Inactive*
Automatic zero threshold	<p>Defines the threshold of the Automatic zero.</p> <p>This setting is only available if Automatic zero is set to Active.</p>	Numeric
Tare Mode	<p>Defines the tare mode.</p> <p>None: No automatic tare.</p> <p>Automatic tare: The balance stores automatically the first stable weight as the tare weight.</p> <p>Preset tare: Allows you to enter manually a numerical entry of a fixed tare weight.</p>	None* Automatic tare Preset tare
Automatic tare threshold	<p>Defines the threshold of the option Tare Mode.</p> <p>This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.</p> <p>Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button  subsequently pressed. The applied weight is directly taken over as a limit.</p> <p>This setting is only available if Tare Mode is set to Automatic tare.</p>	Numeric
Preset tare value	<p>Defines a weight value for the pretare function.</p> <p>Instead of entering the value, the respective tare container can be placed on the weighing pan and the button  subsequently pressed. The weight is directly taken over as pretare value.</p> <p>This setting is only available if Tare Mode is set to Preset tare.</p>	Numeric
Automatic tare after result	<p>If set to Active, the balance is automatically tared when a result is added to the Results list.</p>	Active Inactive*

Automatic task completion	Active: the balance automatically completes a running task after the result of the last weighing item has been added to the Results list . This setting is only available if the method is using multiple weighing items.	Active Inactive*
---------------------------	--	--------------------

* Factory setting

See also

 [Creating a method "Simple formulation" ▶ Page 38](#)

6.2.2.8 Print / Export

Parameter	Description	Values
Strip printout and data export	Defines the content of the printout and/or export, as well as which printing/exporting actions are performed automatically when the task is complete. This section contains several settings that are described in the table Strip printout and data export below.	
Label printout for task	Defines the template of the task label to be printed, i.e., which data is included on the label and in which format. This section contains several settings that are described in the table Label printout for task below.	
Label printout for weighing item	Defines the template of the weighing item label to be printed, i.e., which data is included on the label and in which format. This section contains several settings that are described in the table Label printout for weighing item below.	
Label cutting	Defines if the labels should be cut after printing. Per label: Each label is cut once printed. Per task: The labels are cut when the task is complete. This setting is only relevant if the connected label printer can cut labels.	Off* Per label Per task

* Factory setting

6.2.2.8.1 Strip printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the Results list on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active Inactive*
Results export	Activates/Deactivates the automatic data export to a USB storage device when the Complete button is tapped.	Active Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add result .	Active Inactive*


* Factory setting

Strip printout template

This menu item can be used to define which information is printed by the strip printer.

Each individual parameter can be set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- 1 To disable all check boxes at once, tap **Deselect all**.

- ➔ All parameters are set to **Inactive**.
- 2 To enable all check boxes at once, tap  **Select all**.
 - ➔ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Quality information	Defines which quality information is printed.	Tolerance profile Adjustment date/time Routine test name Routine test last execution date Routine test result GWP Approved state Level state MinWeigh state
Task information	Defines which information about the task is printed.	Method name Method comment Task ID Flask volume Reference weight Expiry date Production date
Weighing item information	Defines which information about the weighing items is printed.	Show excluded weighing items Result state Result IDs Molar mass Purity Amount of substance Concentration GWP Approved state Level state MinWeigh state Tolerance state Target and tolerances
Result detail information	Defines which information related to the result of the measurement is printed.	Weight Tare weight Gross weight Info weight Date/time Stability

6.2.2.8.2 Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric
Used template	Chooses the label template.	Available labels are shown below.

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting

6.2.2.8.3 Label printout for weighing item

Parameter	Description	Values
Automatic label printout for weighing item	When set to Active , the weighing item label is automatically printed when tapping Add result .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric
Used template	Chooses the label template.	Available labels are shown below.

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings











The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting


6.2.2.8.4 Available labels







The following label layouts can be selected:

 <p>1 2 3 4 5</p> <p>5 large fields</p>	 <p>1 2 3 4 5</p> <p>5 small fields</p>
 <p>1 2 3 4 5</p> <p>6 7 8 9 10</p> <p>10 small fields</p>	 <p>1 2 3</p> <p>1D barcode with 3 large fields</p>
 <p>1 2 3</p> <p>1D barcode with 3 small fields</p>	 <p>1 2 3</p> <p>4 5 6</p> <p>1D barcode with 6 small fields</p>
 <p>1 2 3 4 5</p> <p>2D barcode with 5 large fields</p>	 <p>1 2 3 4 5</p> <p>2D barcode with 5 small fields</p>
 <p>1 2 3 4 5</p> <p>6 7 8</p> <p>2D barcode with 2 large fields and 6 small fields</p>	 <p>1 2 3 4 5</p> <p>6 7 8</p> <p>2D barcode with 8 small fields</p>

6.2.3 Settings: method "Titration"

Navigation:  Methods >  Methods list >  my titration >  Edit


 Edit method - my titration

 General	Method type Titration
 ID format	Method name my titration
 Weighing	Comment <i>Enter here</i>
 Weighing item	
 Close	 Save

The settings of the method **Titration** are grouped as follows:

-  **General**
-  **ID format**
-  **Weighing**
-  **Weighing item**
-  **Automation**
-  **Print / Export**

See also

-  [Creating a method "Titration" ▶ Page 39](#)
-  [Editing a method ▶ Page 43](#)

6.2.3.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method.	Text (1...22 characters)
Comment	The method can be described with a comment.	Text (0...128 characters)
Lock method	Locks the method to prevent further editing.	Active Inactive*

* Factory setting

6.2.3.2 ID format

Task IDs

Parameter	Description	Values
Number of task IDs	Defines the number of task IDs. If the Number of task IDs is larger than 0, the settings Task ID , Task description and Prefix/Default value are available for every single task ID.	0 1* 2
Task ID 1	Defines the naming type of the task ID. Manual with default: The value of the task ID can be entered manually at method execution time. Automatic timestamp: The system provides a value created from a prefix with the current date and time appended.	Manual with default* Automatic timestamp
Task description	Allows to define a label for each task ID field.	Text (0...32 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method. This setting is only available when the corresponding Task ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the task ID. This setting is only available is the corresponding Task ID is set to Automatic timestamp .	Text (0...32 characters)

* Factory setting

Result IDs

Parameter	Description	Values
Number of result IDs	Defines the number of result IDs. If the Number of result IDs is larger than 0, the settings Result ID , Result description and Prefix/Default value are available for every single result ID.	0 1* 2
Result ID 1	Defines the naming type of the result ID. Manual with default: The value of the result ID can be entered manually at method execution time. Automatic counter: The system provides a value created from a Prefix to which is appended a unique number (counter).	Manual with default* Automatic counter
Result description	Allows to define a label for each result ID.	Text (0...32 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method. This setting is only available when the corresponding Result ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the result ID. This setting is only available if the corresponding Result ID is set to Automatic counter .	Text (0...32 characters)

* Factory setting

6.2.3.3 Weighing

Weighing settings

Parameter	Description	Values
Tolerance profile	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Tolerance profiles are created by the user for specific balances and applications.
Weight capture mode	Defines the behavior when the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. Stable: The system waits for a stable weight. Immediate: The system doesn't wait for a stable weight. The system waits for the defined amount of seconds (Weight capture delay). After the weight capture delay, the weight value from the weight stream is captured.	Stable* Immediate
Weight capture delay	Defines the time in seconds the balance waits for capturing the weight after the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. This setting is only available if Weight capture mode is set to Immediate .	Numeric (5 seconds* 0...60 seconds)

* Factory setting

Electrostatic

Parameter	Description	Values
Ionizer	Defines whether the ionizer is activated/deactivated.	Active Inactive*

* Factory setting

See also

[Creating a method "Titration"](#) ▶ Page 39

6.2.3.4 Weighing item

Initial values for weighing

Parameter	Description	Values
Unit	Defines the unit of the weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
-Tolerance	Defines the lower tolerance limit. This setting is only available if a Target weight is defined.	Numeric
+Tolerance	Defines the upper tolerance limit. This setting is only available if a Target weight is defined.	Numeric



6.2.3.5 Automation

Parameter	Description	Values
Barcode data target	<p>If a barcode reader is connected to the balance, this option defines how the data is to be processed.</p> <p>Keyboard Input: The data is written in the currently open input window. If no input window is open, the data is ignored.</p> <p>Target weight value: The barcode data is interpreted as a value for the target weight.</p> <p>Task ID 1: The received barcode data is treated as identification text for this task ID.</p> <p>Result ID 1: The received barcode data is treated as identification text for this result ID.</p> <p>The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.</p> <p>Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.</p>	Keyboard Input* Target weight value Task ID 1 Result ID 1 ...

* Factory setting

Weighing automation

Parameter	Description	Values
Automatic zero	<p>Active: the balance is automatically zeroed when the weight falls below a predefined threshold.</p> <p>This setting is not available for approved balances.</p>	Active Inactive*
Automatic zero threshold	<p>Defines the threshold of the Automatic zero.</p> <p>This setting is only available if Automatic zero is set to Active.</p>	Numeric
Tare Mode	<p>Defines the tare mode.</p> <p>None: No automatic tare.</p> <p>Automatic tare: The balance stores automatically the first stable weight as the tare weight.</p> <p>Preset tare: Allows you to enter manually a numerical entry of a fixed tare weight.</p>	None* Automatic tare Preset tare

Automatic tare threshold	<p>Defines the threshold of the option Tare Mode.</p> <p>This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.</p> <p>Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button  subsequently pressed. The applied weight is directly taken over as a limit.</p> <p>This setting is only available if Tare Mode is set to Automatic tare.</p>	Numeric
Preset tare value	<p>Defines a weight value for the pretare function.</p> <p>Instead of entering the value, the respective tare container can be placed on the weighing pan and the button  subsequently pressed. The weight is directly taken over as pretare value.</p> <p>This setting is only available if Tare Mode is set to Preset tare.</p>	Numeric
Automatic result	<p>Automatically generates a weighing result after a threshold is reached.</p> <p>None: No automatic result will be generated.</p> <p>Without sample tare: After a weight value that reached the threshold is being removed from the weighing pan, the balance is not being tared.</p>	None* Without sample tare
Automatic result threshold	<p>Defines the threshold of the Automatic result.</p> <p>The result is automatically added to the Results list only if the weight of the sample is larger than the defined threshold.</p> <p>This setting is only available if Automatic result is set to Active.</p>	Numeric
Weight trigger	<p>Defines the behaviour of the Automatic result threshold.</p> <p>Exceeding: The weighing result is generated when the weight exceeds the defined threshold.</p> <p>Falling below: The weighing result is generated when the weight falls below the defined threshold.</p> <p>This setting is only available if Automatic result is set to Without sample tare.</p>	Exceeding* Falling below
Automatic tare after result	<p>If set to Active, the balance is automatically tared when a result is added to the Results list.</p>	Active Inactive*

* Factory setting

See also

 [Creating a method "Titration" ▶ Page 39](#)

6.2.3.6 Print / Export

Parameter	Description	Values
Strip printout and data export	<p>Defines the content of the printout and/or export, as well as which printing/exporting actions are performed automatically when the task is complete.</p> <p>This section contains several settings that are described in the table Strip printout and data export below.</p>	
Label printout for task	<p>Defines the template of the task label to be printed, i.e., which data is included on the label and in which format.</p> <p>This section contains several settings that are described in the table Label printout for task below.</p>	

Label printout for weighing item	Defines the template of the weighing item label to be printed, i.e., which data is included on the label and in which format. This section contains several settings that are described in the table Label printout for weighing item below.	
Label cutting	Defines if the labels should be cut after printing. Per label: Each label is cut once printed. Per task: The labels are cut when the task is complete. This setting is only relevant if the connected label printer can cut labels.	Off* Per label Per task

* Factory setting

6.2.3.6.1 Strip printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the Results list on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active Inactive*
Results export	Activates/Deactivates the automatic data export to a USB storage device when the Complete button is tapped.	Active Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add result .	Active Inactive*

* Factory setting

Strip printout template

This menu item can be used to define which information is printed by the strip printer.

Each individual parameter can be set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- To disable all check boxes at once, tap **Deselect all**.
➔ All parameters are set to **Inactive**.
- To enable all check boxes at once, tap **Select all**.
➔ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Quality information	Defines which quality information is printed.	Tolerance profile Adjustment date/time Routine test name Routine test last execution date Routine test result GWP Approved state Level state MinWeigh state

Task information	Defines which information about the task is printed.	Method name Method comment Task IDs Automatic result settings
Weighing item information	Defines which information about the weighing items is printed.	Show excluded weighing items Result state Result IDs Density Correction factor GWP Approved state Level state MinWeigh state Tolerance state Target and tolerances
Result detail information	Defines which information related to the result of the measurement is printed.	Weight Tare weight Gross weight Info weight Date/time Stability

6.2.3.6.2 Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric
Used template	Chooses the label template.	Available labels are shown below.

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting

6.2.3.6.3 Label printout for weighing item

Parameter	Description	Values
Automatic label printout for weighing item	When set to Active , the weighing item label is automatically printed when tapping Add result .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric

Used template	Chooses the label template.	Available labels are shown below.
---------------	-----------------------------	-----------------------------------

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings









The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.


Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting

6.2.3.6.4 Available labels

The following label layouts can be selected:

 <p>1 2 3 4 5</p> <p>5 large fields</p>	 <p>1 2 3 4 5</p> <p>5 small fields</p>
 <p>1 2 3 4 5 6 7 8 9 10</p> <p>10 small fields</p>	 <p>1 2 3</p> <p>1D barcode with 3 large fields</p>
 <p>1 2 3</p> <p>1D barcode with 3 small fields</p>	 <p>1 2 3 4 5 6</p> <p>1D barcode with 6 small fields</p>
 <p>1 2 3 4 5</p> <p>2D barcode with 5 large fields</p>	 <p>1 2 3 4 5</p> <p>2D barcode with 5 small fields</p>



6.2.4 Settings: method "Density determination"

Navigation: Methods > Methods list > my density > Edit

The settings of the method **Density determination** are grouped as follows:

- **General**
- **Density**
- **ID format**
- **Weighing**
- **Weighing item**
- **Automation**
- **Print / Export**

See also

- [Creating a method "Density determination" ▶ Page 40](#)
- [Editing a method ▶ Page 43](#)

6.2.4.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method.	Text (1...22 characters)
Comment	The method can be described with a comment.	Text (0...128 characters)
Lock method	Locks the method to prevent further editing.	Active Inactive*

* Factory setting

6.2.4.2 Density

The **Determination type** is defined in the wizard while creating the method and cannot be changed. If another **Determination type** is required, a new method must be created. All settings for all types of **Density determination** are described here.

Parameter	Description	Values
Determination type	Defines the type of density determination measurement. Liquid (pycnometer) : Determines the density of a liquid in a glass vessel, such as a pycnometer. Liquid (sinker) : Determines the density of a liquid. Solid : Determines the density of a solid with the help of a density kit.	Liquid (pycnometer) Liquid (sinker) Solid*
Density unit	Defines the unit to be used for density determination. g/cm³ = grams per cm ³ kg/m³ = kilograms per m ³ g/l = grams per liter	g/cm ³ * kg/m ³ g/l
Density value decimal places	Defines the number of decimal places with which the density is displayed and saved.	1 2 3* 4 5
Air density compensation	Defines the correction factor for force calibration. Active : the density determination result is corrected by the force calibration correction factor and mean air density. Inactive : no correction is applied.	Active* Inactive

* Factory setting

See also

[Creating a method "Density determination"](#) ► Page 40

6.2.4.3 ID format

Task IDs

Parameter	Description	Values
Number of task IDs	Defines the number of task IDs. If the Number of task IDs is larger than 0, the settings Task ID , Task description and Prefix/Default value are available for every single task ID.	0 1* 2
Task ID 1	Defines the naming type of the task ID. Manual with default : The value of the task ID can be entered manually at method execution time. Automatic timestamp : The system provides a value created from a prefix with the current date and time appended.	Manual with default* Automatic timestamp
Task description	Allows to define a label for each task ID field.	Text (0...32 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method. This setting is only available when the corresponding Task ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the task ID. This setting is only available is the corresponding Task ID is set to Automatic timestamp .	Text (0...32 characters)

* Factory setting

Result IDs

Parameter	Description	Values
Number of result IDs	Defines the number of result IDs. If the Number of result IDs is larger than 0, the settings Result ID , Result description and Prefix/Default value are available for every single result ID.	0 1* 2
Result ID 1	Defines the naming type of the result ID. Manual with default: The value of the result ID can be entered manually at method execution time. Automatic counter: The system provides a value created from a Prefix to which is appended a unique number (counter).	Manual with default* Automatic counter
Result description	Allows to define a label for each result ID.	Text (0...32 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method. This setting is only available when the corresponding Result ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the result ID. This setting is only available if the corresponding Result ID is set to Automatic counter .	Text (0...32 characters)

* Factory setting

6.2.4.4 Weighing

Weighing settings

Parameter	Description	Values
Tolerance profile	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Tolerance profiles are created by the user for specific balances and applications.
Weight capture mode	Defines the behavior when the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. Stable: The system waits for a stable weight. Immediate: The system doesn't wait for a stable weight. The system waits for the defined amount of seconds (Weight capture delay). After the weight capture delay, the weight value from the weight stream is captured.	Stable* Immediate
Weight capture delay	Defines the time in seconds the balance waits for capturing the weight after the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. This setting is only available if Weight capture mode is set to Immediate .	Numeric (5 seconds* 0...60 seconds)

* Factory setting

Statistics

Parameter	Description	Values
Activate statistics	<p>If Activate statistics is set to Active, the following statistics will be calculated:</p> <p>Count: Number of items used for the statistics</p> <p>Sum: sum of all value (decimal places and unit according to the method settings)</p> <p>Minimum: smallest value (decimal places and unit according to the method settings)</p> <p>Maximum: largest value (decimal places and unit according to the method setting)</p> <p>Range: difference between the largest and smallest values (decimal places and unit according to the method settings)</p> <p>Average: The values are summed up and divided by the number of values, rounded to 1 digit more than the configured decimal places in the associated tolerance profile (unit according to the method settings).</p> <p>Standard deviation: standard deviation rounded to 1 digit more than the configured decimal places in the associated tolerance profile (unit according to the method settings)</p> <p>Relative standard deviation: relative standard deviation (rounded to 2 decimal places, in %)</p> <p>The statistical values are calculated and displayed as soon as a result is added or updated.</p>	Active Inactive*

* Factory setting

6.2.4.5 Weighing item

The **Weighing item** settings are different for the three types of **Density determination**. The settings for **Initial values for weighing** are presented separately for each **Determination type**.

Initial values for weighing – Determination type: Solid

Parameter	Description	Values
Unit	Defines the unit of the weighing result.	The available units depend on the balance model.
Temperature	Defines the temperature of the auxiliary liquid (distilled water or custom).	Numeric (10°C...30.9°C)
Aux. liquid	Defines the type of auxiliary liquid used for the determination of the density of a solid.	Distilled water* Custom
Aux. liquid name	Defines the name of the custom auxiliary liquid. This setting is only available if Aux. liquid is set to Custom .	Text (0...32 characters)
Aux. liquid density	Defines the density of the custom auxiliary liquid. This setting is only available if Aux. liquid is set to Custom .	Numeric (0.00001... 100 g/cm ³)

* Factory setting

Initial values for weighing – Determination type: Liquid (sinker)

Parameter	Description	Values
Unit	Defines the unit of the weighing result.	The available units depend on the balance model.

Temperature	Defines the temperature of the liquid.	Numeric (10°C...30.9°C)
Sinker volume	Defines the volume of the sinker in cm ³ .	Numeric (0.0001...500 cm ³)

Initial values for weighing – Determination type: Liquid (pycnometer)

Parameter	Description	Values
Unit	Defines the unit of the weighing result.	The available units depend on the balance model.
Temperature	Defines the temperature of the liquid.	Numeric (10°C...30.9°C)
Pycnometer volume	Defines volume of the pycnometer in cm ³ .	Numeric (0.001...10000 cm ³)
Pycnometer weight	Defines the weight of the pycnometer.	Numeric

See also

 Creating a method "Density determination" ▶ Page 40

6.2.4.6 Automation

Parameter	Description	Values
Barcode data target	<p>If a barcode reader is connected to the balance, this option defines how the data is to be processed.</p> <p>Keyboard Input: The data is written in the currently open input window. If no input window is open, the data is ignored.</p> <p>Task ID 1: The received barcode data is treated as identification text for this task ID.</p> <p>Result ID 1: The received barcode data is treated as identification text for this result ID.</p> <p>The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.</p> <p>Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.</p>	Keyboard Input* Task ID 1 Result ID 1 ...

* Factory setting

See also

 Creating a method "Density determination" ▶ Page 40

6.2.4.7 Print / Export

Parameter	Description	Values
Strip printout and data export	<p>Defines the content of the printout and/or export, as well as which printing/exporting actions are performed automatically when the task is complete.</p> <p>This section contains several settings that are described in the table Strip printout and data export below.</p>	

6.2.4.7.1 Strip printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the Results list on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active Inactive*
Results export	Activates/Deactivates the automatic data export to a file server or USB storage device when the Complete button is tapped.	Active Inactive*

* Factory setting

Strip printout template

This menu item can be used to define which information is printed by the strip printer.

Each individual parameter can be set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- To disable all check boxes at once, tap **Deselect all**.
 - ➔ All parameters are set to **Inactive**.
- To enable all check boxes at once, tap **Select all**.
 - ➔ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Quality information	Defines which quality information is printed.	Tolerance profile Adjustment date/time Routine test name Routine test last execution date Routine test result GWP Approved state Level state MinWeigh state
Task information	Defines which information about the task is printed.	Method name Method comment Task IDs Count Average Minimum Maximum Standard deviation Relative standard deviation Type of density determination Decimal places for density weighing results Air density compensation

Weighing item information	Defines which information about the weighing items is printed.	Show excluded weighing items Result state Result IDs GWP Approved state Level state MinWeigh state Temperature Auxiliary liquid name and density Volume of sample Weight of sample in air Weight of sample in liquid
Result detail information	Defines which information related to the result of the measurement is printed.	Weight Tare weight Gross weight Info weight Date/time Stability

6.2.5 Settings: method "Piece Counting"

Navigation: Methods > Methods list > my piece counting > Edit

The settings of the method **Piece Counting** are grouped as follows:

- **General**
- **ID format**
- **Weighing**
- **Weighing item**
- **Automation**
- **Print / Export**

See also

- [Creating a method "Piece Counting" ▶ Page 42](#)
- [Editing a method ▶ Page 43](#)

6.2.5.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method.	Text (1...22 characters)
Comment	The method can be described with a comment.	Text (0...128 characters)

Lock method	Locks the method to prevent further editing.	Active Inactive*
-------------	--	--------------------

* Factory setting

6.2.5.2 ID format

Task IDs

Parameter	Description	Values
Number of task IDs	Defines the number of task IDs. If the Number of task IDs is larger than 0, the settings Task ID , Task description and Prefix/Default value are available for every single task ID.	0 1* 2
Task ID 1	Defines the naming type of the task ID. Manual with default: The value of the task ID can be entered manually at method execution time. Automatic timestamp: The system provides a value created from a prefix with the current date and time appended.	Manual with default* Automatic timestamp
Task description	Allows to define a label for each task ID field.	Text (0...32 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method. This setting is only available when the corresponding Task ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the task ID. This setting is only available is the corresponding Task ID is set to Automatic timestamp .	Text (0...32 characters)

* Factory setting

Result IDs

Parameter	Description	Values
Number of result IDs	Defines the number of result IDs. If the Number of result IDs is larger than 0, the settings Result ID , Result description and Prefix/Default value are available for every single result ID.	0 1* 2
Result ID 1	Defines the naming type of the result ID. Manual with default: The value of the result ID can be entered manually at method execution time. Automatic counter: The system provides a value created from a Prefix to which is appended a unique number (counter).	Manual with default* Automatic counter
Result description	Allows to define a label for each result ID.	Text (0...32 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method. This setting is only available when the corresponding Result ID is set to Manual with default .	Text (0...32 characters)
Prefix	Defines a prefix for the result ID. This setting is only available if the corresponding Result ID is set to Automatic counter .	Text (0...32 characters)

* Factory setting

6.2.5.3 Weighing

Weighing settings

Parameter	Description	Values
Tolerance profile	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Tolerance profiles are created by the user for specific balances and applications.
Weight capture mode	Defines the behavior when the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. Stable: The system waits for a stable weight. Immediate: The system doesn't wait for a stable weight. The system waits for the defined amount of seconds (Weight capture delay). After the weight capture delay, the weight value from the weight stream is captured.	Stable* Immediate
Weight capture delay	Defines the time in seconds the balance waits for capturing the weight after the button to add the result was tapped or the add result was triggered by the automatic weighing result creation. This setting is only available if Weight capture mode is set to Immediate .	Numeric (5 seconds* 0...60 seconds)

* Factory setting

Statistics

Parameter	Description	Values
Activate statistics	If Activate statistics is set to Active , the following statistics will be calculated: Count: Number of items used for the statistics Sum: sum of all value (decimal places and unit according to the method settings) Minimum: smallest value (decimal places and unit according to the method settings) Maximum: largest value (decimal places and unit according to the method setting) Range: difference between the largest and smallest values (decimal places and unit according to the method settings) Average: The values are summed up and divided by the number of values, rounded to 1 digit more than the configured decimal places in the associated tolerance profile (unit according to the method settings). Standard deviation: standard deviation rounded to 1 digit more than the configured decimal places in the associated tolerance profile (unit according to the method settings) Relative standard deviation: relative standard deviation (rounded to 2 decimal places, in %) The statistical values are calculated and displayed as soon as a result is added or updated.	Active Inactive*

* Factory setting

6.2.5.4 Weighing item

Initial values for weighing

Parameter	Description	Values
Reference PCS	Defines the number of items used to determine the average weight per item.	Numeric (1* 1... 10000)
Reference average weight	Defines the average weight for one piece. The average weight of one piece serves as basis for the piece counting. During task execution, the balance calculates the actual number of pieces on the weighing pan based on the measured weight and the average weight of one piece.	Numeric
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
-Tolerance	Defines the lower tolerance limit. This setting is only available if a Target weight is defined.	Numeric
+Tolerance	Defines the upper tolerance limit. This setting is only available if a Target weight is defined.	Numeric

* Factory setting

See also

[Creating a method "Piece Counting"](#) ▶ Page 42



6.2.5.5 Automation

Parameter	Description	Values
Barcode data target	<p>If a barcode reader is connected to the balance, this option defines how the data is to be processed.</p> <p>Keyboard Input: The data is written in the currently open input window. If no input window is open, the data is ignored.</p> <p>Target weight value: The barcode data is interpreted as a value for the target weight.</p> <p>Task ID 1: The received barcode data is treated as identification text for this task ID.</p> <p>Result ID 1: The received barcode data is treated as identification text for this result ID.</p> <p>The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.</p> <p>Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.</p>	Keyboard Input* Target weight value Task ID 1 Result ID 1 ...

* Factory setting

Weighing automation

Parameter	Description	Values
Automatic zero	<p>Active: the balance is automatically zeroed when the weight falls below a predefined threshold.</p> <p>This setting is not available for approved balances.</p>	Active Inactive*
Automatic zero threshold	<p>Defines the threshold of the Automatic zero.</p> <p>This setting is only available if Automatic zero is set to Active.</p>	Numeric

Tare Mode	<p>Defines the tare mode.</p> <p>None: No automatic tare.</p> <p>Automatic tare: The balance stores automatically the first stable weight as the tare weight.</p> <p>Preset tare: Allows you to enter manually a numerical entry of a fixed tare weight.</p>	None* Automatic tare Preset tare
Automatic tare threshold	<p>Defines the threshold of the option Tare Mode.</p> <p>This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.</p> <p>Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button  subsequently pressed. The applied weight is directly taken over as a limit.</p> <p>This setting is only available if Tare Mode is set to Automatic tare.</p>	Numeric
Preset tare value	<p>Defines a weight value for the pretare function.</p> <p>Instead of entering the value, the respective tare container can be placed on the weighing pan and the button  subsequently pressed. The weight is directly taken over as pretare value.</p> <p>This setting is only available if Tare Mode is set to Preset tare.</p>	Numeric
Automatic result	<p>Automatically generates a weighing result after a threshold is reached.</p> <p>None: No automatic result will be generated.</p> <p>Without sample tare: After a weight value that reached the threshold is being removed from the weighing pan, the balance is not being tared.</p>	None* Without sample tare
Automatic result threshold	<p>Defines the threshold of the Automatic result.</p> <p>The result is automatically added to the Results list only if the weight of the sample is larger than the defined threshold.</p> <p>This setting is only available if Automatic result is set to Active.</p>	Numeric
Weight trigger	<p>Defines the behaviour of the Automatic result threshold.</p> <p>Exceeding: The weighing result is generated when the weight exceeds the defined threshold.</p> <p>Falling below: The weighing result is generated when the weight falls below the defined threshold.</p> <p>This setting is only available if Automatic result is set to Without sample tare.</p>	Exceeding* Falling below
Automatic tare after result	<p>If set to Active, the balance is automatically tared when a result is added to the Results list.</p>	Active Inactive*

* Factory setting

When using **Automatic result**, make sure that the **Reference average weight** of one piece is larger than the **Automatic result threshold**.

See also

 [Creating a method "Piece Counting" ▶ Page 42](#)

6.2.5.6 Print / Export

Parameter	Description	Values
Strip printout and data export	Defines the content of the printout and/or export, as well as which printing/exporting actions are performed automatically when the task is complete. This section contains several settings that are described in the table Strip printout and data export below.	
Label printout for task	Defines the template of the task label to be printed, i.e., which data is included on the label and in which format. This section contains several settings that are described in the table Label printout for task below.	
Label printout for weighing item	Defines the template of the weighing item label to be printed, i.e., which data is included on the label and in which format. This section contains several settings that are described in the table Label printout for weighing item below.	
Label cutting	Defines if the labels should be cut after printing. Per label: Each label is cut once printed. Per task: The labels are cut when the task is complete. This setting is only relevant if the connected label printer can cut labels.	Off* Per label Per task

* Factory setting

6.2.5.6.1 Strip printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the Results list on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active Inactive*
Results export	Activates/Deactivates the automatic data export to a USB storage device when the Complete button is tapped.	Active Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add result .	Active Inactive*

* Factory setting

Strip printout template

This menu item can be used to define which information is printed by the strip printer.

Each individual parameter can be set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- To disable all check boxes at once, tap **Deselect all**.
⇒ All parameters are set to **Inactive**.
- To enable all check boxes at once, tap **Select all**.
⇒ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/time User Signature Separating lines Group titles

Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Quality information	Defines which quality information is printed.	Tolerance profile Adjustment date/time Routine test name Routine test last execution date Routine test result GWP Approved state Level state MinWeigh state
Task information	Defines which information about the task is printed.	Method name Method comment Task IDs Automatic result settings Count Sum Average Minimum Maximum Standard deviation Relative standard deviation PCS below -Tolerance PCS above +Tolerance
Weighing item information	Defines which information about the weighing items is printed.	Show excluded weighing items Result state Result IDs GWP Approved state Level state MinWeigh state Tolerance state Target and tolerances Reference PCS Reference average weight
Result detail information	Defines which information related to the result of the measurement is printed.	Weight Tare weight Gross weight Info weight Date/time Stability

6.2.5.6.2 Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric
Used template	Chooses the label template.	Available labels are shown below.

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting

6.2.5.6.3 Label printout for weighing item

Parameter	Description	Values
Automatic label printout for weighing item	When set to Active , the weighing item label is automatically printed when tapping Add result .	Active Inactive*
Copies	Defines how many copies of the label are printed.	Numeric
Used template	Chooses the label template.	Available labels are shown below.

* Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The number of label fields depends on the selected template.	Available entries depend on the method settings.

Barcode settings


The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.









Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. This setting is only available when the selected Used template contains several 2D codes.	TAB* Form feed Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

* Factory setting

6.2.5.6.4 Available labels

The following label layouts can be selected:



 <p>10 small fields</p>	 <p>1D barcode with 3 large fields</p>
 <p>1D barcode with 3 small fields</p>	 <p>1D barcode with 6 small fields</p>
 <p>2D barcode with 5 large fields</p>	 <p>2D barcode with 5 small fields</p>
 <p>2D barcode with 2 large fields and 6 small fields</p>	 <p>2D barcode with 8 small fields</p>

6.3 Test weights settings

6.3.1 Settings: individual test weight

Navigation:  Methods >  Tests >  Test weights >  my weight 1 >  Edit

Parameter	Description	Values
Test weight name	Defines the name of the test weight.	Text (1...22 characters)
Test weight ID	Defines the test weight ID.	Text (1...22 characters)
Nominal weight	Defines the approximate, rounded value of the Actual weight .	Numeric
Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM00 ASTM0 ASTM0 ASTM1 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*
Actual weight	Defines the actual weight. The actual weight is a specific weight with a specific Conventional Mass Value (CMV) from the weight calibration certificate.	Numeric
Next calibration date	Defines the next date for calibration.	Date
Certificate	If the certificate of the test weight is available, set to Active and fill in the additional information related to the certificate (see below).	Active Inactive*
Certificate ID	Defines the certificate ID. This setting is only available if Certificate ID is set to Active .	Text (1...22 characters)

Certificate date	Defines the certificate date. This setting is only available if Certificate ID is set to Active .	Date
Weight set ID	Defines the weight set ID.	Text (1...22 characters)

* Factory setting

6.3.2 Settings: combined test weight

Navigation: Methods > Tests > Test weights > my weight 1+2 > Edit

Parameter	Description	Values
Test weight name	Defines the name of the test weight.	Text (1...22 characters)
Nominal weight	Shows the sum of the nominal weights of all the individual weights included in this combined weight.	Numeric
Minimum weight class	Defines the minimum weight class according to OIML or ASTM. The customized tolerance class Own can also be selected. When choosing the weights that compose the combined weight, only the individual weights with a class better or equal to the selected Minimum weight class are shown.	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM00 ASTM0 ASTM0 ASTM1 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*
Weights	Displays a list of the available individual test weights. A total of two or three individual test weights can be selected. Only the individual weights with a class better or equal to the selected Minimum weight class are shown.	List of individual test weights

* Factory setting

6.4 Tests settings

6.4.1 Settings: Eccentricity

Navigation: Methods > Tests > my eccentricity test > Edit

1. Name and type

Parameter	Description	Values
Test type	The test type has been pre-defined and cannot be changed in this menu.	Available test types
Name	Defines the name of the test.	Text (1...22 characters)
Test activated	Enables/disables the test.	Active* Inactive
Show preparation instructions	If activated, a predefined preparatory instruction is displayed in the test sequence.	Active* Inactive
Automatic print	When activated, the test results are immediately printed on the enabled strip printer after the test result has been calculated.	Active Inactive*

* Factory setting

2. Test specification

Parameter	Description	Values
Result calculation	Select whether the nominal weight or the conventional mass value (CMV) is used for the result calculation. On nominal weight: Nominal value of a weight with a specific weight class. On actual weight (CMV): Conventional mass value (CMV) of a weight from the weight calibration certificate.	On nominal weight* On actual weight (CMV)

* Factory setting

Test point

Parameter	Description	Values
Nominal weight	Defines the nominal value of the weight that will be used for the test.	Numeric
Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM00 ASTM0 ASTM1 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*

* Factory setting

Eccentricity limits

Parameter	Description	Values
Control limit	Defines the error tolerance of a process with respect to its set value. Exceeding the Control limit is a violation of quality requirements and therefore requires a correction of the process. Result if the Control limit is exceeded: The test failed, the balance is out of specification.	Numeric
Warning limit	Defines the upper or lower limit that, if exceeded or not reached, makes more stringent process monitoring necessary. The Warning limit must be smaller than the Control limit . Result if the Warning limit is exceeded: The test is passed, but the difference is higher than expected.	Numeric

3. Test weights

A configured test weight can be selected. For information on test weights definition and settings, see [Test weights ▶ Page 45] and [Test weights settings ▶ Page 121].

4. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if a test has failed. Active: The balance will be blocked after a specified amount of failed tests. In this case, the balance cannot be used anymore until it is unblocked. If a password has been set, the password is needed to unblock the balance. See [Password protection and balance reset ▶ Page 66]. Inactive: The balance will not be blocked.	Active Inactive*

Allowed number of retries	Defines the maximum allowed retries until the balance will be blocked. This setting is only available if Block balance is set to Active .	Numeric (3* 0...9)
---------------------------	--	----------------------

* Factory setting

5. Test planning

Parameter	Description	Values
Planning type	Specifies the schedule for the test to be performed. Manually : The test is performed manually. Daily : A task is generated every day at the specified time. Weekly : A task is generated at least once a week. Additional days can be selected if required. Monthly : A task is generated every month at the specified day and time. Quarterly : A task is generated every three months at the specified time. Annually : A task is generated once a year at the specified time.	Manually* Daily Weekly Monthly Quarterly Annually
Start time	Defines the time when the test is due. This setting is only available if Planning type is not set to Manually .	Time

* Factory setting

Notification

This section does not appear when **Planning type** is set to **Manually**.

Parameter	Description	Values
(x) hours before test	Defines the number of hours before a notification informs about the upcoming planned test.	Different values depending on the selected frequency (Planning type).
Notification every (x) hours	Defines the time interval before the next notification is issued.	Different values depending on the selected frequency (Planning type).

Preferred days

This section only appears when **Planning type** is set to **Weekly**.

Parameter	Description	Values
Preferred days	Defines the preferred weekday for the execution of the test.	Monday* Tuesday* Wednesday* Thursday* Friday* Saturday Sunday

* Factory setting

Preferred day for execution

This section only appears when **Planning type** is set to **Monthly**.

Parameter	Description	Values
Day of the week	Defines the preferred day for execution of the test. If None is selected, the test will be scheduled for a month after the last execution.	None* Monday Tuesday Wednesday Thursday Friday Saturday Sunday

Week of the month	Defines on which week of the month the test is performed. This setting is only available if Day of the week is not set to None .	First* Second Third Fourth
-------------------	---	----------------------------------

* Factory setting

6. Printing

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Test summary	Defines which information about the test summary is printed.	Test type Test name Test result
Test details	Defines which test details are printed.	Test trigger Leveling at start Temperature Preparation instructions Test start (date / time) Test end (date / time) User name
Tare specification	Defines which information about the tare specification is printed. This section is only available for tests using a tare weight.	Tare name Min. tare weight
Test weight	Defines which information about the test weight is printed.	Test weight ID Weight class Nominal weight Actual weight Weight set ID Certificate ID Certificate date Next calibration date Weight type Minimum weight class Used nominal weights Used actual weights
Test limits	Defines which information about the test limits is printed.	Warning limit Control limit
Measurements / Results	Defines which information about the measurements and the results is printed.	Weight Deviation State Level state Zero / Tare Center deviation

See also

[🔗 Defining an individual test weight ▶ Page 45](#)

[🔗 Defining a combined test weight ▶ Page 45](#)

[🔗 Creating a new test ▶ Page 46](#)

6.4.2 Settings: Repeatability test

Navigation: Methods > Tests > my repeatability test > Edit

1. Name and type

Parameter	Description	Values
Test type	The test type has been pre-defined and cannot be changed in this menu.	Available test types
Name	Defines the name of the test.	Text (1...22 characters)
Test activated	Enables/disables the test.	Active* Inactive
Show preparation instructions	If activated, a predefined preparatory instruction is displayed in the test sequence.	Active* Inactive
Automatic print	When activated, the test results are immediately printed on the enabled strip printer after the test result has been calculated.	Active Inactive*

* Factory setting

2. Test specification

Parameter	Description	Values
Result calculation	Select whether the nominal weight or the conventional mass value (CMV) is used for the result calculation. On nominal weight: Nominal value of a weight with a specific weight class. On actual weight (CMV): Conventional mass value (CMV) of a weight from the weight calibration certificate.	On nominal weight* On actual weight (CMV)
Number of repetitions	Defines the number of weight measurements of a series.	Numeric (10* 2...15)

* Factory setting

Tare

This section only appears when **Test type** is set to **Repeatab. - Tare - 1 TP**.

Parameter	Description	Values
Tare name	Defines a name for the tare weight.	Text (1...22 characters)
Minimum tare weight	Defines the minimum weight for the tare container. The test is only continued if a tare container with at least this weight is placed on the balance.	Numeric

* Factory setting

Test point

Parameter	Description	Values
Nominal weight	Defines the nominal value of the weight that will be used for the test.	Numeric
Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM00 ASTM0 ASTM0 ASTM1 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*

* Factory setting

Test limits

Parameter	Description	Values
Control limit	Defines the error tolerance of a process with respect to its set value. Exceeding the Control limit is a violation of quality requirements and therefore requires a correction of the process. The minimum value is 40% of the balance readability. Result if the Control limit is exceeded: The test failed, the balance is out of specification.	Numeric
Warning limit	Defines the upper or lower limit that, if exceeded or not reached, makes more stringent process monitoring necessary. The Warning limit must be smaller than the Control limit . Result if the Warning limit is exceeded: The test is passed, but the difference is higher than expected.	Numeric

3. Test weights

A configured test weight can be selected. For information on test weights definition and settings, see [Test weights ▶ Page 45] and [Test weights settings ▶ Page 121].

4. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if a test has failed. Active: The balance will be blocked after a specified amount of failed tests. In this case, the balance cannot be used anymore until it is unblocked. If a password has been set, the password is needed to unblock the balance. See [Password protection and balance reset ▶ Page 66]. Inactive: The balance will not be blocked.	Active Inactive*
Allowed number of retries	Defines the maximum allowed retries until the balance will be blocked. This setting is only available if Block balance is set to Active .	Numeric (3* 0...9)

* Factory setting

5. Test planning

Parameter	Description	Values
Planning type	Specifies the schedule for the test to be performed. Manually: The test is performed manually. Daily: A task is generated every day at the specified time. Weekly: A task is generated at least once a week. Additional days can be selected if required. Monthly: A task is generated every month at the specified day and time. Quarterly: A task is generated every three months at the specified time. Annually: A task is generated once a year at the specified time.	Manually* Daily Weekly Monthly Quarterly Annually
Start time	Defines the time when the test is due. This setting is only available if Planning type is not set to Manually .	Time

* Factory setting

Notification

This section does not appear when **Planning type** is set to **Manually**.

Parameter	Description	Values
(x) hours before test	Defines the number of hours before a notification informs about the upcoming planned test.	Different values depending on the selected frequency (Planning type).
Notification every (x) hours	Defines the time interval before the next notification is issued.	Different values depending on the selected frequency (Planning type).

Preferred days

This section only appears when **Planning type** is set to **Weekly**.

Parameter	Description	Values
Preferred days	Defines the preferred weekday for the execution of the test.	Monday* Tuesday* Wednesday* Thursday* Friday* Saturday Sunday

* Factory setting

Preferred day for execution

This section only appears when **Planning type** is set to **Monthly**.

Parameter	Description	Values
Day of the week	Defines the preferred day for execution of the test. If None is selected, the test will be scheduled for a month after the last execution.	None* Monday Tuesday Wednesday Thursday Friday Saturday Sunday
Week of the month	Defines on which week of the month the test is performed. This setting is only available if Day of the week is not set to None .	First* Second Third Fourth

* Factory setting

6. Printing

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/ time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Test summary	Defines which information about the test summary is printed.	Test type Test name Test result Standard deviation
Test details	Defines which test details are printed.	Test trigger Leveling at start Temperature Preparation instructions Test start (date / time) Test end (date / time) User name

Tare specification	Defines which information about the tare specification is printed. This section is only available for tests using a tare weight.	Tare name Min. tare weight
Test weight	Defines which information about the test weight is printed.	Test weight ID Weight class Nominal weight Actual weight Weight set ID Certificate ID Certificate date Next calibration date Weight type Minimum weight class Used nominal weights Used actual weights
Test limits	Defines which information about the test limits is printed.	Warning limit Control limit
Measurements / Results	Defines which information about the measurements and the results is printed.	Weight State Level state Zero / Tare

See also

- [🔗 Defining an individual test weight ▶ Page 45](#)
- [🔗 Defining a combined test weight ▶ Page 45](#)
- [🔗 Creating a new test ▶ Page 46](#)

6.4.3 Settings: Sensitivity test

☰ Navigation: Methods > Tests > my sensitivity test > Edit

1. Name and type

Parameter	Description	Values
Test type	The test type has been pre-defined and cannot be changed in this menu.	Available test types
Name	Defines the name of the test.	Text (1...22 characters)
Test activated	Enables/disables the test.	Active* Inactive
Show preparation instructions	If activated, a predefined preparatory instruction is displayed in the test sequence.	Active* Inactive
Automatic print	When activated, the test results are immediately printed on the enabled strip printer after the test result has been calculated.	Active Inactive*

* Factory setting

2. Test specification

Parameter	Description	Values
Result calculation	Select whether the nominal weight or the conventional mass value (CMV) is used for the result calculation. On nominal weight: Nominal value of a weight with a specific weight class. On actual weight (CMV): Conventional mass value (CMV) of a weight from the weight calibration certificate.	On nominal weight* On actual weight (CMV)

* Factory setting

Tare

This section only appears when the option **Test type** is set to **Sensitivity - Tare - 1 TP** or **Sensitivity - Tare - 2 TP**.

Parameter	Description	Values
Tare name	Defines a name for the tare weight.	Text (1...22 characters)
Minimum tare weight	Defines the minimum weight for the tare container. The test is only continued if a tare container with at least this weight is placed on the balance.	Numeric

Test point

Depending on the selected test, the following options can be defined for one or two test points:

Parameter	Description	Values
Nominal weight	Defines the nominal value of the weight that will be used for the test.	Numeric
Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM00 ASTM0 ASTM1 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*
Control limit	Defines the error tolerance of a process with respect to its set value. Exceeding the Control limit is a violation of quality requirements and therefore requires a correction of the process. Result if the Control limit is exceeded: The test failed, the balance is out of specification.	Numeric
Warning limit	Defines the upper or lower limit that, if exceeded or not reached, makes more stringent process monitoring necessary. The Warning limit must be smaller than the Control limit . Result if the Warning limit is exceeded: The test is passed, but the difference is higher than expected.	Numeric

* Factory setting

3. Test weights

A configured test weight can be selected. For information on test weights definition and settings, see [Test weights ▶ Page 45] and [Test weights settings ▶ Page 121].

4. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if a test has failed. Active: The balance will be blocked after a specified amount of failed tests. In this case, the balance cannot be used anymore until it is unblocked. If a password has been set, the password is needed to unblock the balance. See [Password protection and balance reset ▶ Page 66]. Inactive: The balance will not be blocked.	Active Inactive*
Allowed number of retries	Defines the maximum allowed retries until the balance will be blocked. This setting is only available if Block balance is set to Active .	Numeric (3* 0...9)

* Factory setting

5. Test planning

Parameter	Description	Values
Planning type	Specifies the schedule for the test to be performed. Manually: The test is performed manually. Daily: A task is generated every day at the specified time. Weekly: A task is generated at least once a week. Additional days can be selected if required. Monthly: A task is generated every month at the specified day and time. Quarterly: A task is generated every three months at the specified time. Annually: A task is generated once a year at the specified time.	Manually* Daily Weekly Monthly Quarterly Annually
Start time	Defines the time when the test is due. This setting is only available if Planning type is not set to Manually .	Time

* Factory setting

Notification

This section does not appear when **Planning type** is set to **Manually**.

Parameter	Description	Values
(x) hours before test	Defines the number of hours before a notification informs about the upcoming planned test.	Different values depending on the selected frequency (Planning type).
Notification every (x) hours	Defines the time interval before the next notification is issued.	Different values depending on the selected frequency (Planning type).

Preferred days

This section only appears when **Planning type** is set to **Weekly**.

Parameter	Description	Values
Preferred days	Defines the preferred weekday for the execution of the test.	Monday* Tuesday* Wednesday* Thursday* Friday* Saturday Sunday

* Factory setting

Preferred day for execution

This section only appears when **Planning type** is set to **Monthly**.

Parameter	Description	Values
Day of the week	Defines the preferred day for execution of the test. If None is selected, the test will be scheduled for a month after the last execution.	None* Monday Tuesday Wednesday Thursday Friday Saturday Sunday
Week of the month	Defines on which week of the month the test is performed. This setting is only available if Day of the week is not set to None .	First* Second Third Fourth

* Factory setting

6. Printing

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Test summary	Defines which information about the test summary is printed.	Test type Test name Test result
Test details	Defines which test details are printed.	Test trigger Leveling at start Temperature Preparation instructions Test start (date / time) Test end (date / time) User name
Tare specification	Defines which information about the tare specification is printed. This section is only available for tests using a tare weight.	Tare name Min. tare weight
Test weight	Defines which information about the test weight is printed.	Test weight ID Weight class Nominal weight Actual weight Weight set ID Certificate ID Certificate date Next calibration date Weight type Minimum weight class Used nominal weights Used actual weights
Test limits	Defines which information about the test limits is printed.	Warning limit Control limit
Measurements / Results	Defines which information about the measurements and the results is printed.	Weight Deviation State Level state Zero / Tare

See also

- [🔗 Defining an individual test weight ▶ Page 45](#)
- [🔗 Defining a combined test weight ▶ Page 45](#)
- [🔗 Creating a new test ▶ Page 46](#)

6.5 Adjustments settings

≡ Navigation:  Methods >  Adjustments >  Internal adjustment >  Edit

1. Strategy

Parameter	Description	Values
Strategy	Defines the type of adjustment to be performed. When Strategy is set to No adjustment or External adjustment , no other settings are available. For approved balances, this setting is set to Internal adjustment and cannot be edited.	Internal adjustment* External adjustment No adjustment

Automatic print	When activated, the adjustment results are immediately printed on the enabled strip printer after the result has been calculated.	Active Inactive*
-----------------	---	--------------------

* Factory setting

2. Specification

Parameter	Description	Values
"As found" test	At the start of the adjustment sequence, an internal sensitivity test is automatically performed to evaluate the current status. The test results are displayed and recorded.	Active Inactive*
"As left" test	When the adjustment is complete, an internal sensitivity test is automatically performed. The test results are displayed and recorded.	Active Inactive*

* Factory setting

Limits

These settings only appear when one of the options "**As found**" test or "**As left**" test is activated.

Parameter	Description	Values
Control limit	Defines the error tolerance of a process with respect to its set value. Exceeding the Control limit is a violation of quality requirements and therefore requires a correction of the process. Result if the Control limit is exceeded: The adjustment failed, the balance is out of specification.	Numeric (0.1%* 0.001...100%)
Warning limit	Defines the upper or lower limit that, if exceeded or not reached, makes more stringent process monitoring necessary. The Warning limit must be smaller than the Control limit . Result if the Warning limit is exceeded: The adjustment is passed, but the difference is higher than expected.	Numeric (0.001...100%)

* Factory setting

3. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if the adjustment has failed. Active: The balance will be blocked after the adjustment has failed. In this case, the balance cannot be used anymore until it is unblocked. If a password has been set, the password is needed to unblock the balance. See [Password protection and balance reset ▶ Page 66]. Inactive: The balance will not be blocked.	Active Inactive*

* Factory setting

4. Planning

Parameter	Description	Values
Start after leveling	Defines if the internal adjustment starts after leveling.	Active Inactive*
Start after temperature change	Defines if the internal adjustment starts automatically after a temperature change of 1°C. For approved balances, this setting is set to Internal adjustment and cannot be edited. This restriction does not apply to balances of type /AC.	Active Inactive*
Schedule	Defines when the adjustment is being performed. It is possible to define between one and three start times per day. It can also be defined on which day(s) the adjustment is being performed.	Inactive 1 start time 2 start times* 3 start times

Start time 1	Defines the start time for the execution of the task. The number of start times to be defined is specified by Schedule .	Time
Preferred days	Defines the days for the scheduled adjustments. This setting is only available if Schedule is not set to Inactive .	Monday Tuesday Wednesday Thursday Friday Saturday Sunday

* Factory setting

5. Printing

Parameter	Description	Values
Header and Footer	Defines the header and/or footer to be printed.	Title Title text Date/ time User Signature Separating lines Group titles
Balance information	Defines which information about the balance is printed.	Balance type Balance ID Balance serial number Software version
Adjustment summary	Defines which information about the adjustment summary is printed.	Adjustment type Adjustment status Balance adjusted
Adjustment details	Defines which adjustment details are printed.	Trigger Cell temperature Level state Date/time User name
Adjustment weight	Defines which information about the adjustment weight is printed. This section is only available if an external weight is used for the adjustment.	Test weight ID Weight class Nominal weight Actual weight Weight set ID Certificate ID Certificate date Next calibration date Weight type Minimum weight class Used nominal weights Used actual weights
Adjustment limits	Defines which information about the adjustment limits is printed. This section is only available for internal adjustments.	Warning limit Control limit
Measurements / Results	Defines which information about the measurements and the results is printed. The settings available in this section depends on the adjustment strategy.	Correction Test deviation "as found" Test deviation "as left" Test result "as found" Test result "as left"

See also

- [🔗 Defining an individual test weight ▶ Page 45](#)
- [🔗 Defining a combined test weight ▶ Page 45](#)
- [🔗 Editing an "Internal adjustment" ▶ Page 52](#)
- [🔗 Editing an "External adjustment" ▶ Page 52](#)

7 Maintenance

To guarantee the functionality of the balance and the accuracy of the weighing results, a number of maintenance actions must be performed by the user.

The appropriate maintenance interval depends on your standard operating procedure (SOP).

7.1 Maintenance tasks

Maintenance action	Recommended interval	Remarks
Performing an internal adjustment	<ul style="list-style-type: none"> Daily After cleaning After leveling After changing the location 	see "Adjustments"
Performing routine tests (eccentricity test, repeatability test, sensitivity test). METTLER TOLEDO recommends to at least perform a sensitivity test.	<ul style="list-style-type: none"> After cleaning After assembling the balance After a software update Depending on your internal regulations (SOP) 	see "Tests"
Cleaning	<ul style="list-style-type: none"> After every use After changing the substance Depending on the degree of pollution Depending on your internal regulations (SOP) 	see "Cleaning"
Updating the software	<ul style="list-style-type: none"> Depending on your internal regulations (SOP). After a new software release. 	see "Software update"

See also

[Adjustments](#) ▶ Page 52

[Tests](#) ▶ Page 45

[Cleaning](#) ▶ Page 135

[Software update](#) ▶ Page 137

7.2 Cleaning

7.2.1 Cleaning agents

In the following table, cleaning tools and cleaning agents recommended by METTLER TOLEDO are listed. Pay attention to the concentration of the agents specified in the table.

		Tools					Cleaning agents					
		Paper tissue	Brush	Dishwasher	Water	Acetone	Ethanol (70%)	Isopropanol (70%)	Hydrochloric acid (3-10%)	Sodium hydroxide (0.2-1.0 M)	Peracetic acid (2-3%)	
Around the balance	Balance housing	✓	R	—	R	—	R	✓	R	R	R	
	Feet	✓	R	—	R	—	R	✓	R	R	R	

		Paper tissue	Brush	Dishwasher	Water	Acetone	Ethanol (70%)	Isopropanol (70%)	Hydrochloric acid (3-10%)	Sodium hydroxide (0.2-1.0 M)	Peracetic acid (2-3%)
Balance terminal	Terminal	✓	R	—	✓	PR	R	R	R	R	R
	Display	✓	—	—	✓	PR	R	R	R	R	R
	Terminal cover	✓	R	—	✓	—	R	R	R	PR	PR
Balance draft shield	Glass panels	✓	R	R	R	PR	✓	✓	R	R	R
	Glass-free panels	✓	R	—	R	—	✓	✓	R	R	R
	Non-removable handles and frames	✓	R	—	R	PR	✓	✓	R	R	R
Weighing area	Weighing pan	R	R	✓	R	R	✓	✓	R	R	R
	Drip tray	R	R	✓	R	R	✓	✓	—	—	R

Legend

- ✓ Best recommendation by METTLER TOLEDO; can be used without limitation.
- R Recommended by METTLER TOLEDO; can be used without limitation.
- PR Partially recommended by METTLER TOLEDO: individual resistance to acid and alkali must be evaluated, including dependence to the time exposure.
- Not recommend. High risk for damage.

7.2.2 Cleaning the MagicCube draft shield

To clean the MagicCube draft shield, simply remove it from the weighing platform.

7.2.3 Cleaning the balance



NOTICE

Damage to the instrument due to inappropriate cleaning methods

If liquid enters the housing, it can damage the instrument. The surface of the instrument can be damaged by certain cleaning agents, solvents, or abrasives.

- 1 Do not spray or pour liquid on the instrument.
- 2 Only use the cleaning agents specified in the Reference Manual (RM) of the instrument or the guide "8 Steps to a Clean Balance".
- 3 Only use a lightly moistened, lint-free cloth or a tissue to clean the instrument.
- 4 Wipe off any spills immediately.



For further information on cleaning a balance, consult "8 Steps to a Clean Balance".

► www.mt.com/lab-cleaning-guide

Cleaning around the balance

- Remove any dirt or dust around the balance and avoid further contaminations.

Cleaning the terminal

- Clean the terminal with a damp cloth or a tissue and a mild cleaning agent.

Cleaning the removable parts

- Clean the removed part with a damp cloth or a tissue and a mild cleaning agent or clean in a dishwasher up to 80 °C.

Cleaning the weighing unit

- 1 Disconnect the balance from the AC/DC adapter.
- 2 Use a lint-free cloth moistened with a mild cleaning agent to clean the surface of the balance.
- 3 Remove powder or dust with a disposable tissue first.
- 4 Remove sticky substances with a damp lint-free cloth and a mild solvent, e.g., isopropanol or ethanol 70%.

7.2.4 Putting into operation after cleaning

- 1 Reassemble the balance.
 - 2 Check that the draft shield doors (top, sides) open and close normally.
 - 3 Check if the terminal is connected to the balance.
 - 4 Reconnect the balance to the AC/DC adapter.
 - 5 Check the level status, level the balance if necessary.
 - 6 Respect the warm-up time specified in the "Technical Data".
 - 7 Perform an internal adjustment.
 - 8 Perform a routine test according to the internal regulations of your company. METTLER TOLEDO recommends performing a sensitivity test after cleaning the balance.
 - 9 Press **→0←** to zero the balance.
- ➔ The balance is ready to be used.

See also

- [🔗 Leveling the balance ▶ Page 29](#)
- [🔗 Technical Data ▶ Page 142](#)
- [🔗 Performing an internal adjustment ▶ Page 30](#)
- [🔗 Performing a "Sensitivity test" ▶ Page 49](#)

7.3 Service

Regular servicing by an authorized service technician ensures reliability for years to come. Contact your METTLER TOLEDO representative for details about the available service options.

7.4 Software update

Search for software:

▶ www.mt.com/labweighing-software-download


Please contact a METTLER TOLEDO service representative if you need support updating the software. METTLER TOLEDO recommends saving the data on a storage device before updating the software.

☰ **Navigation:** ⚙️ **Balance menu** > 📖 **Maintenance** > 📄 **Software update**

See also


- [🔗 Exporting and importing settings ▶ Page 65](#)

7.4.1 Updating the software


- A USB storage device containing the software installer (zip file format) is connected to the balance.
- 1 Tap  **Software update**.
- 2 Select **Update software** and tap **→Next**.
 - ➔ An update wizard opens and will lead you step-by-step through the procedure.

7.4.2 Restoring the software to the previous version


The current software version can be rolled back to the previous software version.

- 1 Tap  **Software update**.
- 2 Select **Restore the software to the previous version**. and tap **→ Next**.
 - ➔ An update wizard opens and will lead you step-by-step through the procedure.

7.4.3 Putting into operation after software update

- 1 Press  to switch on the balance.
 - 2 Check the level status, level the balance if necessary.
 - 3 Perform an internal adjustment.
 - 4 Perform a routine test according to the internal regulations of your company.
 - 5 Press **→0←** to zero the balance.
- ➔ The balance is ready to be used.

See also

 [Leveling the balance](#) ▶ Page 29

8 Troubleshooting

Possible errors with their cause and remedy are described in the following chapter. If there are errors that cannot be corrected through these instructions, contact METTLER TOLEDO.

8.1 Error messages

Error message	Possible cause	Diagnostic	Remedy
Balance reset failed	Communication failure	–	Disconnect the power cable and reconnect after a few seconds.
The system has no valid date and time set	Low battery	–	Connect to the power outlet and let the battery charge for two to three days.
Weight cannot be determined	Data signal problems of electronics.	–	Disconnect the power cable and reconnect after a few seconds.
	Bad connection between the terminal and the weighing unit.	Check the cable for damage (kinked, twisted or broken pins).	Replace the terminal cable.
	A device error has occurred.	Check if a device error is listed in the service menu, see [Service menu ▶ Page 80]. Tap Device errors .	Note the error code and contact your METTLER TOLEDO service representative.
Cannot start adjustment	Initial zero was not reached when the balance was switched on.	–	Disconnect the power cable and reconnect after a few seconds.
Preventive performance optimization	The balance memory (RAM) is full.	–	Complete the current task. Disconnect the power cable and reconnect after a few seconds.

See also

 Service menu ▶ Page 80

8.2 Error symptoms

Error symptom	Possible cause	Diagnostic	Remedy
The display is dark.	The instrument is on standby.	–	Switch on the instrument.
	There is no power.	Check the connection to the AC/DC adapter and the power outlet.	Connect the weighing unit to the power outlet. See "Connecting the balance".
	The terminal is not connected to the instrument.	Check the terminal cable connection.	Connect the terminal cable to the instrument.
	The terminal cable is defective.	Check the cable for damage (kinked, twisted or broken pins).	Replace the terminal cable.
	The wrong AC/DC adapter is connected to the instrument.	Check it, see "Technical Data".	Use the correct AC/DC adapter.

Error symptom	Possible cause	Diagnostic	Remedy
	The AC/DC adapter is defective.	–	Replace the AC/DC adapter.
The value on the display oscillates.	Vibrations on the weighing bench, e.g., building vibrations, foot traffic	Place a beaker with water on the weighing bench. Vibrations cause ripples on the water surface.	Protect the weighing location against vibrations, e.g. with an absorber. Find a different weighing location.
	Draft due to untight draft shield and/or open window.	Check the draft shield for gaps.	Fix the draft shield. Close the window.
	The weighing sample is electrostatically charged.	Check if the weighing result is stable when using a test weight.	Increase the air humidity in the weighing chamber. Use an ionizer. See "Accessories".
	The location is not suitable for weighing.	–	Follow the requirements for the location. See "Selecting the location".
	Something is touching the weighing pan.	Check for touching parts or dirt.	Remove touching parts. Clean the balance.
The value on the display is drifting towards plus or minus.	The weighing sample absorbs moisture or evaporates moisture.	Check if the weighing result is stable when using a test weight.	Cover the weighing sample.
	The weighing sample is electrostatically charged.	Check if the weighing result is stable when using a test weight.	Increase the air humidity in the weighing chamber. Use an ionizer. See "Accessories".
	The weighing sample is warmer or colder than the air in the weighing chamber.	Check if the weighing result is stable when using an acclimatized test weight.	Bring the sample to room temperature.
	The balance has not yet warmed up.	–	Let the balance warm up. Adequate warm-up time is specified in the "General data".
The display shows overload or underload.	The wrong weighing pan is installed.	Slightly lift or press the weighing pan to see if the weight appears on the display.	Install the proper weighing pan.
	No weighing pan is installed.	–	Install the proper weighing pan.
	Incorrect zero point at power on.	–	Disconnect the power cable and reconnect after a few seconds.
	The balance is not adjusted.	–	Perform an internal adjustment. See "Internal adjustment".
The draft shield front panel is not exactly 90° from the weighing platform	The draft shield front panel is not perfectly adjusted.	–	Contact your METTLER TOLEDO service representative to adjust the front panel.

Error symptom	Possible cause	Diagnostic	Remedy
The draft shield side doors are not exactly closed.	The draft shield side doors are not perfectly adjusted.	–	Contact your METTLER TOLEDO service representative to adjust the side doors.
The user interface responds slowly.	Too many results are included in the Results list of a task.	Check the Results list of every running and pending task.	Complete all tasks: For each task in the list of Tasks , select the task, tap Continue task , and tap Complete .

8.3 Putting into operation after fixing an error

After fixing an error, perform the following steps to put the balance into operation:

- Ensure that the balance is completely reassembled and cleaned.
- Reconnect the balance to the AC/DC adapter.

9 Technical Data

9.1 General data

Power supply

AC/DC adapter (model no. FSP060-DHAN3):

Input: 100 – 240 V AC \pm 10%, 50 – 60 Hz, 1.8 A

Output: 12 V DC, 5 A, LPS, SELV

AC/DC adapter (model no. FSP060-DIBAN2):

Input: 100 – 240 V AC \pm 10%, 50 – 60 Hz, 1.5 A

Output: 12 V DC, 5 A, LPS, SELV

Cable for AC/DC adapter:

3-core, with country-specific plug

Balance power consumption:

12 V DC \pm 10%, 2.25 A

Polarity:



Protection and standards

Overvoltage category:

II

Degree of pollution:

2

Standards for safety and EMC:

See Declaration of Conformity

Range of application:

Use only indoors in dry locations

Environmental conditions

The limit values apply when the balance is used under the following environmental conditions:

Height above mean sea level:

Up to 5000 m

Ambient temperature:

+10 – +30 °C

Temperature change, max.:

5 °C/h

Relative air humidity:

30 – 70%, non-condensing

Acclimatization time:

At least **4 hours** after placing the instrument in the same location where it will be put into operation.

Warm-up time:

At least **30 minutes** after connecting the balance to the power supply. When switched on from standby, the instrument is ready for operation immediately.

The balance can be used under the following environmental conditions. However, the weighing performances of the balance may be outside the limit values:

Ambient temperature:

+5 °C – +40 °C

Relative air humidity:

20% to max. 80% at 31 °C, decreasing linearly to 50% at 40 °C, non-condensing

The balance can be disconnected and stored in its packaging under the following conditions:

Ambient temperature:

-25 – +70 °C

Relative air humidity:

10 – 90%, non-condensing


9.2 Explanatory notes for the METTLER TOLEDO AC/DC adapter

The certified external AC/DC adapter complies to the requirements for Class II double insulated equipment. It is not provided with a protective earth connection but with a functional earth connection for EMC purposes. This earth connection **is not** a safety feature. Further information about the compliance of our products can be found in the "Declaration of Conformity" delivered with every product.

In case of testing with regard to the European Directive 2001/95/EC, the AC/DC adapter and the instrument have to be handled as Class II double insulated equipment.

Consequently, a grounding test is not required. It is not necessary to carry out a grounding test between the earth connector of the power plug and any exposed part of the metallic housing of the instrument.

Because the instrument is sensitive to static charges, a leakage resistor of 10 k Ω is connected between the earth connector (1) and the negative pole (2) of the AC/DC adapter. The arrangement is shown in the equivalent circuit diagram. This resistor is not part of the electrical safety arrangement and does not require testing at regular intervals.



9.3 Model-specific data

9.3.1 S platform

9.3.1.1 Readability 1 mg, with MagicCube Draft Shield and SmartPan

	XSR303S	XSR603S	XSR1203S
Limit values			
Capacity	310 g	610 g	1210 g
Nominal load	300 g	600 g	1200 g
Readability	1 mg	1 mg	1 mg
Capacity of fine range	–	–	–
Readability in fine range	–	–	–
Repeatability	0.9 mg	0.9 mg	0.8 mg
Repeatability in fine range	–	–	–
Linearity deviation	2 mg	2 mg	2 mg
Eccentricity deviation (at test load)	3 mg (100 g)	3 mg (200 g)	3 mg (500 g)
Sensitivity offset (at nominal load) ▲	6 mg	4.5 mg	6 mg
Sensitivity temperature drift	0.0005%/°C	0.0002%/°C	0.0002%/°C
Typical values			
Repeatability	0.5 mg	0.5 mg	0.4 mg
Repeatability in fine range	–	–	–
Linearity deviation	0.6 mg	0.6 mg	0.6 mg
Eccentricity deviation (at test load)	1 mg (100 g)	1 mg (200 g)	1 mg (500 g)
Sensitivity offset (at nominal load) ▲	1.2 mg	1.2 mg	1.5 mg
Minimum weight (USP, tolerance = 0.10%) ▼	1 g	1 g	0.82 g
Minimum weight (tolerance = 1%) ▼	100 mg	100 mg	82 mg
Settling time	1.5 s	1.5 s	1.5 s
Dimensions and other specifications			
Balance dimensions (W × D × H)	194 × 390 × 281 mm	194 × 390 × 281 mm	194 × 390 × 281 mm
Weighing pan dimensions (W × D)	127 × 127 mm	127 × 127 mm	127 × 127 mm
Weighing pan diameter	–	–	–
Usable height of draft shield	175 mm	175 mm	175 mm
Balance weight	7 kg	7 kg	7 kg
Weights for routine testing			
Weights (OIML class)	200 g (F2) / 10 g (F2)	500 g (F2) / 20 g (F2)	1000 g (F2) / 50 g (F2)
Weights (ASTM class)	200 g (ASTM 1) / 10 g (ASTM 1)	500 g (ASTM 1) / 20 g (ASTM 1)	1000 g (ASTM 1) / 50 g (ASTM 1)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

9.3.1.2 Readability 1 mg, with SmartPan

	XSR303SN	XSR603SN
Limit values		
Capacity	310 g	610 g
Nominal load	300 g	600 g
Readability	1 mg	1 mg
Capacity of fine range	–	–
Readability in fine range	–	–
Repeatability	0.9 mg	0.9 mg
Repeatability in fine range	–	–
Linearity deviation	2 mg	2 mg
Eccentricity deviation (at test load)	3 mg (100 g)	3 mg (200 g)
Sensitivity offset (at nominal load) ▲	6 mg	4.5 mg
Sensitivity temperature drift	0.0005%/°C	0.0002%/°C
Typical values		
Repeatability	0.5 mg	0.5 mg
Repeatability in fine range	–	–
Linearity deviation	0.6 mg	0.6 mg
Eccentricity deviation (at test load)	1 mg (100 g)	1 mg (200 g)
Sensitivity offset (at nominal load) ▲	1.2 mg	1.2 mg
Minimum weight (USP, tolerance = 0.10%) ▼	1 g	1 g
Minimum weight (tolerance = 1%) ▼	100 mg	100 mg
Settling time	1.5 s	1.5 s
Dimensions and other specifications		
Balance dimensions (W × D × H)	194 × 390 × 102 mm	194 × 390 × 102 mm
Weighing pan dimensions (W × D)	127 × 127 mm	127 × 127 mm
Weighing pan diameter	–	–
Usable height of draft shield	–	–
Balance weight	5.4 kg	5.4 kg
Weights for routine testing		
Weights (OIML class)	200 g (F2) / 10 g (F2)	500 g (F2) / 20 g (F2)
Weights (ASTM class)	200 g (ASTM 1) / 10 g (ASTM 1)	500 g (ASTM 1) / 20 g (ASTM 1)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

9.3.1.3 Readability 10 mg, with SmartPan

	XSR6002S	XSR6002SDR	XSR10002S
Limit values			
Capacity	6.1 kg	6.1 kg	10.1 kg
Nominal load	6 kg	6 kg	10 kg
Readability	0.01 g	0.1 g	0.01 g
Capacity of fine range	–	1200 g	–
Readability in fine range	–	0.01 g	–
Repeatability	8 mg	60 mg	8 mg
Repeatability in fine range	–	8 mg	–
Linearity deviation	20 mg	60 mg	20 mg
Eccentricity deviation (at test load)	30 mg (2 kg)	100 mg (2 kg)	40 mg (5 kg)
Sensitivity offset (at nominal load) ▲	60 mg	150 mg	50 mg
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C	0.00025%/°C
Typical values			
Repeatability	4 mg	40 mg	4 mg
Repeatability in fine range	–	5 mg	–
Linearity deviation	6 mg	20 mg	6 mg
Eccentricity deviation (at test load)	10 mg (2 kg)	32 mg (2 kg)	12 mg (5 kg)
Sensitivity offset (at nominal load) ▲	12 mg	30 mg	12 mg
Minimum weight (USP, tolerance = 0.10%) ▼	8.2 g	10 g	8.2 g
Minimum weight (tolerance = 1%) ▼	0.82 g	1 g	0.82 g
Settling time	1.2 s	1.2 s	1.5 s
Dimensions and other specifications			
Balance dimensions (W × D × H)	194 × 390 × 102 mm	194 × 390 × 102 mm	194 × 390 × 102 mm
Weighing pan dimensions (W × D)	172 × 205 mm	172 × 205 mm	172 × 205 mm
Weighing pan diameter	–	–	–
Usable height of draft shield	–	–	–
Balance weight	7.9 kg	7.9 kg	7.5 kg
Weights for routine testing			
Weights (OIML class)	5 kg (F2) / 200 g (F2)	5 kg (F2) / 200 g (F2)	10 kg (F2) / 500 g (F2)
Weights (ASTM class)	5 kg (ASTM 4) / 200 g (ASTM 4)	5 kg (ASTM 4) / 200 g (ASTM 4)	10 kg (ASTM 4) / 500 g (ASTM 4)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

	XSR1202S	XSR2002S	XSR4002S
Limit values			
Capacity	1210 g	2.1 kg	4.1 kg
Nominal load	1200 g	2 kg	4 kg
Readability	0.01 g	0.01 g	0.01 g
Capacity of fine range	–	–	–
Readability in fine range	–	–	–
Repeatability	8 mg	8 mg	8 mg
Repeatability in fine range	–	–	–
Linearity deviation	20 mg	20 mg	20 mg
Eccentricity deviation (at test load)	20 mg (500 g)	30 mg (1000 g)	30 mg (2 kg)
Sensitivity offset (at nominal load) ▲	60 mg	60 mg	60 mg
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C	0.0003%/°C
Typical values			
Repeatability	4 mg	4 mg	4 mg
Repeatability in fine range	–	–	–
Linearity deviation	6 mg	6 mg	6 mg
Eccentricity deviation (at test load)	6 mg (500 g)	10 mg (1000 g)	10 mg (2 kg)
Sensitivity offset (at nominal load) ▲	15 mg	25 mg	25 mg
Minimum weight (USP, tolerance = 0.10%) ▼	8.2 g	8.2 g	8.2 g
Minimum weight (tolerance = 1%) ▼	0.82 g	0.82 g	0.82 g
Settling time	1.2 s	1.2 s	1.2 s
Dimensions and other specifications			
Balance dimensions (W × D × H)	194 × 390 × 102 mm	194 × 390 × 102 mm	194 × 390 × 102 mm
Weighing pan dimensions (W × D)	172 × 205 mm	172 × 205 mm	172 × 205 mm
Weighing pan diameter	–	–	–
Usable height of draft shield	–	–	–
Balance weight	7.9 kg	7.9 kg	7.9 kg
Weights for routine testing			
Weights (OIML class)	1000 g (F2) / 50 g (F2)	2 kg (F2) / 100 g (F2)	2 kg (F2) / 200 g (F2)
Weights (ASTM class)	1000 g (ASTM 1) / 50 g (ASTM 1)	2 kg (ASTM 1) / 100 g (ASTM 1)	2 kg (ASTM 4) / 200 g (ASTM 4)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

9.3.1.4 Readability 100 mg

	XSR4001S	XSR6001S
Limit values		
Capacity	4.1 kg	6.1 kg
Nominal load	4 kg	6 kg
Readability	0.1 g	0.1 g
Capacity of fine range	–	–
Readability in fine range	–	–
Repeatability	80 mg	80 mg
Repeatability in fine range	–	–
Linearity deviation	60 mg	60 mg
Eccentricity deviation (at test load)	200 mg (2 kg)	200 mg (2 kg)
Sensitivity offset (at nominal load) ▲	240 mg	240 mg
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	40 mg	40 mg
Repeatability in fine range	–	–
Linearity deviation	20 mg	20 mg
Eccentricity deviation (at test load)	60 mg (2 kg)	60 mg (2 kg)
Sensitivity offset (at nominal load) ▲	50 mg	50 mg
Minimum weight (USP, tolerance = 0.10%) ▼	82 g	82 g
Minimum weight (tolerance = 1%) ▼	8.2 g	8.2 g
Settling time	0.8 s	0.8 s
Dimensions and other specifications		
Balance dimensions (W × D × H)	194 × 390 × 100 mm	194 × 390 × 100 mm
Weighing pan dimensions (W × D)	190 × 223 mm	190 × 223 mm
Weighing pan diameter	–	–
Usable height of draft shield	–	–
Balance weight	6.3 kg	6.3 kg
Weights for routine testing		
Weights (OIML class)	2 kg (F2) / 200 g (F2)	5 kg (F2) / 200 g (F2)
Weights (ASTM class)	2 kg (ASTM 4) / 200 g (ASTM 4)	5 kg (ASTM 4) / 200 g (ASTM 4)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

	XSR8001S	XSR10001S
Limit values		
Capacity	8.1 kg	10.1 kg
Nominal load	8 kg	10 kg
Readability	0.1 g	0.1 g
Capacity of fine range	–	–
Readability in fine range	–	–
Repeatability	80 mg	80 mg
Repeatability in fine range	–	–
Linearity deviation	100 mg	100 mg
Eccentricity deviation (at test load)	200 mg (5 kg)	200 mg (5 kg)
Sensitivity offset (at nominal load) ▲	600 mg	500 mg
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	40 mg	40 mg
Repeatability in fine range	–	–
Linearity deviation	30 mg	30 mg
Eccentricity deviation (at test load)	60 mg (5 kg)	60 mg (5 kg)
Sensitivity offset (at nominal load) ▲	120 mg	120 mg
Minimum weight (USP, tolerance = 0.10%) ▼	82 g	82 g
Minimum weight (tolerance = 1%) ▼	8.2 g	8.2 g
Settling time	1 s	1 s
Dimensions and other specifications		
Balance dimensions (W × D × H)	194 × 390 × 100 mm	194 × 390 × 100 mm
Weighing pan dimensions (W × D)	190 × 223 mm	190 × 223 mm
Weighing pan diameter	–	–
Usable height of draft shield	–	–
Balance weight	6.3 kg	6.3 kg
Weights for routine testing		
Weights (OIML class)	5 kg (F2) / 200 g (F2)	10 kg (F2) / 500 g (F2)
Weights (ASTM class)	5 kg (ASTM 4) / 200 g (ASTM 4)	10 kg (ASTM 4) / 500 g (ASTM 4)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

9.3.2 L platform

9.3.2.1 Readability 100 mg

	XSR10001L	XSR16001L
Limit values		
Capacity	10.1 kg	16.1 kg
Nominal load	10 kg	16 kg
Readability	0.1 g	0.1 g
Capacity of fine range	–	–
Readability in fine range	–	–
Repeatability	80 mg	80 mg
Repeatability in fine range	–	–
Linearity deviation	200 mg	200 mg
Eccentricity deviation (at test load)	300 mg (5 kg)	300 mg (5 kg)
Sensitivity offset (at nominal load) ▲	500 mg	800 mg
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	40 mg	40 mg
Repeatability in fine range	–	–
Linearity deviation	60 mg	60 mg
Eccentricity deviation (at test load)	100 mg (5 kg)	100 mg (5 kg)
Sensitivity offset (at nominal load) ▲	120 mg	200 mg
Minimum weight (USP, tolerance = 0.10%) ▼	82 g	82 g
Minimum weight (tolerance = 1%) ▼	8.2 g	8.2 g
Settling time	1.5 s	1.5 s
Dimensions and other specifications		
Balance dimensions (W × D × H)	360 × 412 × 122 mm	360 × 412 × 122 mm
Weighing pan dimensions (W × D)	360 × 280 mm	360 × 280 mm
Weighing pan diameter	–	–
Usable height of draft shield	–	–
Balance weight	10.1 kg	10.1 kg
Weights for routine testing		
Weights (OIML class)	10 kg (F2) / 500 g (F2)	500 g (F2) / 10000 g (F2)
Weights (ASTM class)	10 kg (ASTM 4) / 500 g (ASTM 4)	500 g (ASTM 4) / 10000 g (ASTM 4)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

	XSR32001L	XSR32001LDR
Limit values		
Capacity	32.1 kg	32.1 kg
Nominal load	30 kg	30 kg
Readability	0.1 g	1 g
Capacity of fine range	–	6.4 kg
Readability in fine range	–	100 mg
Repeatability	80 mg	600 mg
Repeatability in fine range	–	100 mg
Linearity deviation	300 mg	300 mg
Eccentricity deviation (at test load)	300 mg (10 kg)	1 g (10 kg)
Sensitivity offset (at nominal load) ▲	960 mg	960 mg
Sensitivity temperature drift	0.001%/°C	0.001%/°C
Typical values		
Repeatability	40 mg	400 mg
Repeatability in fine range	–	40 mg
Linearity deviation	100 mg	200 mg
Eccentricity deviation (at test load)	100 mg (10 kg)	300 mg (10 kg)
Sensitivity offset (at nominal load) ▲	250 mg	320 mg
Minimum weight (USP, tolerance = 0.10%) ▼	82 g	82 g
Minimum weight (tolerance = 1%) ▼	8.2 g	8.2 g
Settling time	1.5 s	1.5 s
Dimensions and other specifications		
Balance dimensions (W × D × H)	360 × 412 × 122 mm	360 × 412 × 122 mm
Weighing pan dimensions (W × D)	360 × 280 mm	360 × 280 mm
Weighing pan diameter	–	–
Usable height of draft shield	–	–
Balance weight	10.1 kg	10.1 kg
Weights for routine testing		
Weights (OIML class)	1000 g (F2) / 20000 g (F2)	20 kg (F2) / 1000 g (F2)
Weights (ASTM class)	1000 g (ASTM 4) / 20000 g (ASTM 4)	20 kg (ASTM 4) / 1000 g (ASTM 4)

▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

9.3.2.2 Readability 1 g

	XSR16000L	XSR32000L
Limit values		
Capacity	16.1 kg	32.1 kg
Nominal load	16 kg	30 kg
Readability	1 g	1 g
Capacity of fine range	–	–
Readability in fine range	–	–
Repeatability	600 mg	600 mg
Repeatability in fine range	–	–
Linearity deviation	600 mg	600 mg
Eccentricity deviation (at test load)	1 g (5 kg)	1 g (10 kg)
Sensitivity offset (at nominal load) ▲	1.1 g	1.6 g
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	400 mg	400 mg
Repeatability in fine range	–	–
Linearity deviation	400 mg	400 mg
Eccentricity deviation (at test load)	300 mg (5 kg)	300 mg (10 kg)
Sensitivity offset (at nominal load) ▲	350 mg	650 mg
Minimum weight (USP, tolerance = 0.10%) ▼	820 g	820 g
Minimum weight (tolerance = 1%) ▼	82 g	82 g
Settling time	1.2 s	1.2 s
Dimensions and other specifications		
Balance dimensions (W × D × H)	360 × 412 × 122 mm	360 × 412 × 122 mm
Weighing pan dimensions (W × D)	360 × 280 mm	360 × 280 mm
Weighing pan diameter	–	–
Usable height of draft shield	–	–
Balance weight	10.1 kg	10.1 kg
Weights for routine testing		
Weights (OIML class)	10 kg (F2) / 500 g (F2)	20 kg (F2) / 1000 g (F2)
Weights (ASTM class)	10 kg (ASTM 4) / 500 g (ASTM 4)	20 kg (ASTM 4) / 1000 g (ASTM 4)


▲ after adjustment with internal weight

▼ determined at 5% load, k = 2

9.4 Dimensions

9.4.1 S platform, readability 1 mg, with MagicCube Draft Shield and SmartPan


Models: XSR303S, XSR603S, XSR1203S



	Outer dimensions [mm]
	Clear dimensions [mm]
	Position of the weighing hook axle

9.4.2 S platform, readability 1 mg, with SmartPan


Models: XSR303SN, XSR603SN



↔	Outer dimensions [mm]
J	Position of the weighing hook axle

9.4.3 S platform, readability 10 mg, with SmartPan


Models: XSR1202S, XSR2002S, XSR4002S, XSR6002S, XSR6002SDR, XSR10002S



↔	Outer dimensions [mm]
J	Position of the weighing hook axle

9.4.4 S platform, readability 100 mg



Models: XSR4001S, XSR6001S, XSR8001S, XSR10001S



↔	Outer dimensions [mm]
J	Position of the weighing hook axle

9.4.5 L platform, readability 100 mg / 1 g

Models: XSR10001L, XSR16001L, XSR32001L, XSR32001LDR, XSR16000L, XSR32000L



↔	Outer dimensions [mm]
G	Position of the weighing hook axle

10 Disposal

In conformance with the European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE) this device may not be disposed of in domestic waste. This also applies to countries outside the EU, per their specific requirements.

Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment. If you have any questions, please contact the responsible authority or the distributor from which you purchased this device. Should this device be passed on to other parties, the content of this regulation must also be related.



11 Accessories and Spare Parts

11.1 Accessories

Accessories are additional components that could help you in your workflow.

	Description	Order no.
Weighing pans		
	Dynamic weighing pan for 100 mg and 10 mg models, with 4 liter bowl and contact mat, S platform	11132657
	MPS (Magnetic Protection Shield) weighing pan for 0.1 g models 190 × 223 mm, "S" platform	11132625
Draft shields		
	Pro draft shield for 0.1 mg and 1 mg models, height: 248 mm	30300926
	Pro draft shield glass free (food industry) for 0.1 mg and 1 mg models, height: 248 mm	30409092
	Draft shield XP-W12, dimensions (W x D x H): 300 mm × 450 mm × 450 mm, for S weighing platform	11134430
	Draft shield XP-W64, dimensions (W x D x H): 550 mm × 470 mm × 580 mm, for L weighing platform	11134470
	"MagicCube" Draft Shield for 1 mg models, S platform Usable height 175 mm	30300928



"Simple" Draft shield with draft shield element for 5 mg and 10 mg models, usable height 175 mm, S platform

30113496

Stands and wall mounting



Terminal stand for placement of the terminal 30 cm above the weighing pan, S platform

30125077



Terminal stand for placement of the terminal 30 cm above the weighing pan, L platform

30125333



Wall fixture for terminal

30138798



Adapter kit for XSR terminal (required for terminal stand and wall fixture)

30300956

Antistatic kits



Universal AntiStatic Kit complete (U-shaped), including electrode and power supply

11107767

Optional: Second U-electrode* for universal AntiStatic Kit

11107764

* Power supply for optional, second U-electrode (11107764)

11107766



Compact ionizer with stand (USB)


30499859



Additional compact ionizer (USB) for Compact ionizer with stand (30499859)

30496446

Filling-process control



LV12 automatic feeder

30374389



LV12 ProDraft Shield door for 0.1 mg and 1 mg models with S weighing platform
Must be combined with the ProDraft Shield (30300926)

11132711

Density determination



Density kit

30300933



Sinker 10 mL

210260



Calibrated Sinkers 10 mL

210672



Calibrated Thermometer

11132685

Printers



CLS-631 label printer (RS232C/USB-A)

11141820

Label and ink ribbon kit

30004309

The NetCom Kit might be needed for this printer. Contact your local METTLER TOLEDO service representative.



P-52RUE dot matrix printer RS232C, USB and Ethernet connections, simple print-outs

30237290

Paper roll (length: 20 m), set of 5 pcs

00072456

Paper roll (length: 13 m), self-adhesive, set of 3 pcs

11600388

Ribbon cartridge, black, set of 2 pcs

00065975



P-56RUE thermal printer with RS232C, USB and Ethernet connections, simple print-outs, date and time

30094673

Paper roll, white (length: 27 m), set of 10 pcs

30094723

Paper roll, white, self-adhesive (length: 13 m), set of 10 pcs

30094724



P-58RUE thermal printer with RS232C, USB and Ethernet connections, simple print-outs, date and time, label printing, balance applications, e.g., statistics, formulation, totaling

30094674

Paper roll, white (length: 27 m), set of 10 pcs

30094723

Paper roll, white, self-adhesive (length: 13 m), set of 10 pcs

30094724

Paper roll, white, self-adhesive labels (550 labels), set of 6 pcs

30094725


Dimension of the label 56×18 mm

Hands-free accessories



ErgoSens, optical sensor for remote operation (USB connection)

30300915



Foot switch, optional switch for remote operation (USB connection)

30312558

Barcode readers



Corded USB barcode reader

30417466

Anti-theft devices



Anti-theft cable with lock

11600361

Cables for RS232C interfaces



USB-RS232 cable with integrated null modem to connect peripherals and computers via RS232C to an XPR/XSR balance

30576241

Wireless interfaces



Bluetooth RS232C serial adapter ADP-BT-S

30086494

For wireless connection between:

- instrument and computer (depending on the instrument model)
- printer and instrument



Bluetooth USB adapter for wireless connection to P-5x printer (additional Bluetooth RS232C serial adapter 30086494 required)

30416089

Software



LabX Balance Express

11153120

Stand-alone system, includes one balance license.



LabX Balance Server

11153121

Client server system, includes one balance license.



LabX 1 Balance instrument license

11153220

Single additional instrument license for Express or Server edition.

Adjustment weights



OIML / ASTM Weights (with calibration certificate)

► www.mt.com/weights

Various



EasyHub USB

30468768



SmartPrep, single-use funnel for quick and easy sample preparation. For flask sizes 10/19, 12/21, 14/23. 50 pcs

30061260



Terminal cable, extended, length: 4.5 m

30300920



Transport case for 5 mg, 10 mg and 100 mg models,
S platform

30113497



Hook for Platform L


11132565

11.2 Spare parts

Spare parts are parts that are delivered with the original instrument but that can be replaced, if needed, without the help of a service technician.


11.2.1 Balances S weighing platform

11.2.1.1 Balance S platform, readability 1 mg, SmartPan, MagicCube draft shield




	Order no.	Designation	Remarks
1	30215433	Weighing pan	128 × 128 mm
2	30215431	SmartPan weighing pan	127 × 127 mm
3	30416100	Drip tray	For models with draft shield
4	30300967	Protective cover, weighing platform	–
5	30072531	Leveling foot	Including: 1 pcs

11.2.1.2 Balance S platform, readability 1 mg, SmartPan




	Order no.	Designation	Remarks
1	30215433	Weighing pan	128 × 128 mm
2	30215431	SmartPan weighing pan	127 × 127 mm
3	30416108	Drip tray	For models without draft shield
4	30300967	Protective cover, weighing platform	–
5	30072531	Leveling foot	Including: 1 pcs

11.2.1.3 Balance S platform, readability 10 mg, SmartPan



	Order no.	Designation	Remarks
1	30106207	Protective cover, weighing pan	172 × 205 mm
2	30215056	Weighing pan	172 × 205 mm
3	30215057	SmartPan weighing pan	170 × 203 mm
4	30215373	Stop screw	Including: 2 pcs
5	30113501	Drip tray	For models without draft shield
6	11131029	Cap, pan support	Including: 1 pcs
7	30300966	Protective cover, weighing platform	–
8	30072531	Leveling foot	Including: 1 pcs


11.2.1.4 Balance S platform, readability 100 mg



	Order no.	Designation	Remarks
1	30106204	Protective cover, weighing pan	190 × 223 mm
2	11131031	Weighing pan	190 × 223 mm
3	11131037	Pan support	–
4	11131073	Stop screw	Including: 1 pcs
5	11131067	Fastening plate	–
6	11131029	Cap, pan support	Including: 1 pcs
7	30300966	Protective cover, weighing platform	–
8	30072531	Leveling foot	Including: 1 pcs


11.2.2 Balances L weighing platform

11.2.2.1 Balance L platform, readability 100 mg / 1 g




	Order no.	Designation	Remarks
1	239105	Weighing pan (≤ 32 kg)	280 × 360 mm
2	30416105	Cap, pan support (≤ 32 kg)	Including: 4 pcs
3	11133102	Leveling foot	Including: 1 pcs

11.2.3 Miscellaneous



	Order no.	Designation	Remarks
1	30388323	AC/DC adapter	Output: 12 V DC, 5 A
2	88751	Power cable AU	—
3	30015268	Power cable BR	—
4	87920	Power cable CH	—
5	30047293	Power cable CN	—
6	87452	Power cable DK	—
7	87925	Power cable EU	—
8	89405	Power cable GB	—
9	225297	Power cable IL	—
10	11600569	Power cable IN	—
11	87457	Power cable IT	—
12	11107881	Power cable JP	—
13	11107880	Power cable TH, PE	—
14	88668	Power cable US	—
15	89728	Power cable ZA	—
16	30317507	Terminal SRPT	Including: protective cover
17	30300968	Protective cover	For terminal (SRAT, SRPT)
18	30416123	Cable, terminal	—
19	30416122	Holder, terminal	For S platform


11.2.4 MagicCube draft shield



	Order no.	Designation	Remarks
1	30300928	MagicCube draft shield	–
2	11133035	U-shaped panel	Material: glass
3	11133037	Side door	–


11.2.5 Packaging

11.2.5.1 S platform with draft shield




	Order no.	Designation	Remarks
1	30416124	Packaging	Including: export box, inner protection material
2	30416158	Packaging, MagicCube draft shield	Including: export box, inner protection material
3	30416159	Export box, draft shield	Excluding: inner protection material
4	30416156	Export box	Excluding: inner protection material

11.2.5.2 S platform without draft shield




	Order no.	Designation	Remarks
1	30416160	Packaging	Including: export box, inner protection material
2	30416161	Export box	Excluding: inner protection material

11.2.5.3 L platform, readability 10 mg



	Order no.	Designation	Remarks
1	30416125	Packaging	Including: export box, inner protection material
2	30008482	Export box	Excluding: inner protection material

11.2.5.4 L platform, readability 100 mg and 1g



	Order no.	Designation	Remarks
1	30416162	Packaging	Including: export box, inner protection material

12 Appendix

12.1 Approved balances

12.1.1 Definitions

Approved balances

Approved balances are balances that are subject to the local, legal requirements of "non-automatic weighing instruments", as defined in OIML R76. For approved balances, the net weighing results must comply with a higher level of control. Approved balances are used, for example, for legal metrology, for weight-based trading, or for determination of mass for the application of laws. The term "approved balance" includes legal-for-trade (LFT) balances, certified balances, and registered balances.

The restrictions and special behaviors of these balances are described in the present section as well as in specific balance settings throughout the manual.

To identify approved balances, the characters /M or /A are appended to the model names.

Actual scale interval, **d**

The value **d** represents the "actual scale interval". According to OIML R76-1 [T.3.2.2], it represents the difference between two consecutive indicated values. In some countries, the value **d** is defined as the "scale division" or the "scale division interval". In practice, it is often referred to as the "readability".

Verification scale interval, **e**

The value **e** represents the "verification scale interval" [OIML R76-1: T.3.2.3]. This value is used for the classification and verification of an instrument. It represents the absolute accuracy of the instrument and is relevant in the context of market surveillance.

The minimum value of the verification scale interval is 1 mg. [OIML R76-1: 3.2]

12.1.2 Descriptive markings

The descriptive markings of the instrument are on the model label, according to OIML R76-1 [7.1.4]:

- **Min**: minimum capacity
- **Max**: maximum capacity (referred to as "capacity" in this document)
- **e**: verification scale interval
- **d**: actual scale interval

The type label also contains those descriptive markings, as well as other metrological characteristics and limits of the instrument.

12.1.3 Restrictions on zeroing and taring

Zeroing the balance

- When switching on the balance, an initial zero is performed. If the load is more than 20% of the balance capacity during the initial zero, the zeroing is not possible and no weighing value is displayed. [OIML R76-1: T.2.7.2.4 and 4.5.1]
- During operation, the range for which a zero can be performed is $\pm 2\%$ of the balance capacity. [OIML R76-1: 4.5.1]

Taring the balance

- It is not possible to tare the balance if the gross weight is negative. [OIML R76-1: 4.6.4]

12.1.4 Factory method: General Weighing

All balances are delivered with a factory method named **General Weighing**. For approved balances:

- The factory method cannot be deleted.
- The unit of the factory method **General Weighing** is set to **g** and cannot be edited.

- When switching on the balance, the factory method is shown on the weighing screen, regardless of which method was running when the balance was switched off.
- For the tolerance profile used by the factory method, the setting **Display readability** is set to **1d** and cannot be edited.

12.1.5 Representation of weighing results

The representation of weighing results from approved balances follows rules with respect to the weighing units, the weight value, and the indicator of the type of weight. These rules are described in the following paragraphs.

Unit

- A reduced set of units is available for selection.
- Units defined by the user (**Custom unit**) are restricted to characters that cannot be confused with other standard units. The following values are not allowed (uppercase and lowercase letters):
 - all common units, abbreviation or full name, for example, g, gram, kg, ct, oz, etc.
 - c, ca, car, cm, crt, cart, kt, gr, mgr, ugr, kgr, gra, mgra, ugra, kgra, grm, mgrm, ugrm, kgrm, mgram, ugram, kgram, k, kilo, to, tn, sh, tael, dram, dr, lboz, gramme, tonne, livre, once, lbt, cwt, dwt
 - all common units starting with the letter "o", where the "o" is replaced by the number "0", for example, Oz, Ozt, etc.
 - all common units where the letter "s" is added at the end

Weighing result

If the actual scale interval is smaller than the verification scale interval ($d < e$), the digits that are smaller than **e**, are called non-verified digits. For balances showing up to four digits ($d \geq 0.1$ mg), the non-verified digits are marked. For example, a weight of 100 mg placed on a balance with $e = 1$ mg and $d = 0.1$ mg would be printed as 100. [0] mg. [OIML R76-1: 3.4.1, 3.4.2]

- primary weight value on the main weighing screen: the non-verified digits are grayed out
- secondary weight value (**Info weight**) on the main weighing screen: the non-verified digits are grayed out
- **Results list**, detailed view: the non-verified digits are in brackets
- **Alibi memory**: the non-verified digits are in brackets
- Printout: the non-verified digits are in brackets
- Data export: no special marking

If custom units are used, the non-verified digits are not marked.

The depiction of the weight values does not affect the accuracy of the weighing results. That is consistent with legal metrology requirements.

Indicator for weighing result

The type of weighing result, such as **Net weight**, **Tare weight**, or **Gross weight**, is marked according to OIML R76-1 [T.5.2, T.5.3, 4.6.5, 4.6.11, 4.7].

Indicator	Main weighing screen	Results list	Printout
Net weight	Net	Net weight	N
Tare weight	–	Tare weight	T
Preset tare weight	–	Preset tare weight	PT
Gross weight	–	Gross weight	G ¹
Calculated weight	*	*	*
Unstable weight	o	D	D

¹ If only the gross weight is included on the printout, the indicator **G** is omitted.

Printout examples

The following examples refer to a balance with **e** = 1 mg and **d** = 0.1 mg. The tare or preset tare value is 200 mg, the gross weight is 743.2 mg and the net weight is 543.2 mg.

- with manual tare:

N	543. [2] mg
T	200. [0] mg
G	743. [2] mg

- with preset tare:

N	* 543. [2] mg
PT	200.0 mg
G	743. [2] mg

12.1.6 MT-SICS

The following commands are not available for approved balances:

- **C0**
 - It is not possible to change the adjustment type.
- **TI**
 - It is not possible to do an immediate tare. [OIML R76-1: 4.6.8]
- **ZI**
 - It is not possible to do an immediate zero. [OIML R76-1: 4.5.6]

12.1.7 Reference

OIML R 76-1 Edition 2006 (E), Non-automatic weighing instruments, Part 1: Metrological and technical requirements – Tests

Index

A

AC/DC adapter	142, 143
acclimatization	
time	29, 142
adjustment	19, 52
external	52, 53
internal	52
setting	132
altitude	142
approved balance	80, 176

B

balance information	70
barcode reader	57, 78
delete	59
block	
balance	68
balance setting	67
method setting	67
unblocking password	66
Bluetooth	78
printer	55, 78
brightness	76

C

certified balance	
see approved balance	176
clone	
method	43
combined test weight	45
command	
MT-SICS	60, 79
web service	62, 79
compliance information	9
convention	7
create	
eccentricity test	46
method	35
repeatability test	46
sensitivity test	46

D

delete	
device	59
method	43

density determination	
create a method	40
perform	41
setting	107
device	
barcode reader	57, 78
delete	59
edit setting	59
ErgoSens	58, 78
foot switch	79
peripheral	78
printer	53, 54, 55, 78
disposal	158

E

eccentricity test	47
create	46
setting	122
edit	
method	43
environmental condition	22, 142
ErgoSens	58, 78
delete	59
Ethernet	77
EULA	29
external	
adjustment	52, 53
device	78

F

foot switch	79
delete	59

G

general weighing	
create a method	36
perform	36
setting	81

H

history	69
humidity	142

I

install	
barcode reader	57
ErgoSens	58

printer	54, 55	piece counting	42
put into operation	28	simple formulation	38
site	22	titration	39
terminal	23, 27	piece counting	
interface		create a method	42
Bluetooth	78	perform	42
Ethernet	77	setting	113
internal		power supply	
adjustment	52	see AC/DC adapter	142
L		print	
LabX	59, 79	result	54, 55
legal-for-trade balance		test page	54, 56
see approved balance	176	printer	53, 54, 55, 78
level		delete	59
balance	29	install	54, 55
indicator	18	test	54, 56
leveling aid	29, 69	R	
leveling aid	29, 69	repeatability test	48
LFT balance		create	46
see approved balance	176	setting	126
light		S	
StatusLight	76	safety information	11
location	22	sensitivity test	49
M		create	46
main weighing screen	17	setting	129
method	19	service	
clone	43	LabX	59, 79
create	35	MT-SICS	60, 79
delete	43	web	62, 79
edit	43	setting	
perform	35	adjustment	132
type	35	density determination	107
MT-SICS	60, 79	eccentricity test	122
O		general weighing	81
overview		piece counting	113
type label	16	repeatability test	126
P		sensitivity test	129
pack		simple formulation	90
balance	32	test	122
password		titration	100
unblock	66	simple formulation	
perform a method		create a method	38
density determination	41	perform	38
general weighing	36	setting	90
		SmartTrac	18

software	
version	7
sound	
terminal	76
standby	16, 30
StatusLight	76
store	
balance	32
switch on/off	29, 30
symbol	7
warning	11

T

tare	16, 30
temperature	142
acclimatization time	142
warm-up time	142
terminal	
brightness	76
install	23, 27
sound	76
StatusLight	76
test	19, 45
create	46
eccentricity	47
repeatability	48
sensitivity	49
setting	122
test weight	45
time	
acclimatization	29, 142
warm up	29, 142
titration	
create a method	39
perform	39
setting	100
transport	
long distance	32
short distance	31
type label	
overview	16

U

unlock	
balance	68
balance setting	67
unblocking password	66

USB	
printer	54, 78
see device	78

W

warm up	
time	29, 142
warning symbol	11
web service	62, 79
weighing aid	
SmartTrac	18
weighing screen	17
weight	
test weight	45

Z

zero	16, 30
initial	80

GWP®

Good Weighing Practice™

GWP® is the global weighing standard, ensuring consistent accuracy of weighing processes, applicable to all equipment from any manufacturer. It helps to:

- Choose the appropriate balance or scale
- Calibrate and operate your weighing equipment with security
- Comply with quality and compliance standards in laboratory and manufacturing

 www.mt.com/GWP

www.mt.com/XSR-precision

For more information

Mettler-Toledo GmbH

Im Langacher 44
8606 Greifensee, Switzerland
www.mt.com/contact

Subject to technical changes.
© 08/2022 METTLER TOLEDO. All rights reserved.
30357086H en



30357086